

TS 300 SC-SXC

1 2 0 5

219829003 - GB

USE AND MAINTENANCE MANUAL SPARE PARTS CATALOG

21982M00 29/01/98
preparato da UPT
approvato da DITE



UNI EN ISO 9001 : 2000

ISO 9001:2000 - Cert. 0192/3

MOSA has certified its quality system according to UNI EN ISO 9001:2000 to ensure a constant, high quality of its products. This certification covers the design, production and servicing of engine driven welders and generating sets.

The certifying institute, ICIM, which is a member of the International Certification Network IQNet, awarded the official approval to MOSA after an examination of its operations at the head office and plant in Cusago (MI), Italy.

This certification is not a point of arrival but a pledge on the part of the entire company to maintain a level of quality of both its products and services which will continue to satisfy the needs of its clients, as well as to improve the transparency and the communications regarding all the company's activities in accordance with the official procedures and in harmony with the MOSA Manual of Quality.

The advantages for MOSA clients are:

- Constant quality of products and services at the high level which the client expects;
- Continuous efforts to improve the products and their performance at competitive conditions;
- Competent support in the solution of problems;
- Information and training in the correct application and use of the products to assure the security of the operator and protect the environment;
- Regular inspections by ICIM to confirm that the requirements of the company's quality system and ISO 9001 are being respected.

All these advantages are guaranteed by the CERTIFICATE OF QUALITY SYSTEM No.0192 issued by ICIM S.p.A. - Milano (Italy) - www.icim.it

INDEX (for all MOSA models)

M 01	QUALITY SYSTEM	
M 1.01	COPYRIGHT	
M 1.1	NOTES	
M 1.4	NOTES	
M 2- ...	SYMBOLS AND SAFETY PRECAUTIONS	
M 2.3	ABBREVIATIONS LEGEND	
M 2.4	SYMBOLS	
M 2.5...	INSTALLATION AND ADVICE BEFORE USE	
M 2.6	INSTALLATIONS AND ADVICE	
M 2.7	INSTALLATION	
M 3	PACKING	
M 4	TRANSPORT AND DISPLACEMENTS	
M 6	ASSEMBLY: CT.....	
M 20	SETTING-UP THE UNIT (DIESEL ENGINE)	
M 21	ENGINE STARTING AND USE (DIESEL ENGINE)	
M 22	STOPPING THE ENGINE (DIESEL ENGINE)	
M 25	SETTING-UP THE UNIT (GASOLINE ENGINE)	
M 26	STARTING THE ENGINE (GASOLINE ENGINE)	
M 27	STOPPING THE ENGINE (GASOLINE ENGINE)	
M 30	CONTROLS LEGEND	
M 31	CONTROLS	
M 32	CONTROLS (FRONT PANEL)	
M 33	USE AS HYDRAULIC POWER TAKE-OFF	only for TS
M 34	USE AS A WELDER	only for TS
M 35	USE AS AN ENGINE STARTER	only for TS
M 36	USE AS A BATTERY CHARGE	
M 37	USE AS A GENERATOR	
M 38	USE OF THE REMOTE CONTROL	
M 39	USE OF THE ENGINE PROTECTION	
M 40	TROUBLE SHOOTING	
M 43	MAINTENANCE	
M 44	PERIODIC MAINTENANCE	
M 45	STORAGE	
M 46	CAST OFF	
M 51	TECHNICAL DATA	
M 52	TECHNICAL DATA ENGINE DRIVEN WELDER	only for TS
M 53	DIMENSIONS	
M 55	RECOMMENDED ELECTRODES	only for TS
M 60	ELECTRICAL SYSTEM LEGENDE	
M 61	ELECTRICAL SYSTEM	
M 65	HYDRAULIC SYSTEM	
R 1	SPARE PARTS LIST	
.....	SPARE PARTS	
K...	ACCESSORIES	

⚠ ATTENTION

This use and maintenance manual is an important part of the machines in question.

The assistance and maintenance personnel must keep said manual at disposal, as well as that for the engine and alternator (if the machine is synchronous) and all other documentation about the machine.

We advise you to pay attention to the pages concerning the security (see page M1.1).



© All rights are reserved to said Company.

It is a property logo of MOSA division of B.C.S. S.p.A. All other possible logos contained in the documentation are registered by the respective owners.

➡ The reproduction and total or partial use, in any form and/or with any means, of the documentation is allowed to nobody without a written permission by MOSA division of B.C.S. S.p.A.

To this aim is reminded the protection of the author's right and the rights connected to the creation and design for communication, as provided by the laws in force in the matter.

In no case MOSA division of B.C.S. S.p.A. will be held responsible for any damage, direct or indirect, in relation with the use of the given information.

MOSA division of B.C.S. S.p.A. does not take any responsibility about the shown information on firms or individuals, but keeps the right to refuse services or information publication which it judges discutible, unright or illegal.

INFORMATION

Dear Customer,
We wish to thank you for having bought from MOSA a high quality set.

Our sections for Technical Service and Spare Parts will work at best to help you if it were necessary.

To this purpose we advise you, for all control and overhaul operations, to turn to the nearest authorized Service Centre, where you will obtain a prompt and specialized intervention.

☞ In case you do not profit on these Services and some parts are replaced, please ask and be sure that are used exclusively original MOSA parts; this to guarantee that the performances and the initial safety prescribed by the norms in force are re-established.

☞ **The use of non original spare parts will cancel immediately any guarantee and Technical Service obligation from MOSA.**

NOTES ABOUT THE MANUAL

Before actioning the machine please read this manual attentively. Follow the instructions contained in it, in this way you will avoid inconveniences due to negligence, mistakes or incorrect maintenance. The manual is for qualified personnel, who knows the rules: about safety and health, installation and use of sets movable as well as fixed.

You must remember that, in case you have difficulties for use or installation or others, our Technical Service is always at your disposal for explanations or interventions.

The manual for Use Maintenance and Spare Parts is an integrant part of the product. It must be kept with care during all the life of the product.

In case the machine and/or the set should be yielded to another user, this manual must also given to him.

Do not damage it, do not take parts away, do not tear pages and keep it in places protected from dampness and heat.

You must take into account that some figures contained in it want only to identify the described parts and therefore might not correspond to the machine in your possession.

INFORMATION OF GENERAL TYPE

In the envelope given together with the machine and/or set you will find: the manual for Use Maintenance and Spare Parts, the manual for use of the engine and the tools (if included in the equipment), the guarantee (in the countries where it is prescribed by law).

Our products have been designed for the use of generation for welding, electric and hydraulic system; ANY OTHER DIFFERENT USE NOT INCLUDED IN THE ONE INDICATED, relieves MOSA from the risks which could happen or, anyway, from that which was agreed when selling the machine; MOSA excludes any responsibility for damages to the machine, to the things or to persons in this case.

Our products are made in conformity with the safety norms in force, for which it is advisable to use all these devices or information so that the use does not bring damage to persons or things.

While working it is advisable to keep to the personal safety norms in force in the countries to which the product is destined (clothing, work tools, etc.).

Do not modify for any motive parts of the machine (fastenings, holes, electric or mechanical devices, others..) if not duly authorized in writing by MOSA: the responsibility coming from any potential intervention will fall on the executioner as in fact he becomes maker of the machine.

☞ **Notice:** *this manual does not engage MOSA, who keeps the faculty, apart the essential characteristics of the model here described and illustrated, to bring betterments and modifications to parts and accessories, without putting this manual uptodate immediately.*



Tel.: 02 - 90352.1
 Fax: 02 - 90390466
 e-mail : info@mosa.it
 www.mosa.it

MOSA

Divisione della BCS S.p.A.
 V.le Europa 59 - 20090 Cusago (MI) - Italia



ISO 9001:2000 - Cert. 0192/3

DICHIARAZIONE DI CONFORMITA'

Déclaration de Conformité – Declaration of Conformity – Konformitätserklärung
 Conformanceverklaring – Declaración de Conformidad

MOSA dichiara sotto la propria responsabilità che la macchina:
 MOSA déclare, sous sa propre responsabilité, que la machine:
 MOSA declares, under its own responsibility, that the machine:
 MOSA erklärt, daß die Aggregate:
 MOSA verklaard, onder haar eigen verantwoordelijkheid, dat de machine:
 MOSA declara bajo su responsabilidad que la máquina:

Modello/Modèle/Model/Modell/Model/Modelo: _____

Codice/ Code/ Code/ Kode/ Code/ Codice: _____

è conforme con quanto previsto dalle **Directive Comunitarie** e relative modifiche:
 est en conformité avec ce qui est prévu par les **Directives Communautaires** et relatives modifications:
 conforms with the **Community Directives** and related modifications:
 mit den Vorschriften der Gemeinschaft und deren Ergänzungen übereinstimmt:
 in overeenkomst is met de inhoud van gemeenschapsrichtlijnen en gerelateerde modificaties:
 cumple con los requisitos de la **Directiva Comunitaria** y sus anexos:

98/37/CE - 73/23/CE - 89/336/CE - 2000/14/CE

per la verifica sono state considerate le seguenti norme armonizzate, Norme nazionali e internazionali:
 pour la vérification de la conformité ont été consultées les normes harmonisées suivantes, normes nationales
 et internationales:
 to check the conformity, the following harmonized norms, national and international norms, have been
 consulted:
 zur Prüfung hat man die folgenden übereinstimmenden nationalen und internationalen Normen herangezogen:
 ter verificatie van de overeenkomst, zijn de volgende geharmoniseerde normen, nationaal en internationaal,
 geconsulteerd:
 para su verificación se han tenido en cuenta las Normas armonizadas, Normas nacionales e internacionales:

Norme armonizzate - normes harmonisées - harmonized norms - übereinstimmende Normen
 geharmoniseerde normen - Normas armonizadas:

EN 292-1 EN 292-2**EN 60204-1**

EN 50199 EN 60974-1 (Solo per modelli - Seulement pour les modèles - Only for models - nur für die
 Modelle - Alleen voor de modellen - Sólo para modelos: **TS**)

EN 50081-2 EN 50082-2

Altre norme - autres normes - other norms - andere Normen - andere normen - otras normas:

ISO 8528 (Solo per modelli - Seulement pour les modèles - Only for models - nur für die
 Modelle - Alleen voor de modellen - Sólo para modelos: **GE**)

Ing. Benso Marelli
 Direttore Generale

Cusago, _____

MM 065.2.doc


CE The CE mark (European Community) certifies that the product complies with the essential safety requirements provided by the applicable COMMUNITY DIRECTIVES. In the Conformity Declaration are reported the HARMONIZED NORMS and not, used for the checking.

SYMBOLS IN THIS MANUAL

- The symbols used in this manual are designed to call your attention to important aspects of the operation of the machine as well as potential hazards and dangers for persons and things.

IMPORTANT ADVICE

- Advice to the User about the safety:

 N.B.: The information contained in the manual can be changed without notice. Potential damages caused in relation to the use of these instructions will not be considered because these are only indicative. Remember that the non observance of the indications reported by us might cause damage to persons or things. It is understood, that local dispositions and/or laws must be respected.

WARNING



Situations of danger - no harm to persons or things

Do not use without protective devices provided

Removing or disabling protective devices on the machine is prohibited.

Do not use the machine if it is not in good technical condition

The machine must be in good working order before being used. Defects, especially those which regard the safety of the machine, must be repaired before using the machine.

SAFETY PRECAUTIONS



DANGEROUS

This heading warns of an immediate danger for persons as well for things. Not following the advice can result in serious injury or death.



WARNING

This heading warns of situations which could result in injury for persons or damage to things.



CAUTION

To this advice can appear a danger for persons as well as for things, for which can appear situations bringing material damage to things.



IMPORTANT



NOTE



ATTENTION

These headings refer to information which will assist you in the correct use of the machine and/or accessories.

SYMBOLS (for all MOSA models)



STOP - Read absolutely and be duly attentive



Read and pay due attention



GENERAL ADVICE - If the advice is not respected damage can happen to persons or things.



HIGH VOLTAGE - Attention High Voltage. There can be parts in voltage, dangerous to touch. The non observance of the advice implies life danger.



FIRE - Danger of flame or fire. If the advice is not respected fires can happen.



HEAT - Hot surfaces. If the advice is not respected burns or damage to things can be caused.



EXPLOSION - Explosive material or danger of explosion. in general. If the advice is not respected there can be explosions.



WATER - Danger of shortcircuit. If the advice is not respected fires or damage to persons can be caused.



SMOKING - The cigarette can cause fire or explosion. If the advice is not respected fires or explosions can be caused.



ACIDS - Danger of corrosion. If the advice is not respected the acids can cause corrosions with damage to persons or things.



WRENCH - Use of the tools. If the advice is not respected damage can be caused to things and even to persons.



PRESSION - Danger of burns caused by the expulsion of hot liquids under pressure.



ACCES FORBIDDEN to non authorizad people.

PROHIBITIONS No harm for persons

Use only with safety clothing -



It is compulsory to use the personal protection means given in equipment.

Use only with safety clothing -



It is compulsory to use the personal protection means given in equipment.

Use only with safety protections -



It is a must to use protection means suitable for the different welding works.

Use with only safety material -



It is prohibited to use water to quench fires on the electric machines.

Use only with non inserted voltage -



It is prohibited to make interventions before having disinserted the voltage.

No smoking -



It is prohibited to smoke while filling the tank with fuel.

No welding -



It is forbidden to weld in rooms containing explosive gases.

ADVICE No harm for persons and things

Use only with safety tools, adapted to the specific use -

It is advisable to use tools adapted to the various maintenance works.

Use only with safety protections, specifically suitable



It is advisable to use protections suitable for the different welding works.

Use only with safety protections -



It is advisable to use protections suitable for the different daily checking works.

Use only with safety protections -





It is advisable to use all protections while shifting the machine.

Use only with safety protections -













































































It is advisable to use protections suitable for the different daily checking works.and/or of maintenance.

<p>°C: temperature Celsius grades 10:10 kVA synchronous (wording example) 10000:10 kVA asynchronous (wording example) A: Ampere A: ADIM engine atm: pressure B: petrol BAT: battery BC: base current C.A.(c.a.): alternating current C.B.: battery charger C.C.(c.c.): direct current cc: cm³ (volume) CE: European norm conformity CF: special for pipe welding CTL: slow touring trolley CTM CTV: fast touring trolley: hand touring trolley D: diesel D: GFI D: Deutz engine E: electric start EAS: automatic intervention panel for generating sets for connection to the mains EL: electronic regulation, allows to use welder and generating set simultaneously EP1: automatic accelerator according to requested power, engine protection, low oil pressure, high temperature with engine stop, trouble warning lights EP2: engine protection, low oil pressure, high temperature with engine stop, trouble warning lights EP4: engine protection, low oil pressure, high temperature with engine stop, no battery charge, belt broken, low fuel level with engine stop, trouble warning lights EP5: engine protection, low oil pressure, high temperature with engine stop, no battery charge, belt broken, low fuel level with engine stop, overspeed, trouble warning lights EP6: Control and protection unit of generating sets. It has operating modes OFF – MAN – AUTO. It protects the engine for low oil pressure, high temperature, belt broken, no battery charge and low fuel level, over speed and under speed, over and under voltage and no starting. It shows besides: voltage, frequency and current generator, current battery voltage and battery charge, engine rpm. EP6 disposes of 29 programmable parameters. ES: oil/temperature engine protection device EV: electrovalve g/kwh: grams/kilowatt hour (engine consumption) GA: asynchronous alternator GE: generating set GHF: high frequency alternator GS: synchronous alternator h: hour meter (symbol) H: Hatz engine H: Honda engine HI: hydraulic central Hz: frequency I: single-phase auxiliary generation (symbol 1~)</p>	<p>IP: protection grade for electric devices against access to dangerous parts according to the IEC 529 norm (Internal Protection) kg: kilogram (mass) K: welding cables set kVA: kilovolt ampere kW: kilowatt (engine power) kWh: kilowatt hour (energy) l: liters (capacity) L: Lombardini engine Lwa: maximum acoustic (power level) according to the regulations in force mm: millimeter (length) (measure) m: meter (length) mA: milliampere MS-MSG: MOSA engine driven welder with high frequency alternator MT: magnetothermic switch MT: grounding kit MTD: magnetothermic switch / GFI OH: heater (engine oil) for generating sets P: plus PAC: power electric frame PAR: device for double PB: battery holder PL: „pipe line“ welding PS: exhaust pipe extension PW: welder for polyethylene and propylene pipes QEA: automatic electric panel QEM: manual electric panel R: Ruggerini engine RVT: voltage electronic regulator S: symbol of EN 60974-1 S: Suzuki engine SKID: unit assembled on a base with no protection (no fairing) S-SC: silenced (faired) - silenced compact (faired) SX-SXC: supersilenced (faired and sound prof) - supersilenced compact (faired and super sound prof) T: thermic switch TC-TCM-TCPL: remote control TS: welder with asynchronous alternator V: Volt Y: Yanmar engine Y: three-phase auxiliary generation (symbol 3~)</p>
-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------


 Conformity CE	 EEC Sound power conformity	 EN 60974-1 conformity	 Triphase 3 ~	 Singlephase 1 ~	 Users' manual	 Information	 Various news
----------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------

Equipment and optional


Engine	 Gasoline engine	 Diesel engine	 Air cooling	 Water cooling	 Manual recoil	 Electric start	 Battery 12 V			
Engine protection	 Engine protection	 Engine protection	 Engine protection	 Engine protection	 Engine protection	 Siren	 Engine shut down (oil)	 Engine speed		
Engine alarms	 Oil level indicator	 Battery charger indicator	 Fuel level gauge/low fuel	 Low fuel indicator	 Oil temperature	 Warning light for preheating glow plugs	 Air filter blockage	 Belt breakage	 Over speed	 Control unit QEA
Generation	 Asynchronous alternator	 Synchronous alternator	 Generator high frequency	 Voltmeter	 Frequency-meter	 Ammeter	 Compound	 Voltmeter phase selector	 Electronic Voltage regulator	 Switch
Electric protection	 Circuit breaker/ Ground fault interrupter	 Circuit breaker	 Ground fault interrupter	 Thermal shut off	 Fuse	 Isolation monitoring				
Generation use	 Terminal strip	 3 ~ CEE Socket 400/230V EEC	 1 ~ CEE Socket 230/110/48V EEC	 1 ~ Schuko Socket 230V Schuko	 Socket 48V EEC	 Battery charger	 Engine booster			
Welding control	 Arc control	 Welding with covered electrode	 Welding current electr. regulation	 Base current diode bridge	 Polarity inverter	 CC/CV selector	 Constant current	 Constant voltage	 Contact starting	TIG
Various devices	 Hour counter	 Ready for TC	 Ground connection point	 Emergency stop button	 Central lifting eye					
Various	 Standard equipment	 Options on request				 D.C.	 A.C.	 Plus	 Minus	 Maintenance Time
Optionals	 Trolley	 Site tow	 Welding cables	 Remote control						

 The installation and the general advice concerning the operations, are finalized to the correct use of the machine, in the place where it is used as generator group and/or welder.



















ENGINE	Stop engine when fueling	CHECKING BOARD	Do not touch electric devices if you are barefoot or with wet clothes.
	Do not smoke, avoid flames, sparks or electric tools when fueling.		Always keep off leaning surfaces during work operations
	Unscrew the cap slowly to let out the fuel vapours.		Static electricity can damage the parts on the circuit.
	Slowly unscrew the cooling liquid tap if the liquid must be topped up.		An electric shock can kill
	The vapor and the heated cooling liquid under pressure can burn face, eyes, skin.		
	Do not fill tank completely.		
	Wipe up spilled fuel before starting engine.		
	Shut off fuel of tank when moving machine (where it is assembled).		
	Avoid spilling fuel on hot engine.		
	Sparks may cause the explosion of battery vapours		

 **FIRST AID.** In case the operator should be sprayed by accident, from corrosive liquids a/o hot toxic gas or whatever event which may cause serious injuries or death, predispose the first aid in accordance with the ruling labour accident standards or of local instructions.

Skin contact	Wash with water and soap
Eyes contact	Irrigate with plenty of water, if the irritation persists contact a specialist
Ingestion	Do not induce vomit as to avoid the intake of vomit into the lungs, send for a doctor
Suction of liquids from lungs	If you suppose that vomit has entered the lungs (as in case of spontaneous vomit) take the subject to the hospital with the utmost urgency
Inhalation	In case of exposure to high concentration of vapours take immediately to a non polluted zone the person involved

 **FIRE PREVENTION.** In case the working zone, for whatsoever cause goes on fire with flames liable to cause severe wounds or death, follow the first aid as described by the ruling norms or local ones.

EXTINCTION MEANS	
Appropriated	Carbonate anhydride (or carbon dioxide) powder, foam, nebulized water
Not to be used	Avoid the use of water jets
Other indications	Cover eventual shedding not on fire with foam or sand, use water jets to cool off the surfaces close to the fire
Particular protection	Wear an autorespiratory mask when heavy smoke is present
Useful warnings	Avoid, by appropriate means to have oil sprays over metallic hot surfaces or over electric contacts (switches, plugs, etc.). In case of oil sprinkling from pressure circuits, keep in mind that the inflammability point is very low.

 WARNING					 CAUTION		 DANGEROUS
							
							

 **WARNING** **THE MACHINE MUST NOT BE USED IN AREAS WITH EXPLOSIVE ATMOSPHERE**



INSTALLATION AND ADVICE BEFORE USE

The operator of the welder is responsible for the security of the people who work with the welder and for those in the vicinity.

The security measures must satisfy the rules and regulations for engine driven welders.

The information given below is in addition to the local security norms.

Estimate possible electromagnetic problems in the work area taking into account the following indications.

1. Telephonic wirings and/or of communication, check wirings and so on, in the immediate vicinity.
2. Radio and television receptors and transmitters.
3. Computer and other checking devices.
4. Critical devices for safety and/or for industrial checks.
5. People who, for instance, use pace-maker, hearing-aid for deaf or something and else.
6. Devices used for rating and measuring.
7. The immunity of other devices in the operation area of the welder. Make sure that other used devices are compatible. If it is the case, provide other additional measures of protection.
8. The daily duration of the welding time.



Make sure that the area is safe before starting any welding operation.

- ▮▮▮ Do not touch any bare wires, leads or contacts as they may be live and there is danger of electric shock which can cause death or serious burns. The electrode and welding cables, etc. are live when the unit is operating.
- ▮▮▮ Do not touch any electrical parts or the electrode while standing in water or with wet hands, feet or clothes.
- ▮▮▮ Insulate yourself from the work surface while welding. Use carpets or other insulating materials to avoid physical contact with the work surface and the floor.
- ▮▮▮ Always wear dry, insulating gloves, without holes, and body protection.
- ▮▮▮ Do not wind cables around the body.
- ▮▮▮ Use ear protections if the noise level is high.
- ▮▮▮ Keep flammable material away from the welding area.
- ▮▮▮ Do not weld on containers which contain flammable material.
- ▮▮▮ Do not weld near refuelling areas.
- ▮▮▮ Do not weld on easily flammable surfaces.
- ▮▮▮ Do not use the welder to defrost (thaw) pipes.
- ▮▮▮ Remove the electrode from the electrode holder, when not welding.
- ▮▮▮ Avoid inhaling fumes by providing a ventilation system or, if not possible, use an approved air breather.
- ▮▮▮ Do not work in closed areas where there is no fresh air flow.
- ▮▮▮ Protect face and eyes (protective mask with suitable dark lens and side screens), ears and body (non-flammable protective clothers).





INSTALLATION AND ADVICE BEFORE USE

GASOLINE ENGINES

- Use in open space, air swept or vent exhaust gases, which contain the deadly carbone oxyde, far from the work area.


DIESEL ENGINES

- Use in open space, air swept or vent exhaust gases far from the work area.




POSITION


Place the machine on a level surface at a distance of at least 1,5 m from buildings or other plants.



Maximum leaning of the machine (in case of dislevel)



Check that the air gets changed completely and the hot air sent out does not come back inside the set so as to cause a dangerous increase of the temperature.



☞ Make sure that the machine does not move during the work: **block** it possibly with tools and/or devices made to this purpose.

MOVES OF THE MACHINE

☞ At any move check that the engine is **off**, that there are no connections with cables which impede the moves.

PLACE OF THE MACHINE



In spots where it often rains and/or there are flooded areas, do **not** put the machine:


- in the bad weather
- in flooded places.

Protect all the electric parts at risk, because water infiltrations could cause short circuits with damages at persons and/or things.

The protection degree of the machine is put on the data plate and in this manual at page "Technical Data".

Apertura pannello frontale
Opening cover front panel
Ouverture couvercle frontal
Frontdeckel öffnen
Apertura tapa

Gancio di sollevamento - Central lifting eye
Oeillet central de levage - Zentrale Hebeöse
Gancho de elevación




Uscita aria - Air outlet
Expulsion air - Luftaustritt
Salida aire

Apertura portellone
Cover opening
Overture portillon
Klappe öffnen
Apertura tapa

Entrata aria - Air inlet
Entrée air - Lufteintritt
Entrada aire

Caricamento carburante
Fuel filling
Remplissage carburant
Tankstutzen
Carga combustible




SUPERFICIE CALDA
HOT SURFACE
SURFACE TRES CHAUDE
HEIßER BEREICH
SUPERFICIE CALIENTE

Scarico silenziatore motore
Gas exhaust pipe
Tuyau d'échappement gaz
Auspuffgase Motor
Tubo de descarga gas

Entrata aria
Air inlet
Entrée air
Lufteintritt
Entrada aire



NOTE






Be sure that the lifting devices are: correctly mounted, adequate for the weight of the machine with its packaging, and conforms to local rules and regulations.

When receiving the goods make sure that the product has not suffered damage during the transport, that there has not been rough handling or taking away of parts contained inside the packing or in the set.

In case you find damages, rough handling or absence of parts (envelopes, manuals, etc.), we advise you to inform immediately our Technical Service.



For eliminating the packing materials, the User must keep to the norms in force in his country.



- 1) Take the machine (C) out of the shipment packing. Take out of the envelope (A) the user's manual (B).
- 2) Read: the user's manual (B), the plates fixed on the machine, the data plate.



**NOTE**

In case you should transport or move the machine, keep to the instructions as per the figures.

Make the transportation when the machine has **no** petrol in its tank, **no** oil in the engine and and electrolyte in the battery.




Be sure that the lifting devices are: correctly mounted, adequate for the weight of the machine with it's packaging, and conform to local rules and regulations.

Only authorized persons involved in the transport of the machine should be in the area of movement.


DO NOT LOAD OTHER PARTS WHICH CAN MODIFY WEIGHT AND BARICENTER POSITION.

IT IS STRICTLY FORBIDDEN TO DRAG THE MACHINE MANUALLY OR TOW IT BY ANY VEHICLE (model with no CTL accessory).

If you did not keep to the instructions, you could damage the structure of the machine.



LIFT ONLY THE MACHINE



DO NOT LIFT THE MACHINE AND TRAILER



DANGER: LIFTING EYE IS NOT DESIGNED TO SUPPORT ADDED WEIGHT OF ROAD TOW TRAILER



**NOTE**

In case you should transport or move the machine, keep to the instructions as per the figures.

Make the transportation when the machine has **no** petrol in its tank, **no** oil in the engine and and electrolyte in the battery.


Be sure that the lifting devices are: correctly mounted, adequate for the weight of the machine with it's packaging, and conform to local rules and regulations.

Only authorized persons involved in the transport of the machine should be in the area of movement.

DO NOT LOAD OTHER PARTS WHICH CAN MODIFY WEIGHT AND BARICENTER POSITION.

IT IS STRICTLY FORBIDDEN TO DRAG THE MACHINE MANUALLY OR TOW IT BY ANY VEHICLE (model with no CTM accessory).

If you did not keep to the instructions, you could damage the structure of the machine.





ATTENTION


The CTL or CTM accessory cannot be removed from the machine and used separately (actioned manually or following vehicles) for the transport of loads or anyway for used different from the machine movements.

TRAILERS

The machines provided for assembling the CTL accessory (slow towing trolley) can be towed up to a **maximum** speed of **40 Kms/hour** on asphalted surfaces.


Towing on public roads or turnpikes of any type **IS EXCLUDED**, because **not** in possession of the requirements by national and foreign traffic norms.

Nota: Lift the machine and assemble the parts as shown in the drawing



For assembling the generating set on the trolley CTL300 please keep to following instructions:

- 1) - Lift the generating set (by means of suitable hook).
- 2) - Slightly fix the jaw (3) of the parking foot to the bar with the M10x20 screws, the M10 nuts and the washers (so as to let the foot sprag go through).
- 3) - Split (unscrewing them) the two parts of the foot (4S-4I) to be able later to assemble them on the jaw.
- 4) - Introduce into the jaw (3) the upper part (4S) of the foot and screw again the lower part (4I), then tighten the screws (4V) of the jaw to the towbar and block momentarily with the lever (4L) the whole foot.
- 5) - Assemble on the machine the towbar (5) complete of foot with the M10x20 screws, nuts and washers (see fig. page M6.4).
- 6) - Assemble the axle (7) to the base of the machine (see fig. page M6.4) with the M 8x20 screws and relative washers (two per part) so that their supports coincide.
- 7) - Introduce on the axle the antidust ring (7A) with folded edges turned toward the machine.
- 8) - Insert the wheel (9) on the axle paying attention to the spacer (8D) which is between the two bearings, then insert the selflocking nut (8A) and finally assemble the shutting cap (8C).
- 9) - Pump the tyre (9) bringing the pressure to three atms.
- 10)- Lower the machine to the ground and place the parking foot definitively (regulating at the best height).



ATTENTION

Do not substitute the original tires with other types.





BATTERY WITHOUT MAINTENANCE



Connect the cable + (positive) to the pole + (positive) of the battery (after having taken away the protection), by properly tightening the clamp.

Check the state of the battery from the colour of the warning light which is in the upper part.

- Green colour: battery OK
- Black colour: battery to be recharged
- White colour: battery to be replaced

DO NOT OPEN THE BATTERY.



LUBRICANT

RECOMMENDED OIL

MOSA recommends selecting **AGIP** engine oil. Refer to the label on the motor for the recommended products.

<p>PRODOTTI RACCOMANDATI RECOMMENDED PRODUCTS</p>	
<p>AGIP SUPERDIESEL 15W/40 API CF4-SG</p>	<p>OLIO MOTORE DIESEL DIESEL ENGINE OIL</p>
<p>AGIP SUPERMOTOROIL 20W/50 API CC-SF</p>	<p>OLIO MOTORE BENZINA GASOLINE ENGINE OIL</p>
<p>AGIP ANTIFREEZE EXTRA INIBITE ETHYLENE GLYCOL (50% + 50% H₂O)</p>	<p>CIRCUITO DI RAFFREDDAMENTO COOLING CIRCUIT (CUNA NC 956-16 ED 97)</p>

Please refer to the motor operating manual for the recommended viscosity.

REFUELLING AND CONTROL:

Carry out refuelling and controls with motor at level position.

1. Remove the oil-fill tap (24)
2. Pour oil and replace the tap
3. Check the oil level using the dipstick (23); the oil level must be comprised between the minimum and maximum indicators.



ATTENTION

It is dangerous to fill the motor with too much oil, as its combustion can provoke a sudden increase in rotation speed.



DRY AIR FILTER

Check that the dry air filter is correctly installed and that there are no leaks around the filter which could lead to infiltrations of non-filtered air to the inside of the motor.



OIL BATH AIR FILTER

Fill the air filter using the same engine oil up to the level indicated on the filter.



FUEL



ATTENTION



Do not smoke or use open flames during refuelling operations, in order to avoid explosions or fire hazards.

Fuel fumes are highly toxic; carry out operations outdoors only, or in a well-ventilated environment.



Avoid accidentally spilling fuel. Clean any eventual leaks before starting up motor.

Refill the tank with good quality diesel fuel, such as automobile type diesel fuel, for example.

For further details on the type of diesel fuel to use, see the motor operating manual supplied.

Do not fill the tank completely; leave a space of approx. 10 mm between the fuel level and the wall of the tank to allow for expansion.

In rigid environmental temperature conditions, use special winterized diesel fuels or specific additives in order to avoid the formation of paraffin.



GROUNDING CONNECTION

The grounding connection to an earthed installation **is obligatory** for all models equipped with a differential switch (circuit breaker). In these groups the generator star point is generally connected to the machine's earthing; by employing the TN or TT distribution system, the differential switch guarantees protection against indirect contacts.

In the case of powering complex installations requiring or employing additional electrical protection devices, the coordination between the protection devices must be verified.

For the grounding connection, use the terminal (12); comply to local and/or current regulations in force for electrical installations and safety.





Check daily



NOTE

Do not alter the primary conditions of regulation and do not touch the sealed parts.


ENGINES WITH MANUAL RECOIL



Hold the starting handle firmly.



Pull the rope hard and fast. Pull it all the way out. Use two hands if necessary.




Then returning it slowly.

ENGINES WITH ACCELERATOR LEVER

Make sure that the accelerator lever or the switch (16) is at its minimum setting.

Insert the electric protection device (D-Z2-N2) lever towards above and, where mounted, check the isolation monitor (A3) see page M37 –



Introduce the key (Q1), turn it clockwise completely, leaving it as soon as the engine starts and/or the push button (32) (models without key) leaving it as soon as the engine starts.

NB.: for safety reason the key must be kept by qualified personel.

Once the engine has started leave it running at a reduced speed for some minutes.

Accelerate the engine at max., set lever on maximum position and then take up load.

ENGINES WITHOUT ACCELERATOR LEVER

Insert the electric protection device (D-Z2-N2) lever towards above and, where mounted, check the isolation monitor (A3) see page M37 –



Introduce the key (Q1), turn it clockwise completely, leaving it as soon as the engine starts.

NB.: for safety reason the key must be kept by qualified personel.

Let the engine run for some minutes before drawing the load.

Open the fuel cock (where it is assembled).



CAUTION

RUNNING-IN

During the first 50 hours of operation, do not use more than 60% of the maximum output power of the unit and check the oil level frequently, in any case please stick to the rules given in the engine use manual.



NOTE

The machines with E.P. 1 engine protection device (D1), use the accelerator lever ONLY IN EMERGENCY when the engine protection does not work. In this case turn immediately to our Authorized Assistance Centers.

**ENGINE WITH PREHEATING GLOW PLUGS**

Turn the starter key (Q1) on the position „preheating glow plugs“ (the glow plugs light will be on I4), when the light is off, turn the starter key completely clockwise until the engine begins to fire.

Let the engine run for some minutes before drawing the load.

ENGINES WITH R.P.M. ELECTRONIC ADJUSTER (ONLY FOR GENERATING SET)

Turn the starter key (Q1) completely clockwise until the engine begins to fire.

☞ Wait for the AUTOMATIC preheating time before drawing the load

OCCASIONAL USE OF THE ENGINE

Using the engine in special conditions which need an immediate intervention, such as emergency plants, etc., use advise to use our Engine Assistance Centres for specific interventions or our Technical Assistance Service.

**CAUTION**

If the engine fails to start, do not insist for at least 15 seconds.

Space the further operations waiting for at least 4 minutes.


**CAUTION****MACHINE WITH EMERGENCY BUTTON**

Before starting the engine, make sure that the emergency button (32B) is off (turn the button clockwise for this operation)


**CAUTION*****RUNNING-IN***

During the first 50 hours of operation, do not use more than 60% of the maximum output power of the unit and check the oil level frequently, please follow the instructions on the engine use and maintenance manual..

☞ Before stopping the engine **it is compulsory** to effect the following operations:
- stop to draw three/single-phase current from the auxiliary sockets.



- stop to draw power from the welding sockets (only for TS models).




ENGINES WITH ACCELERATOR LEVER

☞ Make sure that the unit is not supplying any power.

Disconnect the electrical protection device (D-Z2-N2) lever downward.

Set the accelerator lever or the switch (16) to minimum position and wait for a few minutes to allow the engine to cool, anyway follow the instructions contained in the engine manual.

Pull the stop lever (28) until the engine stops (where it is assembled).



Remove the key (Q1) turning it counter clockwise, OFF position, then take it out.

☞ **NB.:for safety reason the key must be kept by qualified personnel.**

ENGINES WITHOUT ACCELERATOR LEVER

Make sure that the unit is not supplying any power.

Disconnect the electrical protection device (D-Z2-N2) lever downward.

Let the engine idle for a few minutes.

Press the pushbutton (F3) until the engine stops

(where it is assembled).

Shut the fuel cock (where it is assembled).



Remove the key (Q1) turning it counter clockwise, OFF position, then take it out.

☞ **NB.: for safety reason the key must be kept by qualified personnel.**

ENGINES WITH R.P.M. ELECTRONIC ADJUSTER (ONLY FOR GENERATING SET)

Make sure that the unit is not supplying any power.

Disconnect the electrical protection device (D-Z2-N2) lever downward.

Let the engine idle for a few minutes.

Press the pushbutton (F3) until the engine stops (where it is assembled).



Remove the key (Q1) turning it counter clockwise, OFF position, then take it out.


☞ **NB.: for safety reason the key must be kept by qualified personnel.**





CAUTION

MACHINE WITH EMERGENCY BUTTON
















Pressing it, it allows to stop the engine in any condition (32B) (when assembled).
To re-establish it, see page M21...
















4A	Hydraulic oil level light	B5	Auxiliary current push button
9	Welding socket (+)	C2	Fuel level light
10	Welding socket (-)	C3	E.A.S. PCB
12	Earth terminal	C6	Control unit for generating sets QEA
15	A.C. socket	D	Ground fault interrupter (30 mA)
16	Accelerator lever	D1	Engine control unit and economiser EP1
17	Feed pump	D2	Ammeter
19	48V D.C. socket	E2	Frequency meter
22	Engine air filter	F	Fuse
23	Oil level dipstick	F3	Stop switch
24	Engine oil reservoir cap	F5	Warning light, high temperature
24A	Hydraulic oil reservoir cap	F6	Arc-Force selector
24B	Water filling cap	G1	Fuel level transmitter
25	Fuel prefilter	H2	Voltage commutator
26	Fuel tank cap	H6	Fuel electro pump
27	Muffler	I2	48V A.C. socket
28	Stop control	I3	Welding scale switch
29	Engine protection cover	I4	Preheating indicator
30	Engine cooling/alternator fan belt	I5	Y/▲ switch
31	Oil drain tap	I6	Start Local/Remote selector
31A	Hydraulic oil drain tap	L	A.C. output indicator
31B	Water drain tap	L5	Emergency button
31C	Exhaust tap for tank fuel	L6	Choke button
32	Button	M	Hour counter
33	Start button	M1	Warning level light
34	Booster socket 12V	M2	Contacto
34A	Booster socket 24V	M5	Engine control unit EP5
35	Battery charge fuse	M6	CC/CV switch
36	Space for remote control	N	Voltmeter
37	Remote control	N1	Battery charge warning light
42	Space for E.A.S.	N2	Thermal-magnetic circuit breaker/Ground fault interrupter
42A	Space for PAC	N5	Pre-heat push-button
47	Fuel pump	N6	Connector - wire feeder
49	Electric start socket	O1	Oil pressure warning light/Oil alert
54	Reset button PTO HI	P	Welding arc regulator
55	Quick coupling m. PTO HI	Q1	Starter key
55A	Quick coupling f. PTO HI	Q3	Derivation box
56	Hydraulic oil filter	Q4	Battery charge sockets
59	Battery charger thermal switch	R3	Siren
59A	Engine thermal switch	S	Welding ammeter
59B	Aux current thermal switch	S1	Battery
59C	Supply thermal switch wire feeder-42V	S3	Engine control unit EP4
59D	Pre-heater (spark plug) thermal switch	S6	Wire feeder supply switch
59E	Supply thermal switch oil/water heater	S7	Plug 230V singlephase
63	No load voltage control	T	Welding current regulator
66	Choke control	T4	Dirty air filter warning light/indicator
67A	Auxiliary / welding current control	T5	Earth leakage relay
68	Cellulosic electrodes control	T7	Analogic instrument V/Hz
69A	Voltmeter relay	U	Current transformer
70	Warning lights	U3	R.P.M. adjuster
71	Selecting knob	U4	Polarity inverter remote control
72	Load commut. push button	U5	Release coil
73	Starting push button	V	Welding voltage voltmeter
74	Operating mode selector	V4	Polarity inverter control
75	Power on' warning light	V5	Oil pressure indicator
76	Display	W1	Remote control switch
79	Wire connection unit	W3	Selection push button 30 I/1' PTO HI
86	Selector	W5	Battery voltmeter
86A	Setting confirmation	X1	Remote control socket
87	Fuel valve	Y3	Button indicating light 20 I/1' PTO HI
88	Oil syringe	Y5	Commutator/switch, serial/parallel
A3	Insulation monitoring	Z2	Thermal-magnetic circuit breaker
A4	Button indicating light 30 I/1' PTO HI	Z3	Selection push button 20 I/1' PTO HI
B2	Engine control unit EP2	Z5	Water temperature indicator
B3	E.A.S. connector		
B4	Exclusion indicating light PTO HI		



According to the version of the machine on the front panel there are assembled some instruments:

	warning lights (L) corresponding to the current sockets on the front panel, indicate that the current can be drawn from the sockets when they are lit (I5);
	voltmeter (N);
	GFI (D), Thermal magnetic circuit breaker (Z2) (TS...PL: : one for each auxiliary socket) or Thermal magnetic circuit breaker/GFI (N2);
	voltage selector switch (H2);
	insulation monitoring (A3)- See page M 39.10 -;
	hour-counter (M), which indicates the hours of effective operation of the unit;
	fuse (F), which protects the electric circuit of the engine, replacement of which, in case it breaks, must be effected <u>absolutely</u> with the machine <u>stopped</u> . Remove the mechanical protection, then shift down the small lever of the fuse holder placed on the front panel;
	fuel level gauge (M1): when the quantity of fuel in the tank falls below 5 litres a warning light on the instrument panel lights up;
	fuel level indicator (C2);
	preheating glow plugs warning light (I4) for the preheating (for diesel engines it shows the intervention time of the glow plugs);
	dirty air filter warning light (T4);
	ammeter (D2) indicates the drawn current. In case current is drawn simultaneously from several sockets, it shows the current sum. (DO NOT GO OVER THE MAX. CURRENT INDICATED ON THE LABEL);
	star/ triangle switch (I5);
	frequency meter (E2), that indicates the frequency generated and therefore the number of revolutions of the engine: the frequency should be of 52 Hz» or 62 Hz» when the unit is idle and about 50 Hz or 60 Hz at full load (in case that the found value is different make sure that the engine is completely accelerated), (do never use the unit with a frequency lower than 49 Hz or 59 Hz, in this case decrease the load);
	tone horn (R3)) indicates the defects in the engine;

	engine protections: EV - EP1 (D1) (for engine at 3000/3600 rpm.), EP2 (B2 for engine at 1500/1800 rpm), EP4 – EP5 (M5)- See pag. M39 -;
	starter key (Q1) and engine stop;
	welding socket (gouging, when assembled, - 9+ - 10-) - See pag. M 34 -;
	Emergency button (L5);
	Control switch for accelerator (only for engine at 3000/3600 rpm) - WE ADVISE TO USE THE SWITCH ONLY IF THE EP1 DEVICE IS BROKEN);
	auxiliary current push button (B5);
	welding current regulator (T) and/or „arc force“ selector (F6) - See pag. M34 -1;
	welding scale switch (I3);
	polarity inverter control (V4);- See pag M34 -1;
	cellulosic electrodes control (68);- See pag M34 -1;
	Protection fuse for welding PCB, welding ammeter (S);
	remote control switch (W1) and remote control socket (X1) - See pag M38 -;
	switch CC/CV (M6)- See pag M34 -1;-



This symbol (Norm EN 60974-1 security standards for arc welders) signifies that the welder can be used in areas with increased risk of electrical shock.



ATTENTION

The sockets, after the machine is started (see pages M21-26), also with no cables, are anyway under voltage.




ATTENTION

The areas, access of which is forbidden to unqualified personel, are:
 - the control switchboard (front) - the exhaust of the endothermic engine - the welding process.

Check at the beginning of any work the electric parameters and/or the control placed on the front.

Make sure that the ground connection (12) is efficient (keep to installation local rules and/or to national laws), in order to integrate or ensure the working of varius electric protection devices referring to the several distribution system TT/TN/IT, operation unnecessary for machine with isometer.

Fully insert the welding cable plugs into the corresponding sockets ("only gauging", 9+/10-) turning them clockwise to lock them in position.



Make sure that the ground clamp ,whose cable must be connected to the + or - terminal, depending on the type of electrode, makes a good connection and is near to the welding position.

Pay attention to the two polarities of the welding circuit, which must not come in electric contact between themselves.

When using the welder for air arc gouging connect the ground lead to the - socket and the gouging lead to the socket marked "only gouging" (if present).

MACHINES WITH E.V. PROTECTION

Accelerate the engine at max. with the accelerator lever (16).See page M 39.

MACHINE WITH E.P.2 PROTECTION (B2)

Accelerate the engine at max. with the accelerator lever (16) (when assebled).
 See page M 39

MACHINE WITH E.P.1 PROTECTION (D1)


See page M 39.1

REMOTE CONTROL TC...



See page M 38

WELDING CURRENT REGULATOR



Position welding current adjusting knob (T) in correspondance of the chasen current value, so as to obtain the necessary amperage, taking into acount the diameter and the type of the electrode.

For technical data see page M52



ATTENTION

To reduce the risk of electromagnetic interferences, use the minimum lenght of welding cables and keep them near and down (ex. on the floor).

The welding operations must take place far from any sensitive electronic device.Make sure that the unit is earthed. (see M20 and/or M25). In case the interference should last, adapt further disposition,such as: move the unit, use screened cables, line filters, screen the entire work area. In case the above mentioned operations are non sufficient, please contact our Thechnical Assistance Service.



CAUTION

With a welding cable length up to 20 m is suggested a section of 35 mm²; with longer cables a bigger section is required.



MACHINE WITH REDUCTION SCALE SWITCH

100%
XXX A
max



For small electrodes (up to Ø 3.25-130A and 4-200A) it is recommended to use the reduction scale switch (I3) allowing a more accurate regulation of the welding current (lever position at 130 A and/or 200A).

When using electrodes of a diameter greater than 3.25 and/or 4 set the welding scale knob to 100% and/or max. position.

The arc regulator (T) functions equally between both positions (100%-130A and/or 200A).



Protection fuse (when assembled):the fuse protects the electronic welding PCB in case the remote control is short circuited.

MACHINE WITH O.C.V.

It permits to choose, according to the work to be done and/or the electrode type used, the best O.C.V.



MACHINE WITH POLARITY INVERTER



It permits to have at the electrode holder the positive or negative polarity of the welding diode bridge.

It is used above all in the first run with cellulosic electrodes to lower the bath temperature and so doing ease up the welding on pipes of small thickness

MACHINE WITH BASIC CURRENT "BC"

Positioning the switch on „ON“, is obtained a low voltage welding current which keeps, always, the lit arc necessary for some types of cellulosic electrodes or when a high penetration is wanted.



For electrodes of basic or rutile type, position the switch on "OFF", the welding current will always remain constant.


"CC/CV" MODELS



These models can be used with electrodes or for TIG welding by selecting the CC (constant current) mode, and with solid wire (MIG, MAG) or flux cored wire selecting the CV (constant voltage) mode. The mode of operation is selected by a switch on the front panel.



MACHINE WITH ARC CONTROL OR SELECTOR "ARC FORCE"



Set the welding arc using adjuster knob (6) so as to obtain, for the chosen current value, the best arc characteristic according to the electrode type and to the work to be performed.



On machines with an Arc Force selector, the same result can be obtained by turning the selector "ON" or "OFF". When switched "ON" a base current is applied to the welding current output acting as a sort of "automatic" arc forcing that does not need to be regulated.

For technical data see page M52

At the end of every welding process and/or work, proceed with all the use operations in inverted sense.

To stop the machine see pages M 22-27.

☞ **It is strictly forbidden to connect the group to the public mains a/o to another source of electric power.**

⚠ WARNING

Sockets are not **self-locked**: tension is available immediately after starting also with no plug.

⚠ WARNING

The areas, **access** of which is forbidden to unqualified personel, are:
- the control switchboard (front), the exhaust of the endothermic engine.

☞ At the beginning of every work, check the electric parameters and/or the controls placed on the front.


Make sure the unit is properly grounded (12) (where it is assembled).
- See page M20, 21, 22, 25, 26, 27 -.

Move the accelerator lever (16) and reach the engine maximum speed, except for the engines with constant rpm; the voltmeter (N) (where it is assembled) shows the single-phase voltage whether three or single-phase current has to be drawn.

Nominal voltage	Indicative no-load voltage	
	asynchronous	synchronous (*)
110V	±10%	±5%
230V	±10%	±5%
230V	±10%	±5%
400V	±10%	±5%

*N.B.: with electronic tens. regul. RVT ±1%

Connect up the machine, using proper plugs and cables in good condition to the AC socket (15) to draw single or three-phase power, or, by cables with adequate section, to the terminal board, placed inside the derivation box (Q3).



The warning light (L), located near the current socket, lights up when the unit can supply alternated current, on condition that the engine is at the maximum rpm.

☞ N.B.: if the warning light does not flash, check the accelerator which must be at its maximum, or the fuse of the relevant socket. (single-phase) or the thermoprotection.

Using several sockets at the same time, the maximum power possible is that indicated on the data plate.

To draw power simultaneously in the TS welder version see page M52.


⚠ CAUTION

The replacement of the fuse must absolutely be done with the engine off (remove the mechanical protection, then shift down the small lever of the fuse holder placed on the front panel).

The max. continuous power of the generating set or the load current must not be exceeded.

MACHINE WITH THERMOPROTECTION

If you overload the genset the thermoprotection will automatically switch off. If the thermoprotection is released, disconnect all the connected loads.



Reset the thermoprotection pressing the central pole.

When reset, connect the loads again. In case the protection should act furtherly, check: the connections, the wires or others, and if necessary call the Assistance Service.



Avoid to hold the central pole of the thermoprotection pressed for a long time.

Otherwise, in case of trouble, it will not click, **damaging** the generating set.



TS ... PL VERSION

Start the machine and wait for the end of the preheating time imposed by the EP1, EP2, EP5 engine protection device. - See pages M39... - Press the „generation possibility“ push button (B5) placed on the front side of machine.


The voltmeter will show the auxiliary voltage which, for machines at 1500/1800 RPM, must be approx. $\approx 230V \pm 10\%$ and for machines at 3000/3600 RPM (engine idling) must be approx. $\approx 180V \pm 10\%$.

Push upwards the lever of magnetothermic switch referring to the socket from which load is to be drawn.

MACHINE WITHOUT PROTECTIVE DEVICE

In case machine is not equipped with protective device of indirect contacts, by means of automatic breaking of supply, it **is necessary** to put between the load and the generation a differential switch or a similar equipment capable, in any case, to observe the regulations in force CEI 64/8 (and/or successive) Part 4 Par. 4.13.1 and harmonized by directive Nr. 72/23/EEC.


UNIT FITTED WITH GROUND FAULT INTERRUPTER SWITCH (GFI)



Turn on the GFI safety-switch (D) by pushing it upwards.

The GFI is a safety device which protects the circuit in the event of a malfunction. In this case the switch disconnects the three and single-phase circuit when in any part of the electric connections a current leakage of more than 30 mA occurs.

UNIT FITTED WITH THERMAL MAGNETIC BREAKER




Turn on the thermal magnetic breaker (Z2) by pushing it to the ON position.

The thermal-magnetic breaker is a safety device which protects the circuit in the event of a malfunction. In this case the switch disconnects the three and single-phase circuit when in any part of the electric connections a short circuit or a current absorption occurs above the data specified on the label of the unit.

In the model with setting **DO NOT INTERVENE** on the setting itself. To modify it, please contact our Technical Assistance Service.


UNIT FITTED WITH GFI SWITCH THERMAL MAGNETIC BREAKER



This switch includes the characteristics of both types of breakers (N2).

UNIT WITH VOLTMETRIC COMMUTATOR (ONLY FOR GENERATING SET)

WARNING: the possible single-phase loads must be correctly divided in the three phases, in order to avoid any possible voltage fall on one phase that results excessively loaded.




Check the voltages on the various phases with the switch located on the front (H2) and check, reading on the voltmeter (N) about the same voltage value

N.B.: in case of overload, it is possible that the engine lowers its speed and the voltage is reduced remarkably. In this case, it is necessary to reduce immediately the load.

CAUTION

For machines at 3000/3600 RPM the EP1 safety device will automatically provide to accelerate engine when load is drawn.
- See page M39.1 -







The remote control device for regulating the welding current is connected to the front panel by means of a multipole connector.

To regulate the current from the TC2 / TC2/50, move the switch (7), located above the multipole connector (8), to "ON" position.

Position welding current adjusting (T) knob at the necessary current value for the diameter and type of electrode.


- See page M51 -



The device enables to totalize the welding current of two positions or of two welding machine.

Connect each one of the inputs "+" and "-" of the PAR 600 to each welding position and draw, according to the use, the total current from the "+" and "-" output socket.

Fully insert the welding cable plugs into the corresponding socket (9+/10-) turning them clockwise to lock them in position.

**MAKE SURE**

- 1) the both positions have an identic polarity
 - 2) that O.C.V. have an identic position
- See page M34.2 -

ENGINE PROTECTION (EP1)

The electronic device EP.1 (D1) is a microprocessor with logic-circuit board that ensures the protection of the engine in case of low oil pressure or engine high temperature.

Located on the front of the machine, the EP.1 enters in operation when the engine has been turned on with the ignition key.

The yellow warning light for low oil temperature (D1.1) will immediately light up; **after** 15 seconds the engine will be checked and if everything is operating normally, the "OK engine" light will switch on.



CAUTION

IN THE FIRST FRACTION OF TIME THE DEVICE DOES NOT MAKE ANY PROTECTION.

The automatic device requires an engine warning up time of at least 45 seconds, not permitting to draw power when the engine is still cold.

N.B.: A longer warning up time (4-5 minutes) is advisable for temperatures below +10°C.

When the warning light (D1.1) goes off, whether the unit is used as welder or as a generator, the green light (D1.5) will light up, the engine will go to maximum speed, permitting to draw power.

Should the oil pressure be insufficient, the red light (D1.3) will light up and the EP.1 device will stop the engine.


If the temperature rises to dangerous levels, the red light (D1.4) will light up and the engine will stop thus preventing to draw power.

LIQUID COOLED ENGINE

In case of cooling liquid high temperature, the warning light (D1.4) will light up and the engine will stop thus preventing to draw power.

In this case it is **SUGGESTED** to stop the engine and control the cooling level.

In case of low pressure, check the level and if it is correct, call the service station. In case of high temperature, make sure that there are no leaves and/or pieces of material obstructing the air circuit.



D1.1(G) Low oil temperature/ Cold engine

D1.2(V) Engine test/ OK engine

D1.3(R) Low oil pressure

D1.4(R) High temperature

D1.5(V) Engine at maximum


COLORS
G = yellow
V = green
R = red

ENGINE EQUIPPED WITH A MANUAL ACCELERATOR

NOTE: This unit is equipped with a manual accelerator for use in the unlikely event that the EP.1 or the accelerator solenoid should fail. This manual accelerator can also be used in cases where the auto-idle function is not suitable for the type of welding being carried out.

CAUTION: for machines with EP.1 engine protection: use the accelerator lever **ONLY IN EMERGENCY** when the automatic idle does not work.

Accelerator lever



N.B.: if the unit is used as a generator in hot climates and with loads near to the maximum, the protection can be triggered off, please reduce the load of the engine.

Once the cause of the problem has been removed, to ensure the protection it is sufficient to set the key to zero and restart the engine.



NOTE

THE ENGINE PROTECTIONS OF THE "EP" TYPE DO NOT WORK WHEN THE OIL IS OF LOW QUALITY BECAUSE NOT CHANGED REGULARLY AT INTERVALS AS PRESCRIBED IN THE OWNER'S ENGINE MANUAL.

ENGINE PROTECTION (ES - EV)

The devices ES or EV ensure the protection of the engine in case of low oil pressure or engine high temperature.


The system consist of electronic card of control and check, and of an engine stop device: solenoid (**ElettroStop**), electrovalve (**ElettroValvola**)

The device enter in operation when the engine starts and, in case of low oil pressure and high temperature, will stop the machine and show the cause of the stop with the warning light of high temperature or low oil pressure.

In case of low oil pressure, check the level and if it is correct, call the Service Station. In case of high temperature, make sure that there are no leaves and/or pieces of material obstructing the air ducts.

☞ **N.B.:** if the unit is used as a generator in hot climates and with loads near to the maximum, the protection device can be triggered off, please reduce the load of the engine.

Once the cause of the problem is removed, to reset the protection, it is enough to report the ignition key (Q1) on "OFF" position and start the engine again.

**NOTE**

THE ENGINE PROTECTIONS DO NOT WORK WHEN THE OIL IS OF LOW QUALITY BECAUSE NOT CHANGED REGULARLY AT INTERVALS AS PRESCRIBED IN THE OWNER'S ENGINE MANUAL.

PROBLEM	POSSIBLE CAUSE	WHAT TO DO
No welding current but auxiliary output is OK	1) Defective diode bridge 2) Problem with welding current control (PCB)	1) Check the diodes of the bridge 2) Is the remote control switch in the internal position? 3) Check the diodes and SCR's of the bridge. 4) Check the transformer which supplies power to the welding control PCB. If it is OK replace the PCB
Weld poorly	1) Defective diode bridge 2) Problem with welding current control (PCB)	1) Check the open circuit welding voltage. If it is OK the diode bridge is OK. If it is 1/3 or 2/3 of the nominal value check the diodes or the SCR's. 2) If the diode bridge is OK replace the PCB.
Intermittently welds poorly	1) Bad connections to welding current PCB 2) Problem with welding current control PCB	1) Check that the pins of the green connectors are clean and making good contact. Check that shunt connections are tight. 2) Replace the welding current control PCB
No welding output and no auxiliary power output	1) Short circuit in wiring 2) Defective condenser 3) Defective stator 4) Short circuited diode bridge	1) Check the wiring inside the welder for a short circuit between cables or to ground. 2) If the wiring is OK, short circuit the condenser to be sure that it is discharged, disconnect all wires from condenser and, using an ohmmeter, check that the condenser is not short circuited. 3) If the condenser box is OK, disconnect all leads from the stator except for those going to the condenser box and check the output from the alternator. If there is no output from the welding winding and the auxiliary winding, replace the stator. 4) If there is output from all windings reconnect the diode bridge and check if there is welding current. If not the diode bridge is defective. If there is welding current connect the auxiliary power leads one at a time until there is no output; at this point, the short circuit is in that line.

[.] only for models with electronic control of welding current.

⚠ WARNING



MOVING PARTS can injure

- Have **qualified** personnel do maintenance and troubleshooting work.
 - Stop the engine before doing any work inside the machine. If for any reason the machine must be operated while working inside, **pay attention** moving parts, hot parts (exhaust manifold and muffler, etc.) electrical parts which may be unprotected when the machine is open.
 - Remove guards only when necessary to perform maintenance, and replace them when the maintenance requiring their removal is complete.
 - Use suitable tools and clothes.
 - Do not modify the components if not authorized.
- See pag. M1.1 -



HOT surface can hurt you

NOTE

By maintenance at care of the utilizer we intend all the operatios concerning the verification of mechanical parts, electrical parts and of the fluids subject to use or consumption during the normal operation of the machine.

For what concerns the fluids we must consider as maintenance even the periodical change and or the refills eventually necessary.

Maintenance operations also include machine cleaning operations when carried out on a periodic basis outside of the normal work cycle.

The repairs **cannot be considered** among the maintenance activities, i.e. the replacement of parts subject to occasional damages and the replacement of electric and mechanic components consumed in normal use, by the Assistance Authorized Center as well as by MOSA.

The replacement of tires (for machines equipped with trolleys) must be considered as repair since it is not delivered as standard equipment any lifting system.

The periodic maintenance should be performed according to the schedule shown in the engine manual. An optional hour counter (M) is available to simplify the determination of the working hours.

ENGINE and ALTERNATOR

PLEASE REFER TO THE SPECIFIC MANUALS PROVIDED.

VENTILATION

Make certain there are no obstructions (rags, leaves or other) in the air inlet and outlet openings on the machine, alternator and motor.

ELECTRICAL PANELS

Check condition of cables and connections daily. Clean periodically using a vacuum cleaner, **DO NOT USE COMPRESSED AIR.**

DECALS AND LABELS

All warning and decals should be checked once a year and **replaced** if missing or unreadable.

STRENUOUS OPERATING CONDITIONS

Under extreme operating conditions (frequent stops and starts, dusty environment, cold weather, extended periods of no load operation, fuel with over 0.5% sulphur content) do maintenance more frequently.

BATTERY WITHOUT MAINTENANCE DO NOT OPEN THE BATTERY

The battery is charged automatically from the battery charger circuit supplied with the engine.

Check the state of the battery from the colour of the warning light which is in the upper part.

- Green colour: battery OK
- Black colour: battery to be recharged
- White colour: battery to be replaced

⚠ IMPORTANT



In the maintenance operations avoid that polluting substances, liquids, exhausted oils, etc. bring damage to people or things or can cause negative effects to surroundings, health or safety respecting completely the laws and/or dispositions in force in the place.

⚠ NOTE

THE ENGINE PROTECTION NOT WORK WHEN THE OIL IS OF LOW QUALITY BECAUSE NOT CHARGED REGULARLY AT INTERVALS AS PRESCRIBED IN THE OWNER'S ENGINE MANUAL.



In case the machine should not be used for more than 30 days, make sure that the room in which it is stored presents a suitable shelter from heat sources, weather changes or anything which can cause rust, corrosion or damages to the machine.

☞ Have **qualified** personnel prepare the machine for storage.

GASOLINE ENGINE

Start the engine: It will run until it stops due to the lack of fuel.

Drain the oil from the engine sump and fill it with new oil (see page M25).

Pour about 10 cc of oil into the spark plug hole and screw the spark plug, after having rotated the crankshaft several times.

Rotate the crankshaft slowly until you feel a certain compression, then leave it.

In case the battery, for the electric start, is assembled, disconnect it.

Clean the covers and all the other parts of the machine carefully.

Protect the machine with a plastic hood and store it in a dry place.

DIESEL ENGINE

For short periods of time it is advisable, about every 10 days, to make the machine work with load for 15-30 minutes, for a correct distribution of the lubricant, to recharge the battery and to prevent any possible bloking of the injection system.

For long periods of inactivity, turn to the after sales service of the engine manufacturer.

Clean the covers and all the other parts of the machine carefully.

Protect the machine with a plastic hood and store it in a dry place.

In case of necessity for first aid and of fire prevention, see page. M2.5.



IMPORTANT



In the storage operations avoid that polluting substances, liquids, exhausted oils, etc. bring damage to people or things or can cause negative effects to surroundings, health or safety respecting completely the laws and/or dispositions in force in the place.

☞ Have **qualified** personnel disassemble the machine and dispose of the parts, including the oil, fuel, etc., in a correct manner when it is to be taken out of service.

As cust off we intend all operations to be made, at utilizer's care, at the end of the use of the machine. This comprises the dismantling of the machine, the subdivision of the several components for a further reutilization or for getting rid of them, the eventual packing and transportation of the eliminated parts up to their delivery to the store, or to the bureau entrusted to the cust off or to the storage office, etc.

The several operations concerning the cust off, involve the manipulation of fluids potentially dangerous such as: lubricating oil and battery electrolyte.

The dismantling of metallic parts liable to cause injuries or wounds, must be made wearing heavy gloves and using suitable tools.

The getting rid of the various components of the machine must be made accordingly to rules in force of law a/o local rules.

Particular attention must be paid when getting rid of:

lubricating oils, battery electrolyte, and inflammable liquids such as fuel, cooling liquid.

The machine user is responsible for the observance of the norms concerning the environment conditions with regard to the elimination of the machine being cust off and of all its components.

In case the machine should be cust off without any previous disassembly it is however compulsory to remove:

- tank fuel
- engine lubricating oil
- cooling liquid from the engine
- battery

NOTE: MOSA is involved with custing off the machine **only** for the second hand ones, when not reparable.

This, of course, after authorization.

In case of necessity for first aid and fire prevention, see page M2.5.



IMPORTANT



In the cust-off operations avoid that polluting substances, liquids, exhausted oils, etc. bring damage to people or things or can cause negative effects to surroundings, health or safety respecting completely the laws and/or dispositions in force in the place.

The TS 200 BS/CF engine driven welder is a unit which ensures the function as:

- a) a current source for arc welding
- b) a current source for the auxiliary power generation

It is meant for industrial and professional use, powered by an endothermic engine; it is composed of various main parts such as: engine, alternator, electric and electronic controls, the fairing or a protective structure.

The assembling is made on a steel structure, on which are provided elastic support which must damp the vibrations and also eliminate sounds which would produce noise.

Technical data	TS 300 SC	TS 300 SXC
ALTERNATOR	self-excited, self-regulated, brushless	
Type	Three-phase, asynchronous	
Insulating class	H	
A. C. GENERATORA.		
Three-phase generation	10 kVA / 400 V / 14.4 A	
Single-phase generation	5 kVA / 230 V / 21.7 A	
Single-phase generation	2.5 kVA / 110 V / 22.7 A	
Single-phase generation	5 kVA / 48 V / 104 A	
Frequency	50 Hz	
Service	100 %	
ENGINE		
Mark	RUGGERINI	
Model	RD 210	
Type	4-Stroke	
Displacement	954 cm ³	
Cylinders	2	
Output	14 kW (19 HP)	
Speed	3000 rpm	
Fuel consumption	250 g/kWh	
Cooling system	Air	
Engine oil capacity	3 l	
Starter	Electric	
Fuel	Gasoline	
GENERAL SPECIFICATIONS		
Battery	12V - 45Ah	
Tank capacity	23 l	
Running time (60%)	9 h	
Protection	IP 23	
Dimensions / max. (LxIxh in mm)	1320x790x750	
Dimensions with CTM	1630x920x930	
Dimensions with CTL	2050x980x990	
Weight	350 Kg	370 Kg
Weight with CTM	370 Kg	390 Kg
Weight with CTL	410 Kg	440 Kg
Noise Level	99 LWA (74 dB(A) - 7m)	93 LWA (68 dB(A) - 7m)

OUTPUT

Declared powers at the following ambient conditions: temperature 20°C, relative humidity 30% altitude 100 m above sea level. In an **approximative** way one reduces: of 1% every 100 m altitude and of 2.5% for every 5°C above 25°C.

For possible modifications or changes to be brought on the engines, with climate conditions different from those above mentioned, please call our Assistance Authorized Centers.

ACOUSTIC POWER LEVEL

The machine respects the noise limits, expressed in sound power, given in the a.m. directives.

These limits can be used to judge the sound level produced on site.

For example: the sound power level of 100 LWA.

The sound pressure (noise produced) at 7 meters distance is about 75dBA (the limit value less 25).

To calculate the sound level at other distances use this formula:

$$dB_{Ax} = dB_{Ay} + 10 \log \frac{r_y^2}{r_x^2} \quad \text{At 4 meters the noise level becomes: } \frac{7^2}{4^2} \cdot 75 \text{ dBA} + 10 \log \frac{7^2}{4^2} = 80 \text{ dBA}$$

Technical data


TS 300 SC

TS 300 SXC

D.C. WELDING C.C.

Welding current regulation (I Scale)	20 - 300 A
Service	300 A - 60%, 250 A - 100%
Regulation of welding *	0 - 9
Open circuit voltage	70 V
Welding voltage	20 - 32 V
Ø electrode	2 - 6 mm

OUTPUT CHARACTERISTIC





Welding current regulator position approx. current values	%	0	25	50	75	100
	A	20	80	150	240	300


SIMULTANEOUS UTILIZATION FACTORS

In case **Welding** and **Generation** can be used simultaneously, however, the engine **cannot** be overloaded. The table below gives the maximum limits to be respected:

WELDING CURRENT	>170 A	130 A	80 A	0 A
AUXILIARY POWER	0	2.5 kVA	5 kVA	10 kVA




A: Alternator	A3: Insulation monitoring	A6: Commutator/switch
B: Wire connection unit	B3: E.A.S. connector	B6: Key switch, on/off
C: Capacitor	C3: E.A.S. PCB	C6: QEA control unit
D: G.F.I.	D3: Booster socket	D6: Connector, PAC
E: Welding PCB transformer	E3: Open circuit voltage switch	E6: Frequency rpm regulator
F: Fuse	F3: Stop push-button	F6: Arc-Force selector
G: 400V 3-phase socket	G3: Ignition coil	G6: Device starting motor
H: 230V 1phase socket	H3: Spark plug	H6: Fuel electro pump 12V c.c.
I: 110V 1-phase socket	I3: Range switch	I6: Start Local/Remote selector
L: Socket warning light	L3: Oil shut-down button	L6: Choke button
M: Hour-counter	M3: Battery charge diode	M6: Switch CC/CV
N: Voltmeter	N3: Relay	N6: Connector – wire feeder
P: Welding arc regulator	O3: Resistor	O6: 420V/110V 3-phase transformer
Q: 230V 3-phase socket	P3: Sparkler reactor	P6: Switch IDLE/RUN
R: Welding control PCB	Q3: Output power unit	Q6: Hz/V/A analogic instrument
S: Welding current ammeter	R3: Electric siren	R6: EMC filter
T: Welding current regulator	S3: E.P.4 engine protection	S6: Wire feeder supply switch
U: Current transformer	T3: Engine control PCB	T6: Wire feeder socket
V: Welding voltage voltmeter	U3: R.P.M. electronic regulator	U6: DSP chopper PCB
Z: Welding sockets	V3: PTO HI control PCB	V6: Power chopper supply PCB
X: Shunt	Z3: PTO HI 20 l/min push-button	Z6: Switch and leds PCB
W: D.C. inductor	W3: PTO HI 30 l/min push-button	W6: Hall sensor
Y: Welding diode bridge	X3: PTO HI reset push-button	X6: Water heater indicator
	Y3: PTO HI 20 l/min indicator	Y6: Battery charge indicator
A1: Arc striking resistor	A4: PTO HI 30 l/min indicator	A7: Transfer pump selector AUT-0-MAN
B1: Arc striking circuit	B4: PTO HI reset indicator	B7: Fuel transfer pump
C1: 110V D.C./48V D.C. diode bridge	C4: PTO HI 20 l/min solenoid valve	C7: „GECO“ generating set test
D1: E.P.1 engine protection	D4: PTO HI 30 l/min solenoid valve	D7: Flooting with level switches
E1: Engine stop solenoid	E4: Hydraulic oil pressure switch	E7: Voltmeter regulator
F1: Acceleration solenoid	F4: Hydraulic oil level gauge	F7: WELD/AUX switch
G1: Fuel level transmitter	G4: Preheating glow plugs	G7: Reactor, 3-phase
H1: Oil or water thermostat	H4: Preheating gearbox	H7: Switch disconnecter
I1: 48V D.C. socket	I4: Preheating indicator	I7: Solenoid stop timer
L1: Oil pressure switch	L4: R.C. filter	L7: "VODIA" connector
M1: Fuel warning light	M4: Heater with thermostat	M7: "F" EDC4 connector
N1: Battery charge warning light	N4: Choke solenoid	N7: OFF-ON-DIAGN. selector
O1: Oil pressure warning light	O4: Step relay	O7: DIAGNOSTIC push-button
P1: Fuse	P4: Circuit breaker	P7: DIAGNOSTIC indicator
Q1: Starter key	Q4: Battery charge sockets	Q7: Welding selector mode
R1: Starter motor	R4: Sensor, cooling liquid temperature	R7: R.C. net
S1: Battery	S4: Sensor, air filter clogging	S7: 230V 1-phase plug
T1: Battery charge alternator	T4: Warning light, air filter clogging	T7: V/Hz analogic instrument
U1: Battery charge voltage regulator	U4: Polarity inverter remote control	U7:
V1: Solenoid valve control PCBT	V4: Polarity inverter switch	V7:
Z1: Solenoid valve	Z4: Transformer 230/48V	Z7:
W1: Remote control switch	W4: Diode bridge, polarity change	W7:
X1: Remote control and/or wire feeder socket	X4: Base current diode bridge	X7:
Y1: Remote control plug	Y4: PCB control unit, polarity inverter	Y7:
A2: Remote control welding regulator	A5: Base current switch	A8:
B2: E.P.2 engine protection	B5: Auxiliary push-button ON/OFF	B8:
C2: Fuel level gauge	C5: Accelerator electronic control	C8:
D2: Ammeter	D5: Actuator	D8:
E2: Frequency meter	E5: Pick-up	E8:
F2: Battery charge transformer	F5: Warning light, high temperature	F8:
G2: Battery charge PCB	G5: Commutator auxiliary power	G8: Polarity inverter two way switch
H2: Voltage selector switch	H5: 24V diode bridge	H8:
I2: 48V a.c. socket	I5: Y/s commutator	I8:
L2: Thermal relay	L5: Emergency stop button	L8:
M2: Contactor	M5: Engine protection EP5	M8:
N2: G.F.I. and circuit breaker	N5: Pre-heat push-button	N8:
O2: 42V EEC socket	O5: Accelerator solenoid PCB	O8:
P2: G.F.I. resistor	P5: Oil pressure switch	P8:
Q2: T.E.P. engine protection	Q5: Water temperature switch	Q8:
R2: Solenoid control PCBT	R5: Water heater	R8:
S2: Oil level transmitter	S5: Engine connector 24 poles	S8:
T2: Engine stop push-button T.C.1	T5: Electronic GFI relais	T8:
U2: Engine start push-button T.C.1	U5: Release coil, circuit breaker	U8:
V2: 24V c.a. socket	V5: Oil pressure indicator	V8:
Z2: Thermal magnetic circuit breaker	Z5: Water temperature indicator	Z8:
W2: S.C.R. protection unit	W5: Battery voltmeter	W8:
X2: Remote control socket	X5: Contactor, polarity change	X8:
Y2: Remote control plug	Y5: Commutator/switch, series/parallel	Y8:



Esp. Exp.	Modifica Modification	Data Date	Appr. Appr.
	Denominazione: Engine Ruggerini RD 210 (EV)	Project: 21982.prg	Dis. Dess. di n° 2
	Da Pagi. From Page 1	Project: 21982.prg	Page n° of n° 5
	Alta Pagi. To Page 1	Dis. n° 21982.S.010	Approvato: Approved:
	Machine: TS 300 SC	Data: 09/05/2000	Dis. n° 21982.S.010
	Machine: TS 300 SC	Designator: Leporace N.	Designer:


La MOSA si riserva a termini di legge la proprietà del presente disegno con divieto di riprodurlo o comunicarlo a terzi senza sua autorizzazione



STARTER KEY	
30	50
OFF	ON
ST	START


Ess. Exp.	Modifica Modification	Data Date	Dis. Dis.	Appr. Appr.
Denominazione: Engine Ruggerini RD 210 (EP1)		Progetto Project:	Page n° of n°	di n° of n°
MOSCA		21986.prg	2	5
20090-CUSAGO (MI)-ITALY http://www.mosa.it		Dis. n° Drive n°	Approvato: Approved:	
Machine: TS 300 SC		12/05/2000	21986.S.010	
Designator: Leporace N.		Designer:		

La MOSA si riserva a termini di legge la proprietà del presente disegno con divieto di riprodurlo o comunicarlo a terzi senza sua autorizzazione




Esp. Exp.	Modifica Modification	Data Date	Appr. Appr.
	Denominazione Denomination:	Project:	Page n° of n°
	Aux. (400T/230M/48M) D	21982.prg	3 5
	Machine: TS 300 SC	Dis. n° Drive n°:	Approvato: Approved:
	20090-CUSAGO (MI)-ITALY http://www.mosa.it	09/05/2000	21982.S.020
	Designatore Designer:	Leoprace N.	

La MOSA si riserva a termini di legge la proprietà del presente disegno con divieto di riprodurlo o comunicarlo a terzi senza sua autorizzazione




Esq. Exp.	Modifica Modification	Data Date	Dis. Dess.	Appr. Appr.
		21/05/2000	21986.prg	
	Denominazione: AUC. (400T/230M/110CTEX2) D	Progetto: 21986.S.020	Page n° 3	Page n° 5
	Alta Pag. To Page	Dis. n°: 21986.S.020	Project: 21986.prg	Approved: [Signature]
	Machine: TS 300 SC	Date: 12/05/2000	Project: 21986.S.020	Approved: [Signature]
	Machine: TS 300 SC	Designer: Leporace N.	Project: 21986.S.020	Approved: [Signature]

La MOSA si riserva a termini di legge la proprietà del presente disegno con divieto di riprodurlo o comunicarlo a terzi senza sua autorizzazione





Ess. Exp.	Modifica Modification	Date Date	Appr. Appr.
Da Page From Page	Denominazione Denomination:	Projecto Project:	Dis. n.° of n.°
Alia Page To Page	AUX. (400T/230Mx3) D	21998.prg	3 5
	Macchina Machine:	Dis. n.° Drwg. n.°	Approvato: Approved:
	TS 300 SC	12/05/2000 21998.S.020	(Logo)
MOSA 20090-CUSAGO (MI)-ITALY http://www.mosa.it		Disegnato: Designer: Leporace N.	

La MOSA si riserva a termini di legge la proprietà del presente disegno con divieto di riprodurlo o comunicarlo a terzi senza sua autorizzazione



Esp. Exp.	Modifica	Data	Dis. Des.	Appr. Appr.
	Denominazione:	Projecto:	Projecto:	Projecto:
	From Page	21982.prg	21982.prg	21982.prg
	Ala Pag. To Page	4	4	5
	Machine:	Dis. n.°	Dis. n.°	Dis. n.°
	TS 300 SC	21982.S.030	21982.S.030	21982.S.030
	Designer:	Date:	Date:	Date:
	Leporace N.	09/05/2000	09/05/2000	09/05/2000
	Designer:	Appr. Appr.	Appr. Appr.	Appr. Appr.

La MOSA si riserva a termini di legge la proprietà del presente disegno con divieto di riprodurlo o comunicarlo a terzi senza sua autorizzazione



Esp. Exp.	Modifica Modification	Data Date	Dis. Dess.	Appr. Appr.
	Denominazione: Welding Control	Project: 21982.prg	Page n° 5	di n° 5
	Machine: TS 300 SC	Dis. n°: 21982.S.040	Page n° 5	di n° 5
	Designator: Leppace N.	Date: 09/05/2000	Dis. n°: 21982.S.040	Appr. n°: 61.7
	Machine: TS 300 SC	Designer: Leppace N.	Dis. n°: 21982.S.040	Appr. n°: 61.7

La MOSA si riserva a termini di legge la proprietà del presente disegno con divieto di riprodurlo o comunicarlo a terzi senza sua autorizzazione




MOSA guarantees that any request for spare parts will be satisfied.

To keep the machine in full working order, when replacement of MOSA spare parts is required, always ask for genuine parts only.

The requested data are to be found on the data plate located on the machine structure, quite visible and easy to consult. *


When ordering the spare parts, it is recommended to indicate:

- 1) * serial number
- 2) * model of welder and/or generating set
- 3) ◆ n. table
- 4) ◆ n. position
- 5) quantity




ABBREVIATIONS AND SYMBOLS:

- (EV) When ordering, specify the engine type and the auxiliary voltage
- (ER) Engine with recoil starter only
- (ES) Engine with electric starter only
- (VE) E.A.S version only.
- (QM) When ordering, specify the length in meters
- (VS) Special version only
- (SR) By request only




<i>Pos.</i>	<i>Rev. Cod.</i>	<i>Descr</i>	<i>Note</i>
1	219937020	PANNELLO FRONTALE / <i>FRONT PANEL</i>	
2	105511810	CONTAORE 230V 50Hz IP65 / <i>HOURMETER 230V 50Hz IP65</i>	
3	103011310	VOLTMETRO FONDO SCALA 300V / <i>VOLTMETER 300V</i>	
4	A 773317034	PIASTRINA FISS.COPERCH.SPIE / <i>FIXING PLATE WARNING LAMP COVER</i>	Era 209717027
4a	773317032	COPERCHIETTO PORTA SPIE / <i>WARNING LIGHT HOLDER</i>	
5	219937130	COPERCHIO INTERRUT.DIFFERENZ. / <i>COVER GFI</i>	
6	219937235	COPERCHIO / <i>COVER</i>	
7	219937105	INTERRUTTORE DIFFERENZIALE / <i>GROUNDFAULT INTERRUPTOR (GFI)</i>	(4 poli) (105111540 in dist.)
8	219937036	STAFFA / <i>BRACKET</i>	
9	107519046	COPERCHIO PER PORTAFUSIBILE / <i>BLIND PLATE, FUSE HOLDER</i>	
10	219937234	STAFFA / <i>BRACKET</i>	
11	1291260	FUSIBILE / <i>FUSE</i>	
11a	1291230	FUSIBILE / <i>FUSE</i>	
12	219937228	STAFFA / <i>BRACKET</i>	
13	107509045	PORTAFUSIBILE / <i>HOLDER, FUSE</i>	
14	'0000107509715	GRUPPO POTENZIOMETRO / <i>POTENTIOMETER</i>	
15	'0000207409750	GR.REGOLATORE ARCO SALDATURA / <i>ARC FORCE REGULATOR</i>	
16	102042740	CAPPUCCIO / <i>CAP</i>	
16a	102013290	COMMUTATORE / <i>COMMUTATOR</i>	Era 107509060
17	21970C051	GR.CAVI X COM.A DIST.TC2/TC3 / <i>CABLES FOR REMOTE CONTROL</i>	Era 209509910
18	1302220	SPIA 230V / <i>WARNING LIGHT 230V</i>	
18a	1302160	SPIA 110V / <i>WARNING LIGHT 110V</i>	
19	102044400	PRESA DI SALDATURA (-) / <i>WELDING SOCKET (-)</i>	
20	102301310	PRESA DI SALDATURA (+) / <i>WELDING SOCKET (-)</i>	
21	307047250	PRESA CEE 110V 16A 2 POLI + T / <i>EEC SOCKET 110V 16A 2 POLES +N</i>	
21a	307017240	PRESA 220V 16A / <i>EEC SOCKET 16A, 220V 2P+T</i>	
21b	101131220	PRESA DINSE / <i>SOCKET</i>	
22	105111510	PRESA CEE 380V TRIFASE / <i>EEC SOCKET THREE-PHASE 380V</i>	
23	209719105	COMANDO ACCELERATORE / <i>ACCELERATOR LEVER</i>	
24	105111520	PRESA CEE 220V MONOF. 2POLI+T / <i>EEC SOCKET SINGLE-PH.220V 2P+</i>	
25	209719110	COMANDO ARRESTO MOTORE / <i>ENGINE STOP</i>	
26	107302460	STARTER A CHIAVE / <i>STARTER KEY</i>	
27	1302040	SPIA ROSSA 12V / <i>RED WARNING LIGHT 12V</i>	
28	209500015	UNITA' CONTROLLO MOTORE EP1 / <i>PCB, ENGINE CONTROL EP1</i>	
29	209719850	SCHEDA EV/ES / <i>PCB EV/ES</i>	
30	282009807	DISTANZ. ISOLANTE PER SCHEDE / <i>SPACER</i>	
31	107509870	TRASFORMATORE / <i>AUXILIARY TRANSFORMER</i>	
32	219939801	PIASTRA / <i>PLATE</i>	
33	217609654	SCATOLA PROT.SCHEDA SALD. / <i>BOX PROTECTION PCB WELDER</i>	
34	218019874	STAFFA BLOCC.TRASFORM.AUSIL. / <i>BRACKET</i>	
35	107509890	SHUNT DI MISURA / <i>SHUNT</i>	
36	700409860	UNITA' FILTRO ANTIDISTURBI / <i>ANTIJAMMING FILTER</i>	
37	219937032	COPERCHIO PRESE 48V / <i>COVER SOCKETS 48V</i>	




63	400Y 230I 48I ca 400Y 230IX3	TS 250
63B	400Y 230I 48I ca 400Y 230IX3	TS 300 TS 300 SXH
63C	200Y 230IX3	TS 300
63E	400Y 230I 110I x2 cie 110K4	TS 300 TS 300 SXH
**	RUGGERINI RD 180 RUGGERINI RD 210 RUGGERINI RD 211 HATZ 2 G 40	


<i>Pos.</i>	<i>Rev.</i>	<i>Cod.</i>	<i>Descr</i>	<i>Note</i>
57		209716010	CONVOGLIATORE	
58		107301420	VENTOLA	
59		309501035	SUPPORTO ELASTICO	
60		309503045	FLANGIA PORTA ALTERNATORE	
61		6050050	ANELLO SEEGER	
62		1001060	CUSCINETTO	
63		209703020	STATORE	TS 250 400/230/48
63 b		219823025	STATORE	TS 300 400/230/48
63 e		219863025	STATORE	TS 300 400/230/110
64		309503030	ALBERO CON ROTORE	
65		309503036	TIRANTE	
66		309503040	FLANGIA	
67 a		209502200	MOTORE RUGGERINI RD210 (M8975)	
68		209812035	TRAVERSA SUPPORTO MOTORE	
69		105112020	ANTIVIBRANTE	
70		307012037	PROTEZIONE ANTIVIBRANTE	
71		209712232	SQUADRETTA	no EP1 version
72		209712206	TUBO COMBUSTIBILE	
73		209702228	PREFILTRO GASOLIO	
74		309409060	ELETTROVALVOLA	no EP1 version
75		209712205	TUBO COMBUSTIBILE	
76		102011190	FILTRO NAFTA	
77		209702242	RACCORDO	
78		209702207	TUBO COMBUSTIBILE	
79		309409061	VALVOLA NON RITORNO	no EP1 version
80		309402225	VITE FORATA	no EP1 version
81		102043150	SUPPORTO FILTRO	
82		219932070	TUBO DI SCARICO	
83		309502077	TUBO FLESSIBILE FINITO	(QM) Era 209712077
84		209702241	SUPPORTO FILTRO	
85		209702203	TUBO COMBUSTIBILE	
86	A	6087740	FASCETTA STR.TUBO 38-50 ACC.ZN	era 6087720
87		209812230	LEVA	(SR) EP1 version
89	A	'0000219869050	SOLENOIDE ECONOMIZZATORE	era 274009055 (EP1 Version)
90	A	'0000219869055	SOLENOIDE ARRESTO MOTORE	(EP1 Version)
95		209503038	ANELLO PER VENTOLA	
96		1229810	TUBO FLESSIBILE (MT.1)	(QM)
<i>Pos.</i>	<i>Rev.</i>	<i>Cod.</i>	<i>Descr</i>	<i>Note</i>
57		209716010	FAN COVER	
58		107301420	FAN	
59		309501035	SUPPORT, FLEXIBLE	
60		309503045	ALTERNATOR FLANGE	
61		6050050	RING, SEEGER	
62		1001060	BEARING	
63		209703020	STATOR	TS 250 400/230/48
63 b		219823025	STATOR	TS 300 400/230/48
63 e		219863025	STATOR	TS 300 400/230/110
64		309503030	SHAFT WITH ROTOR	
65		309503036	TIE-ROD	
66		309503040	FLANGE	
67 a		209502200	RUGGERINI ENGINE RD210 (M8975)	
68		209812035	ENGINE SUPPORT CROSSBAR	
69		105112020	VIBRATION DAMPER	
70		307012037	PROTECTION, VIBRATION-DAMPER	
71		209712232	BRACKET	no EP1 version
72		209712206	PIPE, FUEL	
73		209702228	PRE-FILTER DIESEL	
74		309409060	SOLENOID VALVE	no EP1 version
75		209712205	PIPE, FUEL	
76		102011190	FILTER, FUEL	
77		209702242	PIPE FITTING FOR TANK	
78		209702207	PIPE, FUEL	
79		309409061	NON RETURN VALVE	no EP1 version
80		309402225	SCREW, DRILLED	no EP1 version
81		102043150	SUPPORT, FUEL FILTER	
82		219932070	EXHAUST PIPE	
83		309502077	FLEXING PIPE	(QM) Era 209712077
84		209702241	SUPPORT, FILTER	
85		209702203	PIPE, FUEL	
86	A	6087740	CLAMP	era 6087720
87		209812230	LEVER	(SR) EP1 version
89	A	'0000219869050	SOLENOID ECON./ACCEL.	era 274009055 (EP1 Version)
90	A	'0000219869055	SOLENOID_STOP	(EP1 Version)
95		209503038	RING FOR FAN	
96		1229810	FLEXIBLE PIPE (MT.1)	(QM)




<i>Pos.</i>	<i>Rev. Cod.</i>	<i>Descr</i>	<i>Note</i>
106	309509065	RESISTENZA DI PRITT	TS 300 SC-SXH
107	a 219865100	PONTE DIODI	
109	217605091	STAFFA PONTE DIODI	
112	209719882	STAFFA BOX CONDENSATORI	
113	209719880	BOX CONDENSATORI 55MF	
114	107509041	SBARRETTA BOX CONDENSATORI	
115	309509035	UNITA' DIODI PRITT	TS 300 SC-SXH
116	209714110	SUPPORTO REATTANZA	
117	305719875	GALLEGGIANTE	
118	209504100	REATTANZA	
119	309859043	PORTAFUSIBILE	Era 309850525
120	1291120	FUSIBILE	
121	359259150	BATTERIA 45 Ah	Era 102041790
122	209509152	TRAVERSA FISSAGGIO BATTERIA	
123	105611270	TIRANTE PER BATTERIA	
124	102042380	VASCHETTA BATTERIA	
<i>Pos.</i>	<i>Rev. Cod.</i>	<i>Descr</i>	
106	309509065	RESISTOR PRITT	TS 300 SC-SXH
107	a 219865100	DIODE BRIDGE	
109	217605091	DIODE BRIDGE BRACKET	
112	209719882	CAPACITOR BOX BRACKET	
113	209719880	CAPACITOR BOX 55MF	
114	107509041	CONNECTING PLATE-CAPACITOR BOX	
115	309509035	DIODES UNIT, PRITT	TS 300 SC-SXH
116	209714110	SUPPORT, REACTOR	
117	305719875	FLOAT	
118	209504100	REACTOR	
119	309859043	FUSEHOLDER	Era 309850525
120	1291120	FUSE	
121	359259150	BATTERY 45 Ah	Era 102041790
122	209509152	BRACKET, BATTERY FIXING	
123	105611270	TIE ROD, BATTERY	
124	102042380	HOLDER, BATTERY	




<i>Pos.</i>	<i>Rev. Cod.</i>	<i>Descr.</i>	<i>Note</i>
139	319930501	BASAMENTO (VERS.SX/C)	
140	309702050	SILENZIATORE DI SCARICO	
141	219931050	BASAMENTO (VERS.S/C)	
142	219930514	CASSONETTO ASPIRAZIONE	
143	319930515	CASSONETTO SCARICO	
144	309708200	CASSONETTO ASPIRAZ.ALTERNATORE	
147	342202026	TAPPO SERBATOIO	
147 A	317802026	TAPPO SERBATOIO CON CHIAVE	(SR)
148	107301890	TUBO SFIATO (L=MT.1)	
149	107502208	TUBETTO RITORNO GASOLIO	
150	209702203	TUBO COMBUSTIBILE	
151	107300180	CHIUSURA COMPL.A LEVA	
159	308101262	TAPPO SCARICO SERBATOIO	
160	308102023	GUARNIZIONE	
<i>Pos.</i>	<i>Rev. Cod.</i>	<i>Descr.</i>	<i>Note</i>
139	319930501	CRANKASE (VERS.SX/C)	
140	309702050	MUFFLER, EXHAUST	
141	219931050	CRANKCASE (VERS.S/C)	
142	219930514	INDUCTION CASE	
143	319930515	BOX, EXHAUST	
144	309708200	ALTERNATOR INTAKE BOX	
147	342202026	CAP, FUEL TANK	
147 A	317802026	CAP,TANK	(SR)
148	107301890	PIPE, BREATHER (L=MT.1)	
149	107502208	PIPE	
150	209702203	PIPE, FUEL	
151	107300180	LATCH	
159	308101262	FUEL TANK CAP	
160	308102023	GASKET	




<i>Pos.</i>	<i>Rev. Cod.</i>	<i>Descr.</i>	<i>Note</i>
171	209718024	PERNO DI CERNIERA	
172	209718121	COPERTURA APPARECC. ELETTRICA	
173	102302280	GUARNIZIONE (L=MT.1)	
174	219930512	PARATIA ASPIRAZIONE	
175	105112270	GUARNIZIONE (L=MT.1)	
176	209808065	GRIGLIA USCITA ARIA	
177	102042870	MOLLA	
178	209718073	TIRANTE	
179	209718070	COPERCHIETTO	
180	219930513	COPERTURA ALTERNATORE	
181	209711100	ROLL BAR	
182	209508115	PISTONE SOSTEGNO	
183	A 343339601	MANIGLIA	Era 207509601
185	107300180	CHIUSURA COMPL.A LEVA	
186	A 219828230	GRIGLIA ASPIRAZIONE ARIA	
187	A 219828200	PARATIA ASPIRAZ. MOTORE	
188	209748100	COPERCHIO FRONTALE	
189	219938280	GRUPPO CARENATURA	(EV)
<i>Pos.</i>	<i>Rev. Cod.</i>	<i>Descr.</i>	<i>Note</i>
171	209718024	HINGE PIN	
172	209718121	COVER, ELECTRICAL BOX	
173	102302280	GASKET (L=MT.1)	
174	219930512	INLET WALL	
175	105112270	STRIP, SEALING (L=MT.1)	
176	209808065	SCREEN, AIR OUTLET	
177	102042870	SPRING	
178	209718073	TIE-ROD	
179	209718070	COVER	
180	219930513	COVER,ALTERNATOR	
181	209711100	ROLL BAR	
182	209508115	SUPPORT, AIR INLET WALL	
183	A 343339601	KNOB	Era 207509601
185	107300180	LATCH	
186	A 219828230	ENGINE INTAKE GRATE	
187	A 219828200	ENGINE INTAKE COVER	
188	209748100	FRONT COVER	
189	219938280	COVER UNIT	(EV)



<i>Pos.</i>	<i>Rev.</i>	<i>Cod.</i>	<i>Descr.</i>	<i>Descr.</i>	<i>Note</i>
1		219930131	GR.TIMONE,PIEDE X TRAINO LENTO	KIT SITE TOW	
3		102012560	PARAPOLVERE	COVER,DUST	
4		219930132	GR. ASSALE, RUOTE TRAINO LENTO	KIT SITE TOW	
5		209711160	ASSALE	AXLE	
6		209711170	RUOTA	WHEEL	



Pos.	Rev.	Cod.	Descr.	Descr.	Note
1		219930141	GR.TIMONE,PIEDE X TRAINO LENTO	KIT SITE TOW	
2		102351750	PIEDE DI STAZIONAMENTO	PARKING STAND	
3		209701150	TIMONE	TOW BAR	
4		219930142	GR. ASSALE, RUOTE TRAINO LENTO	KIT SITE TOW	
5		209701160	ASSALE	AXLE	
6		105112770	RUOTA	WHEEL	



Pos.	Rev.	Cod.	Descr.	Descr.	Note
1		102013290	COMMUTATORE	COMMUTATOR	
2		107507032	COPERCHIO COMANDO A DISTANZA	BLIND PLATE REMOTE CONTROL	
3		209509910	CONNETTORE FEMM.CON CAVI	FEMALE CONNECTOR WITH CABLES	
4		209519904	CONNETTORE COMPLETO DI CAVI	CONNECTOR WITH CABLES	TC2 vers.
4a		930609904	CONNETTORE CON CAVI	CONNECTORS WITH CABLES	TC2/50 vers.
5		107509702	MANOPOLA REG.CORRENTE SALDAT.	KNOB, WELDING CURRENT REGULAT.	
7		107509700	POTENZIOMETRO	WELDING CURRENT REGULATOR	
8		107509900	SCATOLA	CASE, BOTTOM HALF	
9		209519901	COPERCHIO (CD)	COVER	
10		209510017	PREDISPOSIZIONE CD2	SOCKET SWITCH REMOTE CONTROL	
11		209510018	TC2 COMANDO DISTANZA STANDARD	TC2 STANDARD REMOTE CONTROL	
11a		930600018	TC2 COMANDO DISTANZA STANDARD	TC2 STANDARD REMOTE CONTROL	TC2/50 vers.
12		209510019	KIT TC2 COMPLETO	KIT TC2 COMPL.	
12a		930600019	KIT TC2 COMPLETO	KIT TC2 COMPL.	TC2/50 vers.

Dear Customer,
You can send us the request for order of MOSA original spare parts, filling in this form, with the new spare parts tables as well as with the old ones, by FAX or mail.



Request from:..... **date:**..... **signature:**.....

Please send use us following sapre parts for the machine below:

MOSA SPARE PARTS:

model type:.....

serial nr:

--	--	--	--	--	--	--	--	--	--	--	--	--

NEW TABLES		
table nr.	position	q.ty

OLD TABLES	
code	q.ty

ENGINE SPARE PARTS:

engine model: **engine serial nr.:**.....

code and/or position	description and/or table	q.ty

SYNCHRONOUS ALTERNATOR SPARE PARTS:

alternator model:..... **alternator serial nr.:**.....

code and/or position	description and/or table	q.ty

