

TS 615 VS/VSX EL - BC

1 1 0 6

366109003 - GB

USE AND MAINTENANCE MANUAL SPARE PARTS CATALOG

36610M00
preparato da UPT
approvato da DITE



UNI EN ISO 9001 : 2000

ISO 9001:2000 - Cert. 0192

MOSA has certified its quality system according to UNI EN ISO 9001:2000 to ensure a constant, high quality of its products. This certification covers the design, production and servicing of engine driven welders and generating sets.

The certifying institute, ICIM, which is a member of the International Certification Network IQNet, awarded the official approval to MOSA after an examination of its operations at the head office and plant in Cusago (MI), Italy.

This certification is not a point of arrival but a pledge on the part of the entire company to maintain a level of quality of both its products and services which will continue to satisfy the needs of its clients, as well as to improve the transparency and the communications regarding all the company's activities in accordance with the official procedures and in harmony with the MOSA Manual of Quality.

The advantages for MOSA clients are:

- Constant quality of products and services at the high level which the client expects;
- Continuous efforts to improve the products and their performance at competitive conditions;
- Competent support in the solution of problems;
- Information and training in the correct application and use of the products to assure the security of the operator and protect the environment;
- Regular inspections by ICIM to confirm that the requirements of the company's quality system and ISO 9001 are being respected.

All these advantages are guaranteed by the CERTIFICATE OF QUALITY SYSTEM No.0192 issued by ICIM S.p.A. - Milano (Italy) - www.icim.it

INDEX (for all MOSA models)

M 01	QUALITY SYSTEM	
M 1.01	COPYRIGHT	
M 1.1	NOTES	
M 1.4	NOTES	
M 2- ...	SYMBOLS AND SAFETY PRECAUTIONS	
M 2.3	ABBREVIATIONS LEGEND	
M 2.4	SYMBOLS	
M 2.5...	INSTALLATION AND ADVICE BEFORE USE	
M 2.6	INSTALLATIONS AND ADVICE	
M 2.7	INSTALLATION	
M 3	PACKING	
M 4	TRANSPORT AND DISPLACEMENTS	
M 6	ASSEMBLY: CT.....	
M 20	SETTING-UP THE UNIT (DIESEL ENGINE)	
M 21	ENGINE STARTING AND USE (DIESEL ENGINE)	
M 22	STOPPING THE ENGINE (DIESEL ENGINE)	
M 25	SETTING-UP THE UNIT (GASOLINE ENGINE)	
M 26	STARTING THE ENGINE (GASOLINE ENGINE)	
M 27	STOPPING THE ENGINE (GASOLINE ENGINE)	
M 30	CONTROLS LEGEND	
M 31	CONTROLS	
M 32	CONTROLS (FRONT PANEL)	
M 33	USE AS HYDRAULIC POWER TAKE-OFF	only for TS
M 34	USE AS A WELDER	only for TS
M 35	USE AS AN ENGINE STARTER	only for TS
M 36	USE AS A BATTERY CHARGE	
M 37	USE AS A GENERATOR	
M 38	USE OF THE REMOTE CONTROL	
M 39	USE OF THE ENGINE PROTECTION	
M 40	TROUBLE SHOOTING	
M 43	MAINTENANCE	
M 44	PERIODIC MAINTENANCE	
M 45	STORAGE	
M 46	CAST OFF	
M 51	TECHNICAL DATA	
M 52	TECHNICAL DATA ENGINE DRIVEN WELDER	only for TS
M 53	DIMENSIONS	
M 55	RECOMMENDED ELECTRODES	only for TS
M 60	ELECTRICAL SYSTEM LEGENDE	
M 61	ELECTRICAL SYSTEM	
M 65	HYDRAULIC SYSTEM	
R 1	SPARE PARTS LIST	
.....	SPARE PARTS	
K...	ACCESSORIES	



ATTENTION

This use and maintenance manual is an important part of the machines in question.

The assistance and maintenance personnel must keep said manual at disposal, as well as that for the engine and alternator (if the machine is synchronous) and all other documentation about the machine.

We advise you to pay attention to the pages concerning the security (see page M1.1).



© All rights are reserved to said Company.

It is a property logo of MOSA division of B.C.S. S.p.A. All other possible logos contained in the documentation are registered by the respective owners.

▣ The reproduction and total or partial use, in any form and/or with any means, of the documentation is allowed to nobody without a written permission by MOSA division of B.C.S. S.p.A.

To this aim is reminded the protection of the author's right and the rights connected to the creation and design for communication, as provided by the laws in force in the matter.

In no case MOSA division of B.C.S. S.p.A. will be held responsible for any damage, direct or indirect, in relation with the use of the given information.

MOSA division of B.C.S. S.p.A. does not take any responsibility about the shown information on firms or individuals, but keeps the right to refuse services or information publication which it judges discutible, unright or illegal.

INFORMATION

Dear Customer,
We wish to thank you for having bought from MOSA a high quality set.

Our sections for Technical Service and Spare Parts will work at best to help you if it were necessary.

To this purpose we advise you, for all control and overhaul operations, to turn to the nearest authorized Service Centre, where you will obtain a prompt and specialized intervention.

- ☞ In case you do not profit on these Services and some parts are replaced, please ask and be sure that are used exclusively original MOSA parts; this to guarantee that the performances and the initial safety prescribed by the norms in force are re-established.
- ☞ **The use of non original spare parts will cancel immediately any guarantee and Technical Service obligation from MOSA.**

NOTES ABOUT THE MANUAL

Before actioning the machine please read this manual attentively. Follow the instructions contained in it, in this way you will avoid inconveniences due to negligence, mistakes or incorrect maintenance. The manual is for qualified personnel, who knows the rules: about safety and health, installation and use of sets movable as well as fixed.

You must remember that, in case you have difficulties for use or installation or others, our Technical Service is always at your disposal for explanations or interventions.

The manual for Use Maintenance and Spare Parts is an integrant part of the product. It must be kept with care during all the life of the product.

In case the machine and/or the set should be yielded to another user, this manual must also given to him.

Do not damage it, do not take parts away, do not tear pages and keep it in places protected from dampness and heat.

You must take into account that some figures contained in it want only to identify the described parts and therefore might not correspond to the machine in your possession.

INFORMATION OF GENERAL TYPE

In the envelope given together with the machine and/or set you will find: the manual for Use Maintenance and Spare Parts, the manual for use of the engine and the tools (if included in the equipment), the guarantee (in the countries where it is prescribed by law).

Our products have been designed for the use of generation for welding, electric and hydraulic system; ANY OTHER DIFFERENT USE NOT INCLUDED IN THE ONE INDICATED, relieves MOSA from the risks which could happen or, anyway, from that which was agreed when selling the machine; MOSA excludes any responsibility for damages to the machine, to the things or to persons in this case.





Our products are made in conformity with the safety norms in force, for which it is advisable to use all these devices or information so that the use does not bring damage to persons or things.

While working it is advisable to keep to the personal safety norms in force in the countries to which the product is destined (clothing, work tools, etc.).

Do not modify for any motive parts of the machine (fastenings, holes, electric or mechanical devices, others..) if not duly authorized in writing by MOSA: the responsibility coming from any potential intervention will fall on the executioner as in fact he becomes maker of the machine.

- ☞ **Notice:** *this manual does not engage MOSA, who keeps the faculty, apart the essential characteristics of the model here described and illustrated, to bring betterments and modifications to parts and accessories, without putting this manual uptodate immediately.*



Tel.: 02 - 90352.1 Fax: 02 - 90390466 e-mail : info@mosa.it www.mosa.it	 Divisione della BCS S.p.A. V.le Europa 59 - 20090 Cusago (Mi) - Italia	 ISO 9001:2000 - Cert. 0192/3
<p>DICHIARAZIONE DI CONFORMITA'</p>  <p>Déclaration de Conformité – Declaration of Conformity – Konformitätserklärung Conformiteitsverklaring – Declaración de Conformidad</p> <p>MOSA dichiara sotto la propria responsabilità che la macchina: MOSA déclare, sous sa propre responsabilité, que la machine: MOSA declares, under its own responsibility, that the machine: MOSA erklärt, daß die Aggregate: MOSA verklaard, onder haar eigen verantwoordelijkheid, dat de machine: MOSA declara bajo su responsabilidad que la máquina:</p> <p>Modello/Modèle/Model/Modell/Model/Modelo: _____ Codice/ Code/ Code/ Kode/ Code/ Código: _____</p> <p>è conforme con quanto previsto dalle Direttive Comunitarie e relative modifiche: est en conformité avec ce qui est prévu par les Directives Communautaires et relatives modifications: conforms with the Community Directives and related modifications: mit den Vorschriften der Gemeinschaft und deren Ergänzungen übereinstimmt: in overeenkomst is met de inhoud van gemeenschapsrichtlijnen gerelateerde modificaties: cumple con los requisitos de la Directiva Comunitaria y sus anexos:</p> <p style="text-align: center;">98/37/CE - 73/23/CE - 89/336/CE</p> <p>per la verifica sono state considerate le seguenti norme armonizzate, Norme nazionali e internazionali: pour la vérification de la conformité ont été consultées les normes harmonisées suivantes, normes nationales et internationales: to check the conformity, the following harmonized norms, national and international norms, have been consulted: zur Prüfung hat man die folgenden übereinstimmenden nationalen und internationalen Normen herangezogen: ter verificatie van de overeenkomst, zijn de volgende geharmoniseerde normen, nationaal en internationaal, geconsulteerd: para su verificación se han tenido en cuenta las Normas armonizadas, Normas nacionales e internacionales:</p> <p>Norme armonizzate - normes harmonisées - harmonized norms - übereinstimmende Normen geharmoniseerde normen - Normas armonizadas:</p> <p>EN 12100-1 EN 12100-2 EN 60204-1 EN 60974-10 EN 60974-1 (Solo per modelli - Seulement pour les modèles - Only for models - nur für die Modelle - Alleen voor de modellen - Sólo para modelos: TS) EN 50081-2 EN 50082-2</p> <p>Altre norme - autres normes - other norms - andere Normen - andere normen - otras normas: ISO 8528 EN 12601 (Solo per modelli - Seulement pour les modèles - Only for models - nur für die Modelle - Alleen voor de modellen - Sólo para modelos: GE)</p> <p style="text-align: center;">2000/14/CE</p> <p style="text-align: center;">L_{WA} Garantito - L_{WA} Garantie – Guaranteed L_{WA} : dB(A)</p> <p style="text-align: right;">  Irg. Benso Marelli Direttore Generale </p> <p style="text-align: left;">Cusago,</p>		

MM 065 4.doc

CE The CE mark (European Community) certifies that the product complies with the essential safety requirements provided by the applicable COMMUNITY DIRECTIVES. In the Conformity Declaration are reported the HARMONIZED NORMS and not, used for the checking.

SYMBOLS IN THIS MANUAL

- The symbols used in this manual are designed to call your attention to important aspects of the operation of the machine as well as potential hazards and dangers for persons and things.

IMPORTANT ADVICE

- Advice to the User about the safety:

- ☞ N.B.: The information contained in the manual can be changed without notice. Potential damages caused in relation to the use of these instructions will not be considered because these are only indicative. Remember that the non observance of the indications reported by us might cause damage to persons or things. It is understood, that local dispositions and/or laws must be respected.

WARNING



Situations of danger - no harm to persons or things

Do not use without protective devices provided

Removing or disabling protective devices on the machine is prohibited.

Do not use the machine if it is not in good technical condition

The machine must be in good working order before being used. Defects, especially those which regard the safety of the machine, must be repaired before using the machine.

SAFETY PRECAUTIONS



DANGEROUS

This heading warns of an **immediate danger** for persons as well for things. Not following the advice can result in serious injury or death.



WARNING

This heading warns of situations which could result in injury for persons or damage to things.



CAUTION

To this advice can appear a danger for persons as well as for things, for which can appear situations bringing material damage to things.



IMPORTANT



NOTE



ATTENTION

These headings refer to information which will assist you in the correct use of the machine and/or accessories.

SYMBOLS (for all MOSA models)



STOP - Read absolutely and be duly attentive



Read and pay due attention



GENERAL ADVICE - If the advice is not respected damage can happen to persons or things.



HIGH VOLTAGE - Attention High Voltage. There can be parts in voltage, dangerous to touch. The non observance of the advice implies life danger.



FIRE - Danger of flame or fire. If the advice is not respected fires can happen.



HEAT - Hot surfaces. If the advice is not respected burns or damage to things can be caused.



EXPLOSION - Explosive material or danger of explosion. in general. If the advice is not respected there can be explosions.



WATER - Danger of shortcircuit. If the advice is not respected fires or damage to persons can be caused.



SMOKING - The cigarette can cause fire or explosion. If the advice is not respected fires or explosions can be caused.



ACIDS - Danger of corrosion. If the advice is not respected the acids can cause corrosions with damage to persons or things.



WRENCH - Use of the tools. If the advice is not respected damage can be caused to things and even to persons.



PRESSION - Danger of burns caused by the expulsion of hot liquids under pressure.



ACCES FORBIDDEN to non authorizad people.

PROHIBITIONS No harm for persons

Use only with safety clothing -



It is compulsory to use the personal protection means given in equipment.

Use only with safety clothing -



It is compulsory to use the personal protection means given in equipment.

Use only with safety protections -



It is a must to use protection means suitable for the different welding works.

Use with only safety material -



It is prohibited to use water to quench fires on the electric machines.

Use only with non inserted voltage -



It is prohibited to make interventions before having disinserted the voltage.

No smoking -



It is prohibited to smoke while filling the tank with fuel.

No welding -



It is forbidden to weld in rooms containing explosive gases.

ADVICE No harm for persons and things

Use only with safety tools, adapted to the specific use -

It is advisable to use tools adapted to the various maintenance works.

Use only with safety protections, specifically suitable



It is advisable to use protections suitable for the different welding works.

Use only with safety protections -



It is advisable to use protections suitable for the different daily checking works.

Use only with safety protections -




It is advisable to use all protections while shifting the machine.

Use only with safety protections -




It is advisable to use protections suitable for the different daily checking works.and/or of maintenance.

 The installation and the general advice concerning the operations, are finalized to the correct use of the machine, in the place where it is used as generator group and/or welder.


ENGINE	Stop engine when fueling	CHECKING BOARD	Do not touch electric devices if you are barefoot or with wet clothes.
	Do not smoke, avoid flames, sparks or electric tools when fueling.		Always keep off leaning surfaces during work operations
	Unscrew the cap slowly to let out the fuel vapours.		Static electricity can damage the parts on the circuit.
	Slowly unscrew the cooling liquid tap if the liquid must be topped up.		An electric shock can kill
	The vapor and the heated cooling liquid under pressure can burn face, eyes, skin.		
	Do not fill tank completely.		
	Wipe up spilled fuel before starting engine.		
	Shut off fuel of tank when moving machine (where it is assembled).		
	Avoid spilling fuel on hot engine.		
	Sparks may cause the explosion of battery vapours		




















 **FIRST AID.** In case the operator should be sprayed by accident, from corrosive liquids a/o hot toxic gas or whatever event which may cause serious injuries or death, predispose the first aid in accordance with the ruling labour accident standards or of local instructions.

Skin contact	Wash with water and soap
Eyes contact	Irrigate with plenty of water, if the irritation persists contact a specialist
Ingestion	Do not induce vomit as to avoid the intake of vomit into the lungs, send for a doctor
Suction of liquids from lungs	If you suppose that vomit has entered the lungs (as in case of spontaneous vomit) take the subject to the hospital with the utmost urgency
Inhalation	In case of exposure to high concentration of vapours take immediately to a non polluted zone the person involved



 **FIRE PREVENTION.** In case the working zone, for whatsoever cause goes on fire with flames liable to cause severe wounds or death, follow the first aid as described by the ruling norms or local ones.

EXTINCTION MEANS	
Appropriated	Carbonate anhydride (or carbon dioxide) powder, foam, nebulized water
Not to be used	Avoid the use of water jets
Other indications	Cover eventual shedding not on fire with foam or sand, use water jets to cool off the surfaces close to the fire
Particular protection	Wear an autorespiratory mask when heavy smoke is present
Useful warnings	Avoid, by appropriate means to have oil sprays over metallic hot surfaces or over electric contacts (switches, plugs, etc.). In case of oil sprinkling from pressure circuits, keep in mind that the inflammability point is very low.

 WARNING					 CAUTION		 DANGEROUS
							
							

 WARNING	THE MACHINE MUST NOT BE USED IN AREAS WITH EXPLOSIVE ATMOSPHERE
---	--



INSTALLATION AND ADVICE BEFORE USE

The operator of the welder is responsible for the security of the people who work with the welder and for those in the vicinity.

The security measures must satisfy the rules and regulations for engine driven welders.

The information given below is in addition to the local security norms.

Estimate possible electromagnetic problems in the work area taking into account the following indications.

1. Telephonic wirings and/or of communication, check wirings and so on, in the immediate vicinity.
2. Radio and television receptors and transmettors.
3. Computer and other checking devices.
4. Critical devices for safety and/or for industrial checks.
5. Peapol who, for instance, use pace-maker, hearing-aid for deaf or something and else.
6. Devices used for rating and measuring.
7. The immunity of other devices in the operation area of the welder. Make sure that other used devices are compatible. If it is the case, provide other additional measures of protection.
8. The daily duration of the welding time.



Make sure that the area is safe before starting any welding operation.

- ⚡ Do not touch any bare wires, leads or contacts as they may be live and there is danger of electric shock which can cause death or serious burns. The electrode and welding cables, etc. are live when the unit is operating.
- ⚡ Do not touch any electrical parts or the electrode while standing in water or with wet hands, feet or clothes.
- ⚡ Insulate yourself from the work surface while welding. Use carpets or other insulating materials to avoid physical contact with the work surface and the floor.
- ⚡ Always wear dry, insulating gloves, without holes, and body protection.
- ⚡ Do not wind cables around the body.
- ⚡ Use ear protections if the noise level is high.
- ⚡ Keep flammable material away from the welding area.
- ⚡ Do not weld on containers which contain flammable material.
- ⚡ Do not weld near refuelling areas.
- ⚡ Do not weld on easily flammable surfaces.
- ⚡ Do not use the welder to defrost (thaw) pipes.
- ⚡ Remove the electrode from the electrode holder, when not welding.
- ⚡ Avoid inhaling fumes by providing a ventilation system or, if not possible, use an approved air breather.
- ⚡ Do not work in closed areas where there is no fresh air flow.
- ⚡ Protect face and eyes (protective mask with suitable dark lens and side screens), ears and body (non-flammable protective clothers).






INSTALLATION AND ADVICE BEFORE USE

GASOLINE ENGINES

- Use in open space, air swept or vent exhaust gases, which contain the deadly carbone oxyde, far from the work area.


DIESEL ENGINES

- Use in open space, air swept or vent exhaust gases far from the work area.




POSITION


Place the machine on a level surface at a distance of at least 1,5 m from buildings or other plants.



Maximum leaning of the machine (in case of dislevel)



Check that the air gets changed completely and the hot air sent out does not come back inside the set so as to cause a dangerous increase of the temperature.



☞ Make sure that the machine does not move during the work: **block** it possibly with tools and/or devices made to this purpose.

MOVES OF THE MACHINE

☞ At any move check that the engine is **off**, that there are no connections with cables which impede the moves.

PLACE OF THE MACHINE




In spots where it often rains and/or there are flooded areas, do **not** put the machine:

- in the bad weather
- in flooded places.


Protect all the electric parts at risk, because water infiltrations could cause short circuits with damages at persons and/or things.

The protection degree of the machine is put on the data plate and in this manual at page "Technical Data".





NOTE






Be sure that the lifting devices are: correctly mounted, adequate for the weight of the machine with its packaging, and conforms to local rules and regulations.

When receiving the goods make sure that the product has not suffered damage during the transport, that there has not been rough handling or taking away of parts contained inside the packing or in the set.

In case you find damages, rough handling or absence of parts (envelopes, manuals, etc.), we advise you to inform immediately our Technical Service.



For eliminating the packing materials, the User must keep to the norms in force in his country.



- 1) Take the machine (C) out of the shipment packing. Take out of the envelope (A) the user's manual (B).
- 2) Read: the user's manual (B), the plates fixed on the machine, the data plate.

**NOTE**

In case you should transport or move the machine, keep to the instructions as per the figures.

Make the transportation when the machine has **no** petrol in its tank, **no** oil in the engine and and electrolyte in the battery.





Be sure that the lifting devices are: correctly mounted, adequate for the weight of the machine with it's packaging, and conform to local rules and regulations.

Only authorized persons involved in the transport of the machine should be in the area of movement.


DO NOT LOAD OTHER PARTS WHICH CAN MODIFY WEIGHT AND BARICENTER POSITION.

IT IS STRICTLY FORBIDDEN TO DRAG THE MACHINE MANUALLY OR TOW IT BY ANY VEHICLE (model with no CTL accessory).

If you did not keep to the instructions, you could damage the structure of the machine.



LIFT ONLY THE MACHINE



DO NOT LIFT THE MACHINE AND TRAILER



**DANGER: LIFTING EYE IS NOT DESIGNED TO SUPPORT
ADDED WEIGHT OF ROAD TOW TRAILER**





ATTENTION


The CTL accessory cannot be removed from the machine and used separately (actioned manually or following vehicles) for the transport of loads or anyway for used different from the machine movements.

TRAILERS

The machines provided for assembling the CTL accessory (slow towing trolley) can be towed up to a **maximum** speed of **40 Kms/hour** on asphalted surfaces.


Towing on public roads or turnpikes of any type **IS EXCLUDED**, because **not** in possession of the requirements by national and foreign traffic norms.

Nota: Lift the machine and assemble the parts as shown in the drawing



For assembling the generating set on the trolley CTL22 please keep to following instructions:

- 1) - Lift the generating set (by means of suitable hook).
- 2) - Slightly fix the jaw (3) of the parking foot to the bar with the M10x20 screws, the M10 nuts and the washers (so as to let the foot sprag go through).
- 3) - Split (unscrewing them) the two parts of the foot (4S-4I) to be able later to assemble them on the jaw.
- 4) - Introduce into the jaw (3) the upper part (4S) of the foot and screw again the lower part (4I), then tighten the screws (4V) of the jaw to the towbar and block momentarily with the lever (4L) the whole foot.
- 5) - Assemble the tool holder (6) on the towbar with the M8x14 screws, nuts and washers.
- 6) - Assemble on the machine the towbar (5) complete of foot with the M10x20 screws, nuts and washers (see fig. page M6.3).
- 7) - Assemble the axle (7) to the base of the machine (see fig. page M6.3) with the M 10x25 screws and relative washers (two per part) so that their supports coincide.
- 8) - Insert the wheel (9) on the axle then screw the self blocking nuts (8).
- 9) - Pump the tyre (9) bringing the pressure to four atms.
- 10) - Lower the machine to the ground and place the parking foot definitively (regulating at the best height).



ATTENTION

Do not substitute the original tires with other types.



Nota: Lift the machine and assemble the parts as shown in the drawing

Lift the machine and assemble the parts indicated in the figure.

1) and 2) fix the crossbars to the unit with the screws corresponding to the holes made on the supports.


3) fix the extension plate of the exhaust pipe in the points provided on the trolley.

Put the unit on the trolley platform and then fix it. Connect the flexible pipe to the plate and to the exhaust of the unit with the blocking clamps.

ATTENTION For every missing information please refer to the conformity declaration for vehicles of homologated type given with the trolley. declaratio

☞ The maximum permitted speed can be found in the declaration of **conformity**

For information about the trailer refer to the declaration of conformity, which is supplied with the trailer.





BATTERY WITHOUT MAINTENANCE



Connect the cable + (positive) to the pole + (positive) of the battery (after having taken away the protection), by properly tightening the clamp.

Check the state of the battery from the colour of the warning light which is in the upper part.

- Green colour: battery OK
- Black colour: battery to be recharged
- White colour: battery to be replaced

DO NOT OPEN THE BATTERY.



LUBRICANT

RECOMMENDED OIL

MOSA recommends selecting **AGIP** engine oil. Refer to the label on the motor for the recommended products.

PRODOTTI RACCOMANDATI RECOMMENDED PRODUCTS	
AGIP SUPERDIESEL 15W/40 API CF4-SG	OLIO MOTORE DIESEL DIESEL ENGINE OIL
AGIP SUPERMOTOROIL 20W/50 API CC-SF	OLIO MOTORE BENZINA GASOLINE ENGINE OIL
AGIP ANTIFREEZE EXTRA INIBITE ETHYLENE GLYCOL (50% + 50% H ₂ O)	CIRCUITO DI RAFFREDDAMENTO COOLING CIRCUIT (CUNA NC 956-16 ED 97)

Please refer to the motor operating manual for the recommended viscosity.

REFUELLING AND CONTROL:

Carry out refuelling and controls with motor at level position.

1. Remove the oil-fill tap (24)
2. Pour oil and replace the tap
3. Check the oil level using the dipstick (23); the oil level must be comprised between the minimum and maximum indicators.



ATTENTION

It is dangerous to fill the motor with too much oil, as its combustion can provoke a sudden increase in rotation speed.



DRY AIR FILTER

Check that the dry air filter is correctly installed and that there are no leaks around the filter which could lead to infiltrations of non-filtered air to the inside of the motor.



OIL BATH AIR FILTER

Fill the air filter using the same engine oil up to the level indicated on the filter.



FUEL



ATTENTION



Do not smoke or use open flames during refuelling operations, in order to avoid explosions or fire hazards.

Fuel fumes are highly toxic; carry out operations outdoors only, or in a well-ventilated environment.



Avoid accidentally spilling fuel. Clean any eventual leaks before starting up motor.

Refill the tank with good quality diesel fuel, such as automobile type diesel fuel, for example.

For further details on the type of diesel fuel to use, see the motor operating manual supplied.

Do not fill the tank completely; leave a space of approx. 10 mm between the fuel level and the wall of the tank to allow for expansion.

In rigid environmental temperature conditions, use special winterized diesel fuels or specific additives in order to avoid the formation of paraffin.



GROUNDING CONNECTION

The grounding connection to an earthed installation **is obligatory** for all models equipped with a differential switch (circuit breaker). In these groups the generator star point is generally connected to the machine's earthing; by employing the TN or TT distribution system, the differential switch guarantees protection against indirect contacts.

In the case of powering complex installations requiring or employing additional electrical protection devices, the coordination between the protection devices must be verified.

For the grounding connection, use the terminal (12); comply to local and/or current regulations in force for electrical installations and safety.





Check daily



NOTE

Do not alter the primary conditions of regulation and do not touch the sealed parts.


ENGINES WITH MANUAL RECOIL



Hold the starting handle firmly.



Pull the rope hard and fast. Pull it all the way out. Use two hands if necessary.




Then returning it slowly.

ENGINES WITH ACCELERATOR LEVER

Make sure that the accelerator lever or the switch (16) is at its minimum setting.

Insert the electric protection device (D-Z2-N2) lever towards above and, where mounted, check the isolation monitor (A3) see page M37 –



Introduce the key (Q1), turn it clockwise completely, leaving it as soon as the engine starts and/or the push button (32) (models without key) leaving it as soon as the engine starts.

NB.: for safety reason the key must be kept by qualified personnel.

Once the engine has started leave it running at a reduced speed for some minutes.

Accelerate the engine at max., set lever on maximum position and then take up load.

ENGINES WITHOUT ACCELERATOR LEVER

Insert the electric protection device (D-Z2-N2) lever towards above and, where mounted, check the isolation monitor (A3) see page M37 –



Introduce the key (Q1), turn it clockwise completely, leaving it as soon as the engine starts.

NB.: for safety reason the key must be kept by qualified personnel.

Let the engine run for some minutes before drawing the load.

Open the fuel cock (where it is assembled).



CAUTION

RUNNING-IN

During the first 50 hours of operation, do not use more than 60% of the maximum output power of the unit and check the oil level frequently, in any case please stick to the rules given in the engine use manual.



NOTE

The machines with E.P. 1 engine protection device (D1), use the accelerator lever ONLY IN EMERGENCY when the engine protection does not work. In this case turn immediately to our Authorized Assistance Centers.

**ENGINE WITH PREHEATING GLOW PLUGS**

Turn the starter key (Q1) on the position „preheating glow plugs“ (the glow plugs light will be on I4), when the light is off, turn the starter key completely clockwise until the engine begins to fire.

Let the engine run for some minutes before drawing the load.

ENGINES WITH R.P.M. ELECTRONIC ADJUSTER (ONLY FOR GENERATING SET)

Turn the starter key (Q1) completely clockwise until the engine begins to fire.

☞ Wait for the AUTOMATIC preheating time before drawing the load

OCCASIONAL USE OF THE ENGINE

Using the engine in special conditions which need an immediate intervention, such as emergency plants, etc., use advise to use our Engine Assistance Centres for specific interventions or our Technical Assistance Service.

**CAUTION**

If the engine fails to start, do not insist for at least 15 seconds.

Space the further operations waiting for at least 4 minutes.


**CAUTION****MACHINE WITH EMERGENCY BUTTON**

Before starting the engine, make sure that the emergency button (32B) is off (turn the button clockwise for this operation)


**CAUTION****RUNNING-IN**

During the first 50 hours of operation, do not use more than 60% of the maximum output power of the unit and check the oil level frequently, please follow the instructions on the engine use and maintenance manual..

☞ Before stopping the engine **it is compulsory** to effect the following operations:
- stop to draw three/single-phase current from the auxiliary sockets.



- stop to draw power from the welding sockets (only for TS models).



ENGINES WITH ACCELERATOR LEVER

☞ Make sure that the unit is not supplying any power.

Disconnect the electrical protection device (D-Z2-N2) lever downward.

Set the accelerator lever or the switch (16) to minimum position and wait for a few minutes to allow the engine to cool, anyway follow the instructions contained in the engine manual.

Pull the stop lever (28) until the engine stops (where it is assembled).



Remove the key (Q1) turning it counter clockwise, OFF position, then take it out.

☞ **NB.:**for safety reason the key must be kept by qualified personnel.

ENGINES WITHOUT ACCELERATOR LEVER

Make sure that the unit is not supplying any power.

Disconnect the electrical protection device (D-Z2-N2) lever downward.

Let the engine idle for a few minutes.

Press the pushbutton (F3) until the engine stops

(where it is assembled).

Shut the fuel cock (where it is assembled).



Remove the key (Q1) turning it counter clockwise, OFF position, then take it out.

☞ **NB.:** for safety reason the key must be kept by qualified personnel.

ENGINES WITH R.P.M. ELECTRONIC ADJUSTER (ONLY FOR GENERATING SET)

Make sure that the unit is not supplying any power.

Disconnect the electrical protection device (D-Z2-N2) lever downward.

Let the engine idle for a few minutes.

Press the pushbutton (F3) until the engine stops (where it is assembled).



Remove the key (Q1) turning it counter clockwise, OFF position, then take it out.


☞ **NB.:** for safety reason the key must be kept by qualified personnel.





CAUTION

MACHINE WITH EMERGENCY BUTTON

Pressing it, it allows to stop the engine in any condition (32B) (when assembled).
To re-establish it, see page M21...



4A	Hydraulic oil level light	B4	Exclusion indicating light PTO HI
9	Welding socket (+)	B5	Auxiliary current push button
10	Welding socket (-)	C2	Fuel level light
12	Earth terminal	C3	E.A.S. PCB
15	A.C. socket	C6	Control unit for generating sets QEA
16	Accelerator lever	D	Ground fault interrupter (30 mA)
17	Feed pump	D1	Engine control unit and economiser EP1
19	48V D.C. socket	D2	Ammeter
22	Engine air filter	E2	Frequency meter
23	Oil level dipstick	F	Fuse
24	Engine oil reservoir cap	F3	Stop switch
24A	Hydraulic oil reservoir cap	F5	Warning light, high temperature
24B	Water filling cap	F6	Arc-Force selector
25	Fuel prefilter	G1	Fuel level transmitter
26	Fuel tank cap	H2	Voltage commutator
27	Muffler	H6	Fuel electro pump
28	Stop control	I2	48V A.C. socket
29	Engine protection cover	I3	Welding scale switch
30	Engine cooling/alternator fan belt	I4	Preheating indicator
31	Oil drain tap	I5	Y/▲ switch
31A	Hydraulic oil drain tap	I6	Start Local/Remote selector
31B	Water drain tap	L	A.C. output indicator
31C	Exhaust tap for tank fuel	L5	Emergency button
32	Button	L6	Choke button
33	Start button	M	Hour counter
34	Booster socket 12V	M1	Warning level light
34A	Booster socket 24V	M2	Contactora
35	Battery charge fuse	M5	Engine control unit EP5
36	Space for remote control	M6	CC/CV switch
37	Remote control	N	Voltmeter
42	Space for E.A.S.	N1	Battery charge warning light
42A	Space for PAC	N2	Thermal-magnetic circuit breaker/Ground fault interrupter
47	Fuel pump	N5	Pre-heat push-button
49	Electric start socket	N6	Connector - wire feeder
54	Reset button PTO HI	O1	Oil pressure warning light/Oil alert
55	Quick coupling m. PTO HI	P	Welding arc regulator
55A	Quick coupling f. PTO HI	Q1	Starter key
56	Hydraulic oil filter	Q3	Derivation box
59	Battery charger thermal switch	Q4	Battery charge sockets
59A	Engine thermal switch	Q7	Welding selector mode
59B	Aux current thermal switch	R3	Siren
59C	Supply thermal switch wire feeder-42V	S	Welding ammeter
59D	Pre-heater (spark plug) thermal switch	S1	Battery
59E	Supply thermal switch oil/water heater	S3	Engine control unit EP4
59F	Electropump thermal switch	S6	Wire feeder supply switch
63	No load voltage control	S7	Plug 230V singlephase
66	Choke control	T	Welding current regulator
67A	Auxiliary / welding current control	T4	Dirty air filter warning light/indicator
68	Cellulosic electrodes control	T5	Earth leakage relay
69A	Voltmeter relay	T7	Analogic instrument V/Hz
70	Warning lights	U	Current transformer
71	Selecting knob	U3	R.P.M. adjuster
72	Load commut. push button	U4	Polarity inverter remote control
73	Starting push button	U5	Release coil
74	Operating mode selector	U7	Engine control unit EP6
75	Power on warning light	V	Welding voltage voltmeter
76	Display	V4	Polarity inverter control
79	Wire connection unit	V5	Oil pressure indicator
86	Selector	W1	Remote control switch
86A	Setting confirmation	W3	Selection push button 30 I/1' PTO HI
87	Fuel valve	W5	Battery voltmeter
88	Oil syringe	X1	Remote control socket
A3	Insulation monitoring	Y3	Button indicating light 20 I/1' PTO HI
A4	Button indicating light 30 I/1' PTO HI	Y5	Commutator/switch, serial/parallel
B2	Engine control unit EP2	Z2	Thermal-magnetic circuit breaker
B3	E.A.S. connector	Z3	Selection push button 20 I/1' PTO HI
		Z5	Water temperature indicator





This symbol (Norm EN 60974-1 security standards for arc welders) signifies that the welder can be used in areas with increased risk of electrical shock.



ATTENTION

The sockets, after the machine is started (see pages M21-26), also with no cables, are anyway under voltage.




ATTENTION

The areas, access of which is forbidden to unqualified personel, are:
 - the control switchboard (front) - the exhaust of the endothermic engine - the welding process.

Check at the beginning of any work the electric parameters and/or the control placed on the front.

Make sure that the ground connection (12) is efficient (keep to installation local rules and/or to national laws), in order to integrate or ensure the working of varius electric protection devices referring to the several distribution system TT/TN/IT, operation unnecessary for machine with isometer.

Fully insert the welding cable plugs into the corresponding sockets ("only gauging", 9+/10-) turning them clockwise to lock them in position.



Make sure that the ground clamp ,whose cable must be connected to the + or - terminal, depending on the type of electrode, makes a good connection and is near to the welding position.

Pay attention to the two polarities of the welding circuit, which must not come in electric contact between themselves.

When using the welder for air arc gouging connect the ground lead to the - socket and the gouging lead to the socket marked "only gouging" (if present).

MACHINES WITH E.V. PROTECTION

Accelerate the engine at max. with the accelerator lever (16).See page M 39.

MACHINE WITH E.P.2 PROTECTION (B2)

Accelerate the engine at max. with the accelerator lever (16) (when assebled).

See page M 39

MACHINE WITH E.P.1 PROTECTION (D1)


See page M 39.1

REMOTE CONTROL TC...



See page M 38

WELDING CURRENT REGULATOR



Position welding current adjusting knob (T) in correspondance of the chasen current value, so as to obtain the necessary amperage, taking into acount the diameter and the type of the electrode.

For technical data see page M52



ATTENTION

To reduce the risk of electromagnetic interferences, use the minimum lenght of welding cables and keep them near and down (ex. on the floor).

The welding operations must take place far from any sensitive electronic device.Make sure that the unit is earthed. (see M20 and/or M25). In case the interference should last, adapt further disposition,such as: move the unit, use screened cables, line filters, screen the entire work area. In case the above mentioned operations are non sufficient, please contact our Thechnical Assistance Service.



CAUTION

With a welding cable length up to 20 m is suggested a section of 35 mm²; with longer cables a bigger section is required.



MACHINE WITH REDUCTION SCALE SWITCH



For small electrodes (up to Ø 3.25-130A and 4-200A) it is recommended to use the reduction scale switch (I3) allowing a more accurate regulation of the welding current (lever position at 130 A and/or 200A).

When using electrodes of a diameter greater than 3.25 and/or 4 set the welding scale knob to 100% and/or max. position.

The arc regulator (T) functions equally between both positions (100%-130A and/or 200A).



Protection fuse (when assembled):the fuse protects the electronic welding PCB in case the remote control is short circuited.

MACHINE WITH O.C.V.

It permits to choose, according to the work to be done and/or the electrode type used, the best O.C.V.



MACHINE WITH POLARITY INVERTER

It permits to have at the electrode holder the positive or negative polarity of the welding diode bridge. It is used above all in the first run with cellulosic electrodes to lower the bath temperature and so doing ease up the welding on pipes of small thickness



MACHINE WITH BASIC CURRENT "BC"

Positioning the switch on „ON“, is obtained a low voltage welding current which keeps, always, the lit arc necessary for some types of cellulosic electrodes or when a high penetration is wanted.



For electrodes of basic or rutile type, position the switch on "OFF", the welding current will always remain constant.


"CC/CV" MODELS



These models can be used with electrodes or for TIG welding by selecting the CC (constant current) mode, and with solid wire (MIG, MAG) or flux cored wire selecting the CV (constant voltage) mode. The mode of operation is selected by a switch on the front panel.



MACHINE WITH ARC CONTROL OR SELECTOR "ARC FORCE"



Set the welding arc using adjuster knob (6) so as to obtain, for the chosen current value, the best arc characteristic according to the electrode type and to the work to be performed.




On machines with an Arc Force selector, the same result can be obtained by turning the selector "ON" or "OFF". When switched "ON" a base current is applied to the welding current output acting as a sort of "automatic" arc forcing that does not need to be regulated.

For technical data see page M52


At the end of every welding process and/or work, proceed with all the use operations in inverted sense.

To stop the machine see pages M 22-27.

☞ **It is strictly forbidden to connect the group to the public mains a/o to another source of electric power.**

 **WARNING**

Sockets are not **self-locked**: tension is available immediately after starting also with no plug.

 **WARNING**

The areas, **access** of which is forbidden to unqualified personel, are:
- the control switchboard (front), the exhaust of the endothermic engine.

☞ At the beginning of every work, check the electric parameters and/or the controls placed on the front.


Make sure the unit is properly grounded (12) (where it is assembled).
- See page M20, 21, 22, 25, 26, 27 -.

Move the accelerator lever (16) and reach the engine maximum speed, except for the engines with constant rpm; the voltmeter (N) (where it is assembled) shows the single-phase voltage whether three or single-phase current has to be drawn.

Nominal voltage	Indicative no-load voltage	
	asynchronous	synchronous (*)
110V	±10%	±5%
230V	±10%	±5%
230V	±10%	±5%
400V	±10%	±5%

*N.B.: with electronic tens. regul. RVT ±1%

Connect up the machine, using proper plugs and cables in good condition to the AC socket (15) to draw single or three-phase power, or, by cables with adequate section, to the terminal board, placed inside the derivation box (Q3).




The warning light (L), located near the current socket, lights up when the unit can supply alternated current, on condition that the engine is at the maximum rpm.

☞ N.B.: if the warning light does not flash, check the accelerator which must be at its maximum, or the fuse of the relevant socket. (single-phase) or the thermoprotection.

Using several sockets at the same time, the maximum power possible is that indicated on the data plate.

To draw power simultaneously in the TS welder version see page M52.

 **CAUTION**


The replacement of the fuse must absolutely be done with the engine off (remove the mechanical protection, then shift down the small lever of the fuse holder placed on the front panel).

The max. continuous power of the generating set or the load current must not be exceeded.

MACHINE WITH THERMOPROTECTION

If you overload the genset the thermoprotection will automatically switch off. If the thermoprotection is released, disconnect all the connected loads.




CIRCUIT BREAKER

Reset the thermoprotection pressing the central pole.

When reset, connect the loads again. In case the protection should act furtherly, check: the connections, the wires or others, and if necessary call the Assistance Service.



Avoid to hold the central pole of the thermoprotection pressed for a long time.

Otherwise, in case of trouble, it will not click, **damaging** the generating set.



TS ... PL VERSION

Start the machine and wait for the end of the preheating time imposed by the EP1, EP2, EP5 engine protection device. - See pages M39... - Press the „generation possibility“ push button (B5) placed on the front side of machine.


The voltmeter will show the auxiliary voltage which, for machines at 1500/1800 RPM, must. be approx. $\approx 230V \pm 10\%$ and for machines at 3000/3600 RPM (engine idling) must. be approx. $\approx 180V \pm 10\%$.

Push upwards the lever of magnetothermic switch referring to the socket from which load is to be drawn.

MACHINE WITHOUT PROTECTIVE DEVICE

In case machine is not equipped with protective device of indirect contacts, by means of automatic breaking of supply, it is **necessary** to put between the load and the generation a differential switch or a similar equipment capable, in any case, to observe the regulations in force CEI 64/8 (and/or successive) Part 4 Par. 4.13.1 and harmonized by directive Nr. 72/23/EEC.


UNIT FITTED WITH GROUND FAULT INTERRUPTER SWITCH (GFI)



Turn on the GFI safety-switch (D) by pushing it upwards.

The GFI is a safety device which protects the circuit in the event of a malfunction. In this case the switch disconnects the three and single-phase circuit when in any part of the electric connections a current leakage of more than 30 mA occurs.

UNIT FITTED WITH THERMAL MAGNETIC BREAKER




Turn on the thermal magnetic breaker (Z2) by pushing it to the ON position.

The thermal-magnetic breaker is a safety device which protects the circuit in the event of a malfunction. In this case the switch disconnects the three and single-phase circuit when in any part of the electric connections a short circuit or a current absorption occurs above the data specified on the label of the unit.

In the model with setting **DO NOT INTERVENE** on the setting itself. To modify it, please contact our Technical Assistance Service.


UNIT FITTED WITH GFI SWITCH THERMAL MAGNETIC BREAKER



This switch includes the characteristics of both types of breakers (N2).

UNIT WITH VOLTMETRIC COMMUTATOR (ONLY FOR GENERATING SET)

WARNING: the possible single-phase loads must be correctly divided in the three phases, in order to avoid any possible voltage fall on one phase that results excessively loaded.




Check the voltages on the various phases with the switch located on the front (H2) and check, reading on the voltmeter (N) about the same voltage value

N.B.: in case of overload, it is possible that the engine lowers its speed and the voltage is reduced remarkably. In this case, it is necessary to reduce immediately the load.

CAUTION

For machines at 3000/3600 RPM the EP1 safety device will automatically provide to accelerate engine when load is drawn. - See page M39.1 -







The remote control device for regulating the welding current is connected to the front panel by means of a multipole connector.

To regulate the current from the TC2 / TC2/50, move the switch (7), located above the multipole connector (8), to "ON" position.

Position welding current adjusting (T) knob at the necessary current value for the diameter and type of electrode.


- See page M51 -



The device enables to totalize the welding current of two positions or of two welding machine.

Connect each one of the inputs "+" and "-" of the PAR 600 to each welding position and draw, according to the use, the total current from the "+" and "-" output socket.

Fully insert the welding cable plugs into the corresponding socket (9+/10-) turning them clockwise to lock them in position.

**MAKE SURE**

- 1) the both positions have an identic polarity
 - 2) that O.C.V. have an identic position
- See page M34.2 -

ENGINE PROTECTION (ES - EV)

The devices ES or EV ensure the protection of the engine in case of low oil pressure or engine high temperature.


The system consist of electronic card of control and check, and of an engine stop device: solenoid (**ElettroStop**), electrovalve (**ElettroValvola**)

The device enter in operation when the engine starts and, in case of low oil pressure and high temperature, will stop the machine and show the cause of the stop with the warning light of high temperature or low oil pressure.

In case of low oil pressure, check the level and if it is correct, call the Service Station. In case of high temperature, make sure that there are no leaves and/or pieces of material obstructing the air ducts.

N.B.: if the unit is used as a generator in hot climates and with loads near to the maximum, the protection device can be triggered off, please reduce the load of the engine.

Once the cause of the problem is removed, to reset the protection, it is enough to report the ignition key (Q1) on "OFF" position and start the engine again.



NOTE

THE ENGINE PROTECTIONS DO NOT WORK WHEN THE OIL IS OF LOW QUALITY BECAUSE NOT CHANGED REGULARLY AT INTERVALS AS PRESCRIBED IN THE OWNER'S ENGINE MANUAL.

PROBLEM	POSSIBLE CAUSE	WHAT TO DO
No welding current but auxiliary output is OK	1) Defective diode bridge 2) Problem with welding current control (PCB)	1) Check the diodes of the bridge 2) Is the remote control switch in the internal position? 3) Check the diodes and SCR's of the bridge. 4) Check the transformer which supplies power to the welding control PCB. If it is OK replace the PCB
Weld poorly	1) Defective diode bridge 2) Problem with welding current control (PCB)	1) Check the open circuit welding voltage. If it is OK the diode bridge is OK. If it is 1/3 or 2/3 of the nominal value check the diodes or the SCR's. 2) If the diode bridge is OK replace the PCB.
Intermittently welds poorly	1) Bad connections to welding current PCB 2) Problem with welding current control PCB	1) Check that the pins of the green connectors are clean and making good contact. Check that shunt connections are tight. 2) Replace the welding current control PCB
No welding output and no auxiliary power output	1) Short circuit in wiring 2) Defective condenser 3) Defective stator 4) Short circuited diode bridge	1) Check the wiring inside the welder for a short circuit between cables or to ground. 2) If the wiring is OK, short circuit the condenser to be sure that it is discharged, disconnect all wires from condenser and, using an ohmmeter, check that the condenser is not short circuited. 3) If the condenser box is OK, disconnect all leads from the stator except for those going to the condenser box and check the output from the alternator. If there is no output from the welding winding and the auxiliary winding, replace the stator. 4) If there is output from all windings reconnect the diode bridge and check if there is welding current. If not the diode bridge is defective. If there is welding current connect the auxiliary power leads one at a time until there is no output; at this point, the short circuit is in that line.

[.] only for models with electronic control of welding current.



WARNING



MOVING PARTS can injure

- Have **qualified** personnel do maintenance and troubleshooting work.
 - Stop the engine before doing any work inside the machine. If for any reason the machine must be operated while working inside, **pay attention** moving parts, hot parts (exhaust manifold and muffler, etc.) electrical parts which may be unprotected when the machine is open.
 - Remove guards only when necessary to perform maintenance, and replace them when the maintenance requiring their removal is complete.
 - Use suitable tools and clothes.
 - Do not modify the components if not authorized.
- See pag. M1.1 -



HOT surface can hurt you

NOTE

By maintenance at care of the utilizer we intend all the operatios concerning the verification of mechanical parts, electrical parts and of the fluids subject to use or consumption during the normal operation of the machine.

For what concerns the fluids we must consider as maintenance even the periodical change and or the refills eventually necessary.

Maintenance operations also include machine cleaning operations when carried out on a periodic basis outside of the normal work cycle.

The repairs **cannot be considered** among the maintenance activities, i.e. the replacement of parts subject to occasional damages and the replacement of electric and mechanic components consumed in normal use, by the Assistance Authorized Center as well as by MOSA.

The replacement of tires (for machines equipped with trolleys) must be considered as repair since it is not delivered as standard equipment any lifting system.

The periodic maintenance should be performed according to the schedule shown in the engine manual. An optional hour counter (M) is available to simplify the determination of the working hours.

ENGINE and ALTERNATOR

PLEASE REFER TO THE SPECIFIC MANUALS PROVIDED.

VENTILATION

Make certain there are no obstructions (rags, leaves or other) in the air inlet and outlet openings on the machine, alternator and motor.

ELECTRICAL PANELS

Check condition of cables and connections daily. Clean periodically using a vacuum cleaner, **DO NOT USE COMPRESSED AIR.**

DECALS AND LABELS

All warning and decals should be checked once a year and **replaced** if missing or unreadable.

STRENUOUS OPERATING CONDITIONS

Under extreme operating conditions (frequent stops and starts, dusty environment, cold weather, extended periods of no load operation, fuel with over 0.5% sulphur content) do maintenance more frequently.

BATTERY WITHOUT MAINTENANCE DO NOT OPEN THE BATTERY

The battery is charged automatically from the battery charger circuit supplied with the engine.

Check the state of the battery from the colour of the warning light which is in the upper part.

- Green colour: battery OK
- Black colour: battery to be recharged
- White colour: battery to be replaced



IMPORTANT



In the maintenance operations avoid that polluting substances, liquids, exhausted oils, etc. bring damage to people or things or can cause negative effects to surroundings, health or safety respecting completely the laws and/ or dispositions in force in the place.




NOTE

THE ENGINE PROTECTION NOT WORK WHEN THE OIL IS OF LOW QUALITY BECAUSE NOT CHARGED REGULARLY AT INTERVALS AS PRESCRIBED IN THE OWNER'S ENGINE MANUAL.



In case the machine should not be used for more than 30 days, make sure that the room in which it is stored presents a suitable shelter from heat sources, weather changes or anything which can cause rust, corrosion or damages to the machine.

 Have **qualified** personnel prepare the machine for storage.

GASOLINE ENGINE

Start the engine: It will run until it stops due to the lack of fuel.

Drain the oil from the engine sump and fill it with new oil (see page M25).

Pour about 10 cc of oil into the spark plug hole and screw the spark plug, after having rotated the crankshaft several times.

Rotate the crankshaft slowly until you feel a certain compression, then leave it.

In case the battery, for the electric start, is assembled, disconnect it.

Clean the covers and all the other parts of the machine carefully.

Protect the machine with a plastic hood and store it in a dry place.

DIESEL ENGINE

For short periods of time it is advisable, about every 10 days, to make the machine work with load for 15-30 minutes, for a correct distribution of the lubricant, to recharge the battery and to prevent any possible bloking of the injection system.

For long periods of inactivity, turn to the after sales service of the engine manufacturer.

Clean the covers and all the other parts of the machine carefully.

Protect the machine with a plastic hood and store it in a dry place.

In case of necessity for first aid and of fire prevention, see page. M2.5.



IMPORTANT



In the storage operations avoid that polluting substances, liquids, exhausted oils, etc. bring damage to people or things or can cause negative effects to surroundings, health or safety respecting completely the laws and/or dispositions in force in the place.



☞ Have **qualified** personnel disassemble the machine and dispose of the parts, including the oil, fuel, etc., in a correct manner when it is to be taken out of service.

As cust off we intend all operations to be made, at utilizer's care, at the end of the use of the machine. This comprises the dismantling of the machine, the subdivision of the several components for a further reutilization or for getting rid of them, the eventual packing and transportation of the eliminated parts up to their delivery to the store, or to the bureau encharged to the cust off or to the storage office, etc.

The several operations concerning the cust off, involve the manipulation of fluids potentially dangerous such as: lubricating oil and battery electrolyte.

The dismantling of metallic parts liable to cause injuries or wounds, must be made wearing heavy gloves and using suitable tools.

The getting rid of the various components of the machine must be made accordingly to rules in force of law a/o local rules.

**Particular attention must be paid when getting rid of:
lubricating oils, battery electrolyte, and inflammable liquids such as fuel, cooling liquid.**

The machine user is responsible for the observance of the norms concerning the environment conditions with regard to the elimination of the machine being cust off and of all its components.

In case the machine should be cust off without any previous disassembly it is however compulsory to remove:

- tank fuel
- engine lubricating oil
- cooling liquid from the engine
- battery

NOTE: MOSA is involved with custing off the machine **only** for the second hand ones, when not reparable.
This, of course, after authorization.

In case of necessity for first aid and fire prevention, see page M2.5.



IMPORTANT



In the cust-off operations avoid that polluting substances, liquids, exhausted oils, etc. bring damage to people or things or can cause negative effects to surroundings, health or safety respecting completely the laws and/or dispositions in force in the place.

The TS 610 engine driven welder is a unit which ensures the function as:

- a) a current source for arc welding
- b) a current source for the auxiliary power generation

It is meant for industrial and professional use, powered by an endothermic engine; it is composed of various main parts such as: engine, alternator, electric and electronic controls, the fairing or a protective structure.

The assembling is made on a steel structure, on which are provided elastic support which must damp the vibrations and also eliminate sounds which would produce noise.

Technical data	TS 615 VS	TS 615 VSX
ALTERNATOR		
	self-excited, self-regulated, brushless	
Type	three-phase, asynchronous	
Insulating class	H	
A. C. GENERATOR		
Three-phase generation	20 kVA / 400 V / 28.9 A	
Single-phase generation	15 kVA / 230 V / 65.2 A	
Single-phase generation	7.5 kVA / 110 V / 68.2 A	
Single-phase generation	5 kVA / 48 V / 104 A	
Frequency	50 Hz	
Service	100 %	
ENGINE		
Mark	VM	
Model	SUN 3105	
Type	4-Stroke	
Displacement	2985 cm ³	
Cylinders	2	
Output	31 kW (42 HP)	
Speed	1500 rpm	
Fuel consumption	210 g/kWh	
Cooling system	Air	
Engine oil capacity	6.9 l	
Starter	Electric	
Fuel	Diesel	
SPECIFICHE GENERALI		
Battery	12V - 100Ah	
Tank capacity	68 l	
Running time (60%)	15 h	
Protection	IP 23	
Dimensions / max. Lxwxh (mm) *	1940x850x1080	
Weight	920 Kg	940 Kg
Noise level	98 LWA (73 dB(A) - 7m)	93 LWA (68 dB(A) - 7m)

* Dimensions and weight are inclusive of all parts without wheels and towbar

OUTPUT

Declared powers at the following ambient conditions: temperature 20°C, relative humidity 30% altitude 100 m above sea level. In an **approximative** way one reduces: of 1% every 100 m altitude and of 2.5% for every 5°C above 25°C.

For possible modifications or changes to be brought on the engines, with climate conditions different from those above mentioned, please call our Assistance Authorized Centers.

ACOUSTIC POWER LEVEL

The machine respects the noise limits, expressed in sound power, given in the a.m. directives.

These limits can be used to judge the sound level produced on site.

For example: the sound power level of 100 LWA.

The sound pressure (noise produced) at 7 meters distance is about 75dBA (the limit value less 25).

To calculate the sound level at other distances use this formula:

$$dBA_x = dBA_y + 10 \log \frac{r_y^2}{r_x^2}$$

At 4 meters the noise level becomes:

$$75 \text{ dBA} + 10 \log \frac{7^2}{4^2} = 80 \text{ dBA}$$

D.C. WELDING

Welding current electronic regulation (on two scales)

20 - 200 / 20 - 550 A

Service


550 A - 35%, 500 A - 60%, 400 A - 100%

Striking voltage

60 V

Welding voltage



20 - 42 V




SIMULTANEOUS UTILIZATION FACTORS

In case **Welding** and **Generation** can be used simultaneously, however, the engine **cannot** be overloaded. The table below gives the maximum limits to be respected:

WELDING CURRENT	>350 A	270 A	200 A	140 A	0
AUXILIARY POWER	0	5 kVA	9 kVA	12 kVA	20 kVA




A: Alternator	A3: Insulation monitoring	A6: Commutator/switch
B: Wire connection unit	B3: E.A.S. connector	B6: Key switch, on/off
C: Capacitor	C3: E.A.S. PCB	C6: QEA control unit
D: G.F.I.	D3: Booster socket	D6: Connector, PAC
E: Welding PCB transformer	E3: Open circuit voltage switch	E6: Frequency rpm regulator
F: Fuse	F3: Stop push-button	F6: Arc-Force selector
G: 400V 3-phase socket	G3: Ignition coil	G6: Device starting motor
H: 230V 1phase socket	H3: Spark plug	H6: Fuel electro pump 12V c.c.
I: 110V 1-phase socket	I3: Range switch	I6: Start Local/Remote selector
L: Socket warning light	L3: Oil shut-down button	L6: Choke button
M: Hour-counter	M3: Battery charge diode	M6: Switch CC/CV
N: Voltmeter	N3: Relay	N6: Connector – wire feeder
P: Welding arc regulator	O3: Resistor	O6: 420V/110V 3-phase transformer
Q: 230V 3-phase socket	P3: Sparkler reactor	P6: Switch IDLE/RUN
R: Welding control PCB	Q3: Output power unit	Q6: Hz/V/A analogic instrument
S: Welding current ammeter	R3: Electric siren	R6: EMC filter
T: Welding current regulator	S3: E.P.4 engine protection	S6: Wire feeder supply switch
U: Current transformer	T3: Engine control PCB	T6: Wire feeder socket
V: Welding voltage voltmeter	U3: R.P.M. electronic regulator	U6: DSP chopper PCB
Z: Welding sockets	V3: PTO HI control PCB	V6: Power chopper supply PCB
X: Shunt	Z3: PTO HI 20 l/min push-button	Z6: Switch and leds PCB
W: D.C. inductor	W3: PTO HI 30 l/min push-button	W6: Hall sensor
Y: Welding diode bridge	X3: PTO HI reset push-button	X6: Water heater indicator
	Y3: PTO HI 20 l/min indicator	Y6: Battery charge indicator
A1: Arc striking resistor	A4: PTO HI 30 l/min indicator	A7: Transfer pump selector AUT-0-MAN
B1: Arc striking circuit	B4: PTO HI reset indicator	B7: Fuel transfer pump
C1: 110V D.C./48V D.C. diode bridge	C4: PTO HI 20 l/min solenoid valve	C7: „GECO“ generating set test
D1: E.P.1 engine protection	D4: PTO HI 30 l/min solenoid valve	D7: Flooting with level switches
E1: Engine stop solenoid	E4: Hydraulic oil pressure switch	E7: Voltmeter regulator
F1: Acceleration solenoid	F4: Hydraulic oil level gauge	F7: WELD/AUX switch
G1: Fuel level transmitter	G4: Preheating glow plugs	G7: Reactor, 3-phase
H1: Oil or water thermostat	H4: Preheating gearbox	H7: Switch disconnecter
I1: 48V D.C. socket	I4: Preheating indicator	I7: Solenoid stop timer
L1: Oil pressure switch	L4: R.C. filter	L7: "VODIA" connector
M1: Fuel warning light	M4: Heater with thermostat	M7: "F" EDC4 connector
N1: Battery charge warning light	N4: Choke solenoid	N7: OFF-ON-DIAGN. selector
O1: Oil pressure warning light	O4: Step relay	O7: DIAGNOSTIC push-button
P1: Fuse	P4: Circuit breaker	P7: DIAGNOSTIC indicator
Q1: Starter key	Q4: Battery charge sockets	Q7: Welding selector mode
R1: Starter motor	R4: Sensor, cooling liquid temperature	R7: R.C. net
S1: Battery	S4: Sensor, air filter clogging	S7: 230V 1-phase plug
T1: Battery charge alternator	T4: Warning light, air filter clogging	T7: V/Hz analogic instrument
U1: Battery charge voltage regulator	U4: Polarity inverter remote control	U7: Engine protection EP6
V1: Solenoid valve control PCBT	V4: Polarity inverter switch	V7: G.F.I. relay supply switch
Z1: Solenoid valve	Z4: Transformer 230/48V	Z7: Radio remote control receiver
W1: Remote control switch	W4: Diode bridge, polarity change	W7: Radio remote control transmitter
X1: Remote control and/or wire feeder socket	X4: Base current diode bridge	X7: Isometer test push-button
Y1: Remote control plug	Y4: PCB control unit, polarity inverter	Y7: Remote start socket
A2: Remote control welding regulator	A5: Base current switch	A8: Transfer fuel pump control
B2: E.P.2 engine protection	B5: Auxiliary push-button ON/OFF	B8: Ammeter selector switch
C2: Fuel level gauge	C5: Accelerator electronic control	C8:
D2: Ammeter	D5: Actuator	D8:
E2: Frequency meter	E5: Pick-up	E8:
F2: Battery charge transformer	F5: Warning light, high temperature	F8:
G2: Battery charge PCB	G5: Commutator auxiliary power	G8: Polarity inverter two way switch
H2: Voltage selector switch	H5: 24V diode bridge	H8:
I2: 48V a.c. socket	I5: Y/s commutator	I8:
L2: Thermal relay	L5: Emergency stop button	L8:
M2: Contactor	M5: Engine protection EP5	M8:
N2: G.F.I. and circuit breaker	N5: Pre-heat push-button	N8:
O2: 42V EEC socket	O5: Accelerator solenoid PCB	O8:
P2: G.F.I. resistor	P5: Oil pressure switch	P8:
Q2: T.E.P. engine protection	Q5: Water temperature switch	Q8:
R2: Solenoid control PCBT	R5: Water heater	R8:
S2: Oil level transmitter	S5: Engine connector 24 poles	S8:
T2: Engine stop push-button T.C.1	T5: Electronic GFI relais	T8:
U2: Engine start push-button T.C.1	U5: Release coil, circuit breaker	U8:
V2: 24V c.a. socket	V5: Oil pressure indicator	V8:
Z2: Thermal magnetic circuit breaker	Z5: Water temperature indicator	Z8:
W2: S.C.R. protection unit	W5: Battery voltmeter	W8:
X2: Remote control socket	X5: Contactor, polarity change	X8:
Y2: Remote control plug	Y5: Commutator/switch, series/parallel	Y8:



STARTER KEY	
ON	30 15 50
OFF	⊖ ⊕ ⊖
ST	⊖ ⊕ ⊖ ⊖


Espr. Exp.	Modifica	Data	Dis. Des.	Appr.
	26610.prg	2000/04/05	2	5
Denominazione: Engine VM SUN 3105 (ES)		Dis. n.°: 26610.S.010	Approvato: <i>[Signature]</i>	
Macchine: TS 615 VS		Disegnato: Leporace N.		
MOSCA		20090-CUSAGO (MI)-ITALY http://www.mosa.it		

La MOSA si riserva a termini di legge la proprietà del presente disegno con divieto di riprodurlo o comunicarlo a terzi senza sua autorizzazione




Esp. Exp.	Modifica	Data	Dis. Des.	Appr. Appr.
		Date	Page n°	Page n°
		Projecto:	26610.prg	3
		Project:	26610.prg	5
		Dis. n°	26610.S.020	5
		Drwg. n°:	26610.S.020	5
		Disegnatore:	Leporace N.	6
		Designer:	Leporace N.	6
		Date:	04/05/2000	
		Machine:	TS 615 VS	
		Denominazione:	AUX. (400T/230Mx2/48M) DT	
		Da Pagg. From Page	1	
		Ala Pagg. To Page	1	
		Machine:	TS 615 VS	
		Machine:	TS 615 VS	
		Disegnatore:	Leporace N.	
		Designer:	Leporace N.	
		Date:	04/05/2000	
		Dis. n°:	26610.S.020	
		Drwg. n°:	26610.S.020	
		Appr.:		
		Appr.:		

La MOSA si riserva a termini di legge la proprietà del presente disegno con divieto di riprodurlo o comunicarlo a terzi senza sua autorizzazione




Esq. Exp.	Modifica: Modification	Data Date	Dis. Disegn.	Appr. Approv.
	Denominazione: Denomination:	Projecto: Project	Page n°	di n°
	Aux. (400T/230Mx3) DT	26611.prg	3	5
	Disegnatore: Designer:	Data: Date:	Approvato: Approved:	
	Leporace N.	05/05/2000	(Signature)	
	Macchina: Machine:	26611.S.020		
	TS 615 VS			

La MOSA si riserva a termini di legge la proprietà del presente disegno con divieto di riprodurlo o comunicarlo a terzi senza sua autorizzazione





Espr. Exp.	Modifica Modification		Data Date	Dis. Des.	Appr. Appr.
MOSA	Denominazione: Denomination:	Aux. (400T/230M/110CTEX2) DT	26612.pig	3	5
20090-CUSAGO (MI)-ITALY http://www.mosa.it	Dis. n.°: Dwg. n.°:	26612.S.020	Dis. n.°: Dwg. n.°:	3	5
	Designatore: Designer:	Leporace N.	Dis. n.°: Dwg. n.°:	3	5
	Maschina: Machine:	TS 615 VS	Dis. n.°: Dwg. n.°:	3	5

La MOSA si riserva a termini di legge la proprietà del presente disegno con divieto di riprodurlo o comunicarlo a terzi senza sua autorizzazione



B	Aggiunto cavo 13A per voltmetro di saldatura.	14.02.2001	L.N.	4	5
A	Spostato filo n°13 a monte del reattore	30.03.2000	L.N.	4	5
Modifica: Denominazione: Welding Power Da Pag. From Page Alla Pag. To Page Macchina: TS 500 PS Designatore: Lepprace N. Dis. n°: 76501.S.030-B Dwg. n°: 76501.prg		Dis. n°: Dwg. n°: Dis. n°: Dwg. n°:		Approvato: Approvato:	

La MOSA si riserva a termini di legge la proprietà del presente disegno con divieto di riprodurlo o comunicarlo a terzi senza sua autorizzazione



Espr. Exp.	Modifica Modification	Data Date	Dis. Desig.	Appr. Appr.
Da Page From Page	Denominazione: Denomination:	Progetto: Project:	Dis. n.° Drive n.°	Appr. di n.° of n.°
Ala Page To Page	Welding Control BC	26610.prg	26610	5
	Macchina: Machine:	Designatore: Designer:	Dis. n.° Drive n.°	Appr. di n.° of n.°
	TS 615 VS	Leoporce N.	26610.S.040-B	5
	20090-CUSAGO (MI)-ITALY http://www.mosa.it	Date: Date:	04/05/2000	Approvato: Approved:

La MOSA si riserva a termini di legge la proprietà del presente disegno con divieto di riprodurlo o comunicarlo a terzi senza sua autorizzazione




MOSA guarantees that any request for spare parts will be satisfied.

To keep the machine in full working order, when replacement of MOSA spare parts is required, always ask for genuine parts only.


The requested data are to be found on the data plate located on the machine structure, quite visible and easy to consult. *

When ordering the spare parts, it is recommended to indicate:


- 1) * serial number
- 2) * model of welder and/or generating set
- 3) ◆ n. table
- 4) ◆ n. position
- 5) quantity

**ABBREVIATIONS AND SYMBOLS:**

- (EV) When ordering, specify the engine type and the auxiliary voltage
- (ER) Engine with recoil starter only
- (ES) Engine with electric starter only
- (VE) E.A.S version only.
- (QM) When ordering, specify the length in meters
- (VS) Special version only
- (SR) By request only




<i>Pos.</i>	<i>Rev.</i>	<i>Cod.</i>	<i>Descr.</i>	<i>Note</i>
1		'0000107509715 765007110	GRUPPO POTENZIOMETRO PRESA DI SALDATURA ROSSA	Fino a REV.0 - 05/06 Del.35/ 06 del 30/3/06
2		765007111	PRESA DI SALDATURA NERA	
3		1291250	FUSIBILE	
4		1291120	FUSIBILE	
5		107509903	PRESA	
6		307759045	PORTAFUSIBILE	
7		317809910	CONNETTORE	SR
8		305717300	VOLTMETRO	
9		102042740	CAPPUCCIO	
10		307809902	DEVIATORE	SR
11		107509702	MANOPOLA REG.CORRENTE SALDAT.	
12		836709701	POTENZIOMETRO	
13		873407107	DISGIUNTORE TERMICO 30A/250V	
14		155307107	DISGIUNTORE TERMICO 15A-250V	
15		765000166	AV1 KIT AMPEROMETRO/VOLTMETRO	SR
16		105511810	CONTAORE 230V 50Hz IP65	
17		102013290	COMMUTATORE	
19		219937036	STAFFA	
20		305027105	INTERRUTTORE DIFFERENZIALE	
21		219937130	COPERCHIO INTERRUT.DIFFERENZ.	
26		1302040	SPIA ROSSA 12V	
27		107302460	STARTER A CHIAVE	
32		101131220	PRESA DINSE	vers. 48V
33		307017240	PRESA 220V 16A	
34		366107020	PANNELLO FRONTALE	
35		105111530	PRESA CEE 32A 110V 2 POLI + T	monofase
36		107517032	COPERCHIO PRESE 48V	
37		105111520	PRESA CEE 220V MONOF. 2POLI+T	monofase
38		105111510	PRESA CEE 380V TRIFASE	trifase
<i>Pos.</i>	<i>Rev.</i>	<i>Cod.</i>	<i>Descr.</i>	<i>Note</i>
1		'0000107509715 765007110	POTENTIOMETER RED WELDING SOCKET	Up to REV.0 - 05/06 Del.35/ 06 del 30/3/06
2		765007111	BLACK WELDING SOCKET	
3		1291250	FUSE	
4		1291120	FUSE	
5		107509903	SOCKET	
6		307759045	FUSE HOLDER	
7		317809910	CONNECTOR	SR
8		305717300	VOLTMETER	
9		102042740	CAP	
10		307809902	FOUR POLE COMMUTATOR	SR
11		107509702	KNOB,WELDING CURRENT REGULAT.	
12		836709701	POTENTIOMETER	
13		873407107	CIRCUIT BREAKER 30A/250V	
14		155307107	THERMAL SWITCH 15A-250V	
15		765000166	AV1 KIT AMPEROMETER/VOLTMETER	SR
16		105511810	HOURMETER 230V 50Hz IP65	
17		102013290	COMMUTATOR	
19		219937036	BRACKET	
20		305027105	GROUNDFAULT INTERRUPTOR (GFI)	
21		219937130	COVER GFI	
26		1302040	RED WARNING LIGHT 12V	
27		107302460	STARTER KEY	
32		101131220	SOCKET	vers. 48V
33		307017240	EEC SOCKET 16A, 220V 2P+T	
34		366107020	FRONT PANEL	
35		105111530	EEC SOCKET 32A 110V 2 POLES+N	monofase
36		107517032	BLIND PLATE, SOCKETS 48V	
37		105111520	EEC SOCKET SINGLE-PH.220V 2P+	monofase
38		105111510	EEC SOCKET THREE-PHASE 380V	trifase




<i>Pos.</i>	<i>Rev. Cod.</i>	<i>Descr.</i>	<i>Note</i>
30	6050050	ANELLO SEEGER	
31	107509005	GUARNIZIONE	
53	307806010	CONVOGLIATORE GENERATORE	
54	107601470	VENTOLA COMPLETA	
56	366103020	STATORE	
57	366103030	ALBERO CON ROTORE	
58	1001050	CUSCINETTO	
70	307803101	TRAVERSA ALTERNATORE	
71	105612070	ANTIVIBRANTE (40x50)	
91	765003012	DISCO X ALBERO ROTORE	
114	107301390	ANELLO	


<i>Pos.</i>	<i>Rev. Cod.</i>	<i>Descr.</i>	<i>Note</i>
30	6050050	RING, SEEGER	
31	107509005	GASKET	
53	307806010	GENERATOR CONVEYOR	
54	107601470	FAN	
56	366103020	STATOR	
57	366103030	SHAFT WITH ROTOR	
58	1001050	BEARING	
70	307803101	ALTERNATOR BRACKET	
71	105612070	VIBRATION-DAMPER (40x50)	
91	765003012	DISC FOR SHAFT WITH ROTOR	
114	107301390	RING FIXING FAN	



- 49
- 85
- 46
- 92
- 47
- 48





- 88
- 93



- 51
- 117
- 50



- 71

- 110



- 55
- 52

- 75
- 76



- 63
- 108
- 81
- 82
- 103
- 105

- 86

- 87



- 83

- 91

- 84


- 85

- 89



- 104
- 59
- 79
- 101
- 102
- 118

- 90




Pos. Rev.Cod.**Descr.**

	'0000219869055	SOLENOIDE ARRESTO MOTORE
46	343337010	SCATOLA ELETTRICA
47	105111830	MORSETTIERA
48	209719850	SCHEDA EV/ES
49	375209800	SCHEDA CONTROLLO SALDATURA
50	366108218	PARATIA INFERIORE ALTERNATORE
51	766704010	RESISTORE DI POTENZA
52	a 364124100	REATTORE DI LIVELLO
55	102302280	GUARNIZIONE (L=MT.1) QM
59	6095030	TUBO GOMMA QM
63	366108217	PARATIA SUPERIORE ALTERNATORE
71	105612070	ANTIVIBRANTE (40x50)
75	343332070	TUBO DI SCARICO
76	343332200	MOTORE VM SUN3105 vers. MOSA
81	307402208	TUBO IN GOMMA (L=MT.1) QM
82	308102207	TUBO GOMMA (L=MT.1) QM
83	342802130	FILTRO ARIA COMPLETO
84	342802125	FASCETTA
85	105319880	BOX CONDENSATORI
86	1229870	TUBO FLESSIBILE (MT.1) QM
87	325462131	INDICAT.INTASAMENTO F.ARIA
88	305718115	PISTONE SOSTEGNO
89	b 764409150	BATTERIA 100 AH
90	107301770	STAFFA
91	a 342802132	ELEMENTO FILTRANTE
92	209719882	STAFFA BOX CONDENSATORI
93	343332040	CONVOGLIATORE ARIA MOTORE
101	219869055	ELETTROMAGNETE ARRESTO MOTORE
102	305779101	STAFFA
103	305689056	TIRANTE COMANDO ELETTROMAGNETE
104	105631146	TESTINA SNODATA
105	305772219	LEVA COMANDO GAS
108	256602228	FILTRO GASOLIO
108	342209058	TIRANTE SNODATO
110	343332035	STAFFA SUPPORTO MOTORE
117	366105300	GRUPPO RADDRIZZATORI
118	307719975	GALLEGGIANTE LIV.CARB.(FINITO)

Pos. Rev.Cod.**Descr.**

	'0000219869055	SOLENOID.STOP
46	343337010	ELECTRICAL BOX
47	105111830	TERMINAL BOARD
48	209719850	PCB EV/ES
49	375209800	WELDING CONTROL PCB
50	366108218	ALTERNATOR UNDERWALL
51	766704010	POWER RESISTANCE
52	a 364124100	REACTANCE
55	102302280	GASKET (L=MT.1) QM
59	6095030	PIPE QM
63	366108217	ALTERNATOR TOP WALL
71	105612070	VIBRATION-DAMPER (40x50)
75	343332070	EXHAUST PIPE
76	343332200	VM ENGINE SUN3105 vers. MOSA
81	307402208	RUBBER PIPE QM
82	308102207	PIPE QM
83	342802130	AIR FILTER,ASSY
84	342802125	CLAMP
85	105319880	CAPACITOR BOX
86	1229870	FLEXIBLE PIPE (MT.1) QM
87	325462131	WARNING LIGHT
88	305718115	SUPPORT, REAR COVER
89	b 764409150	BATTERY 100 AH
90	107301770	BRACKET
91	a 342802132	AIR FILTER
92	209719882	CAPACITOR BOX BRACKET
93	343332040	ENGINE CONVEYOR
101	219869055	STOP SOLENOID
102	305779101	BRACKET
103	305689056	SOLENOID TIE-ROD
104	105631146	BALL JOINT
105	305772219	LEVER, ACCELERATOR
108	256602228	FUEL FILTER
108	342209058	TIE ROD
110	343332035	ENGINE SUPPORT BRACKET
117	366105300	RECTIFIER ASSY
118	307719975	FUEL LEVEL GAUGE



Pos.	Rev. Cod.	Descr.	
23	343338100	COPERCHIO FRONTALE	
24	343338021	COPERCHIO CARENATURA	
40	343331050	BASAMENTO	
41	343338010	FIANCATA CARENATURA	
42	744508140	CERNIERA PER FIANCATA	
65	343332212	TUBO SCARICO OLIO	
66	343338123	COPERCHIO CAMERA SILEN.SCARICO	
67	102302280	GUARNIZIONE (L=MT.1)	
68	343338225	PARATIA CAMERA SILENZ.SCARICO	
69	107301890	TUBO SFIATO (L=MT.1)	QM
72	343331100	ROLL-BAR	
73	308102023	GUARNIZIONE	
74	308101262	TAPPO SCARICO SERBATOIO	
77	343332050	SILENZIATORE DI SCARICO	
95	343338015	FIANCATA SX	
96	343338035	CARENATURA POSTERIORE	
97	343339601	MANIGLIA	
98	105112270	GUARNIZIONE (L=MT.1)	QM
119	107300180	CHIUSURA COMPL.A LEVA	
120	840952053	COPERCHIETTO PARAPIOGGIA	
Pos.	Rev. Cod.	Descr.	
23	343338100	FRONT COVER	
24	343338021	FRONT COVER	
40	343331050	BASE	
41	343338010	COVER SIDE	
42	744508140	LATCH	
65	343332212	EXHAUST OIL PIPE	
66	343338123	COVER X EXHAUST BOX	
67	102302280	GASKET (L=MT.1)	
68	343338225	WALL X MUFFLER EXHAUST BOX	
69	107301890	PIPE, BREATHER (L=MT.1)	QM
72	343331100	ROLL-BAR	
73	308102023	GASKET	
74	308101262	FUEL TANK CAP	
77	343332050	EXHAUST MUFFLER	
95	343338015	SIDE COVER	
96	343338035	REAR COVER	
97	343339601	KNOB	
98	105112270	STRIP, SEALING (L=MT.1)	QM
119	107300180	LATCH	
120	840952053	WATER CAP	

Dear Customer,

You can send us the request for order of MOSA original spare parts, filling in this form, with the new spare parts tables as well as with the old ones, by FAX or mail.

Request from:..... date:..... signature:.....

Please send use us following sapre parts for the machine below:

MOSA SPARE PARTS:

model type:.....

serial nr:

--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

NEW TABLES		
table nr.	position	q.ty

OLD TABLES	
code	q.ty

ENGINE SPARE PARTS:

engine model: engine serial nr:.....

code and/or position	description and/or table	q.ty

SYNCHRONOUS ALTERNATOR SPARE PARTS:

alternator model:..... alternator serial nr:.....

code and/or position	description and/or table	q.ty

