
GE 12000 SXC/GS

0 9 0 9 359219003 - GB

USE AND MAINTENANCE MANUAL SPARE PARTS CATALOG

Main Characteristics of the unit:

- Single-phase electric power 13.5 kVA / 230 V / 50 Hz
- Diesel engine LOMBARDINI 12LD 477/2
- Asynchronous alternator brushless
- Tank of 23I with autonomy of 8.2 h
- Dimensions / weight: 1320x790x750 / 297 Kg
- Noise level at 7m 71dBA
- Prepared for automatic start unit
- Prepared for remote start/stop.



The unit is composed of: a structured base which includes a tank, an engine/alternator unit fixed on the base by 3 elastic dampers, a roll-bar, with hook for an easy and sure lifting, a chest hinged to the base for a quick access to the engine, to the air filter and to the battery. The set is completed by a frontal panel where the sockets, the protections and the measur ing instruments are mounted, all this protected by a same sized cover.







UNI EN ISO 9001: 2000

MOSA has certified its quality system according to UNI EN ISO 9001:2000 to ensure a constant, high quality of its products. This certification covers the design, production and servicing of engine driven welders and generating sets.

The certifying institute, ICIM, which is a member of the International Certification Network IQNet, awarded the official approval to MOSA after an examination of its operations at the head office and plant in Cusago (MI), Italy.

This certification is not a point of arrival but a pledge on the part of the entire company to maintain a level of quality of both its products and services which will continue to satisfy the needs of its clients, as well as to improve the transparency and the communications regarding all the company's actives in accordance with the official procedures and in harmony with the MOSA Manual of Quality.

The advantages for MOSA clients are:

- Constant quality of products and services at the high level which the client expects;
- Continuous efforts to improve the products and their performance at competitive conditions;
- Competent support in the solution of problems;
- Information and training in the correct application and use of the products to assure the security of the operator and protect the environment;
- Regular inspections by ICIM to confirm that the requirements of the company's quality system and ISO 9001 are being respected.

All these advantages are guaranteed by the CERTIFICATE OF QUALITY SYSTEM No.0192 issued by ICIM S.p.A. - Milano (Italy) - www.icim.it



M 01	QUALITY SYSTEM
M 1.01	COPYRIGHT
M 1.1	NOTES
M 1.4	CE MARK
M 1.5	TECHNICAL DATA
M 1.6	TECHNICAL DATA ENGINE DRIVEN WELDER
M 2-2.1	SYMBOLS AND SAFETY PRECAUTIONS
M 2.5	INSTALLATION AND ADVICE BEFORE USE
M 2.6	INSTALLATIONS AND ADVICE
M 2.7	INSTALLATION
M 3	PACKING
	TRANSPORT AND DISPLACEMENTS
	ASSEMBLY: CT
	SETTING-UP THE UNIT (DIESEL ENGINE)
M 21	
M 22	
M 25	
M 26	STARTING THE ENGINE (GASOLINE ENGINE)
M 27	STOPPING THE ENGINE (GASOLINE ENGINE)
M 30	CONTROLS LEGEND
M 31	CONTROLS
M 34	USE AS A WELDER
M 35	USE AS AN ENGINE STARTER
M 36	USE AS A BATTERY CHARGE
M 37	USE AS A GENERATOR
M 38	
M 39	
M 40	
M 43	
M 45	
M 46	
M 53	
	RECOMMENDED ELECTRODES
	ELECTRICAL SYSTEM LEGENDE
M 61	ELECTRICAL SYSTEM
R 1	SPARE PARTS LIST

SPARE PARTS

ACCESSORIES

.....

K...

ATTENTION

This use and maintenance manual is an important part of the machines in question.

The assistance and maintenance personel must keep said manual at disposal, as well as that for the engine and alternator (if the machine is synchronous) and all other documentation about the machine.

We advise you to pay attention to the pages concerning the security (see page M1.1).



© All rights are reserved to said Company.

It is a property logo of MOSA division of B.C.S. S.p.A. All other possible logos contained in the documentation are registered by the respective owners.

The reproduction and total or partial use, in any form and/or with any means, of the documentation is allowed to nobody without a written permission by MOSA division of B.C.S. S.p.A.

To this aim is reminded the protection of the author's right and the rights connected to the creation and design for communication, as provided by the laws in force in the matter.

In no case MOSA division of B.C.S. S.p.A. will be held responsible for any damaga, direct or indirect, in relation with the use of the given information.

MOSA division of B.C.S. S.p.A. does not take any responsibility about the shown information on firms or individuals, but keeps the right to refuse services or information publication which it judges discutible, unright or illegal.



INFORMATION

Dear Customer, We wish to thank you for having bought from MOSA a high quality set.

Our sections for Technical Service and Spare Parts will work at best to help you if it were necessary.

To this purpose we advise you, for all control and overhaul operations, to turn to the nearest authorized Service Centre, where you will obtain a prompt and specialized intervention.

- In case you do not profit on these Services and some parts are replaced, please ask and be sure that are used exclusively original MOSA parts; this to guarantee that the performances and the initial safety prescribed by the norms in force are re-established.
- The use of **non original spare parts will cancel immediately** any guarantee and Technical Service obligation from MOSA.

NOTES ABOUT THE MANUAL

Before actioning the machine please read this manual attentively. Follow the instructions contained in it, in this way you will avoid inconveniences due to negligence, mistakes or incorrect maintenance. The manual is for qualified personnel, who knows the rules: about safety and health, installation and use of sets movable as well as fixed.

You must remember that, in case you have difficulties for use or installation or others, our Technical Service is always at your disposal for explanations or interventions.

The manual for Use Maintenance and Spare Parts is an integrant part of the product. It must be kept with care during all the life of the product.

In case the machine and/or the set should be yielded to another user, this manual must also given to him.

Do not damage it, do not take parts away, do not tear pages and keep it in places protected from dampness and heat.

You must take into account that some figures contained in it want only to identify the described parts and therefore might not correspond to the machine in your possession.

INFORMATION OF GENERAL TYPE

In the envelope given together with the machine and/or set you will find: the manual for Use Maintenance and Spare Parts, the manual for use of the engine and the tools (if included in the equipment), the guarantee (in the countries where it is prescribed by law).

Our products have been designed for the use of generation for welding, electric and hydraulic system; ANY OTHER DIFFERENT USE NOT INCLUDED IN THE ONE INDICATED, relieves MOSA from the risks which could happen or, anyway, from that which was agreed when selling the machine; MOSA excludes any responsibility for damages to the machine, to the things or to persons in this case.

Our products are made in conformity with the safety norms in force, for which it is advisable to use all these devices or information so that the use does not bring damage to persons or things.

While working it is advisable to keep to the personal safety norms in force in the countries to which the product is destined (clothing, work tools, etc.).

Do not modify for any motive parts of the machine (fastenings, holes, electric or mechanical devices, others..) if not duly authorized in writing by MOSA: the responsibility coming from any potential intervention will fall on the executioner as in fact he becomes maker of the machine.

who keeps the faculty, apart the essential characteristics of the model here described and illustrated, to bring betterments and modifications to parts and accessories, without putting this manual uptodate immediately.











Any of our product is labelled with CE marking attesting its conformity to appliable directives and also the fulfillment of safety requirements of the product itself; the list of these directives is part of the declaration of conformity included in any machine standard equipment. Here below the adopted symbol:



CE marking is clearly readable and unerasable and it can be either part of the data-plate (A) or placed as a sticker near the data-plate (B)





Furthermore, on each model it is shown the noise level value; the symbol used is the following:



(B) Technical data and machine description

GE 12000 SXC/GS

M 1.5

The generating set GE 12000 is a unit which transforms the mechanical energy, generated by endothermic engine, into electric energy, through an alternator.

Is meant for industrial and professional use, powered by an endothermic engine; it is composed of various main parts such as: engine, alternator, electric and electronic controls, the fairing or a protective structure.

The assembling is made on a steel structure, on which are provided elastic support which must damp the vibrations and also eliminate sounds which would produce noise.

Technical data	GE 12000 SXC/GS			
A.C. GENERATOR				
Stand-by single-phase power	13.5 kVA (12.1 kW) / 230 V / 58.7 A			
P.R.P. single-phase power	12 kVA (10.8 kW) / 230 V / 52.5 A			
Stand-by single-phase power	13.5 kVÀ (12.1 kW) / 115 V / 117.4 A			
P.R.P. single-phase power	12 kVA (10.8 kW) / 115 V / 104.3 A			
Frequency	50 Hz			
Cos φ	0.9			
ALTERNATOR				
Туре	synchronous, single-phase, self-excited, self-regulated, brushless			
Insulating class	Н			
ENGINE				
Mark / Model	LOMBARDINI 12LD 477/2			
Type / Cooling system	Diesel 4 Stroke / air			
Cylinders/Displacement	2 / 954 cm ³			
Stand-by output	14.9 kW (20.3 HP)			
P.R.P. output	13.5 kW (18.4 HP)			
Speed	3000 rpm			
Fuel consumption (75% of P.R.P.)	2.8 l/h			
Engine oil capacity	31			
Starter	Electric			
GENERAL SPECIFICATIONS				
Tank capacity	23			
Running time (75% of P.R.P.)	8.2 h			
Protection	IP 23			
Dimensions / max. Lxwxh (mm) *	1320x790x750			
Weight on base*	297 Kg			
Measured acoustic power LwA (pressure LpA)	96 db(A)(71 db(A) @ 7m)			
Garanteed acoustic power LwA (pressure LpA)	96 db(A)(71 db(A) @ 7m)			
* Dimensions and weight are inclusive of all parts	· 			

OUTPUT

Declared power according to ISO 8528-1 (temperature 25°C, 30% relative humidity, altitude 100 m above sea level). (*Stand-by) = maximum available power for use at variable loads for a yearly number of hours limited at 500 h. No overload is

(**Prime power P.R.P.) = maximum available power for use at variable loads for a yearly illimited number of hours. The average power to be taken during a period of 24 h must not be over 80% of the P.R.P.

It's admitted overload of 10% each hour every 12 h.

In an approximative way one reduces: of 1% every 100 m altitude and of 2.5% for every 5°C above 25°C.

ACOUSTIC POWER LEVEL

ATTENTION: The concrete risk due to the machine depends on the conditions in which it is used. Therefore, it is up to the enduser and under his direct responsibility to make a correct evaluation of the same risk and to adopt specific precautions (for instance, adopting a I.P.D. -Individual Protection Device)

Acoustic Noise Level (LWA) - Measure Unit dB(A): it stands for acoustic noise released in a certain delay of time. This is not submitted to the distance of measurement.

Acoustic Pressure (Lp) - Measure Unit dB(A): it measures the pressure originated by sound waves emission. Its value changes in proportion to the distance of measurement.

The here below table shows examples of acoustic pressure (Lp) at different distances from a machine with Acoustic Noise Level (LWA) of 95 dB(A)

SYMBOLS IN THIS MANUAL

 The symbols used in this manual are designed to call your attention to important aspects of the operation of the machine as well as potential hazards and dangers for persons and things.

IMPORTANT ADVICE

- Advice to the User about the safety:
- N.B.: The information contained in the manual can be changed without notice.

Potential damages caused in relation to the use of these instructions will not be considered because these are only <u>indicative</u>.

Remember that the non observance of the indications reported by us might cause damage to persons or things.

It is understood, that local dispositions and/or laws must be respected.

WARNING



<u>Situations of danger - no harm to persons or things</u>

Do not use without protective devices provided

Removing or disabling protective devices on the machine is prohibited.

Do not use the machine if it is not in good technical condition

The machine must be in good working order before being used. Defects, especially those which regard the safety of the machine, must be repaired before using the machine.

SAFETY PRECAUTIONS



DANGEROUS

This heading warns of an <u>immediate</u> danger for persons as well for things. Not following the advice can result in serious injury or death.



WARNING

This heading warns of situations which could result in injury for persons or damage to things.



CAUTION

To this advice can appear a danger for persons as well as for things, for which can appear situations bringing material damage to things.



IMPORTANT



NOTE



ATTENTION

These headings refer to information which will assis you in the correct use of the machine and/or accessories.

SYMBOLS (for all MOSA models)



STOP - Read absolutely and be duly attentive



Read and pay due attention



GENERAL ADVICE - If the advice is not respected damage can happen to persons or things.



HIGH VOLTAGE - Attention High Voltage. There can be parts in voltage, dangerous to touch. The non observance of the advice implies life danger.



FIRE - Danger of flame or fire. If the advice is not respected fires can happen.



HEAT - Hot surfaces. If the advice is not respected burns or damage to things can be caused.



EXPLOSION - Explosive material or danger of explosion. in general. If the advice is not respected there can be explosions.



WATER - Danger of shortcircuit. If the advice is not respected fires or damage to persons can be caused.



SMOKING - The cigarette can cause fire or explosion. If the advice is not respected fires or explosions can be caused.



ACIDS - Danger of corrosion. If the advice is not respected the acids can cause corrosions with damage to persons or things.



WRENCH - Use of the tools. If the advice is not respected damage can be caused to things and even to persons.



PRESSION - Danger of burns caused by the expulsion of hot liquids under pressure.

PROHIBITIONS No harm for persons

Use only with safety clothing -



It is compulsory to use the personal protection means given in equipment.

Use only with safety clothing -



It is compulsory to use the personal protection means given in equipment.

Use only with safety protections -



It is a must to use protection means suitable for the different welding works.

Use with only safety material -



It is prohibited to use water to quench fires on the electric machines.

Use only with non inserted voltage -



It is prohibited to make interventions before having disinserted the voltage.

No smoking -



It is prohibited to smoke while filling the tank with fuel.

No welding -



It is forbidden to weld in rooms containing explosive gases.

ADVICE No harm for persons and things

Use only with safety tools, adapted to the specific use -

It is advisable to use tools adapted to the various maintenance works.

Use only with safety protections, specifically suitable

It is advisable to use protections suitable for the different welding works.

Use only with safety protections -



It is advisable to use protections suitable for the different daily checking works.

Use only with safety protections -



It is advisable to use all protections while shifting the machine.

Use only with safety protections -



It is advisable to use protections suitable for the different daily checking works.and/or of maintenance.





INSTALLATION AND ADVICE BEFORE USE

GE_, MS_, TS_

M 2-5

The installation and the general advice concerning the operations, are finalized to the correct use of the machine, in the place where it is used as generator group and/or welder.

	Stop engine when fueling		Do not touch electric devices if you
	Do not smoke, avoid flames, sparks or electric tools when fueling.		are barefoot or with wet clothes.
	Unscrew the cap slowly to let out the fuel vapours.	2	Always keep off leaning surfaces
Ē	Slowly unscrew the cooling liquid tap if the liquid must be topped up.	BOAI	during work operations
ENGIN	The vapor and the heated cooling liquid under pressure can burn face, eyes, skin.	KING	Static electricity can demage the parts on the circuit.
	Do not fill tank completely.	回	
	Wipe up spilled fuel before starting engine.	ᇙ	
	Shut off fuel of tank when moving machine (where it is assembled).		An electric shock can kill
	Avoid spilling fuel on hot engine.		
	Sparks may cause the explosion of battery vapours		



FIRST AID. In case the operator shold be sprayed by accident, from corrosive liquids a/o hot toxic gas or whatever event which may cause serious injuries or death, predispose the first aid in accordance with the ruling labour accident standards or of local instructions.

Skin contact	Wash with water and soap
Eyes contact	Irrigate with plenty of water, if the irritation persists contact a specialist
0	Do not induce vomit as to avoid the intake of vomit into the lungs, send for a doctor
Suction of liquids from	If you suppose that vomit has entered the lungs (as in case of spontaneous vomit) take the
lungs	subject to the hospital with the utmost urgency
Inhalation	In case of exposure to high concentration of vapours take immediately to a non polluted zone
	the person involved



FIRE PREVENTION. In case the working zone, for whatsoever cause goes on fire with flames liable to cause severe wounds or death, follow the first aid as described by the ruling norms or local ones.

EXTINCTION MEANS					
Appropriated	Carbonate anhydride (or carbon dioxyde) powder, foam, nebulized water				
Not to be used	to be used Avoid the use of water jets				
Other indications	Cover eventual shedding not on fire with foam or sand, use water jets to cool off the surfaces close to the fire				
Particular protection	Wear an autorespiratory mask when heavy smoke is present				
Useful warnings	Avoid, by appropriate means to have oil sprays over metallic hot surfaces or over electric contacts (switches,plugs,etc.). In case of oil sprinkling from pressure circuits, keep in mind that the inflamability point is very low.				








INSTALLATION AND ADVICE BEFORE USE

GASOLINE ENGINES

Use in open space, air swept or vent exhaust gases, which contain the deathly carbone oxyde, far from the work area.


DIESEL ENGINES

■ Use in open space, air swept or vent exhaust gases far from the work area.




POSITION

Place the machine on a level surface at a distance of at least 1,5 m from buildings or other plants.



Maximum leaning of the machine (in case of dislevel)

Check that the air gets changed completely and the hot air sent out does not come back inside the set so as to cause a dangerous increase of the temperature.



Make sure that the machine does not move during the work: **block** it possibly with tools and/or devices made to this purpose.

MOVES OF THE MACHINE

At any move check that the engine is **off**, that there are no connections with cables which impede the moves.

PLACE OF THE MACHINE




ATTENTION

For a safer use from the operator **DO NOT** fit the machine in locations with high risk of flood.




Please do not use the machine in weather conditions which are beyond IP protection shown both in the data plate and on page named "technical data" in this same manual.





D Luftzirkulation
E Instalación


GE 12000 SXC/GS GE 14000 SXC/GS M 2.7





A.

NOTE




Be sure that the lifting devices are: correctly mounted, adequate for the weight of the machine with it's packaging, and conforms to local rules and regulations.


When receiving the goods make sure that the product has not suffered damage during the transport, that there has not been rough handling or taking away of parts contained inside the packing or in the set.

In case you find damages, rough handling or absence of parts (envelopes, manuals, etc.), we advise you to inform immediately our Technical Service.



For eliminating the packing materials, the User must keep to the norms in force in his country.





- 1) Take the machine (C) out of the shipment packing. Take out of the envelope (A) the user's manual (B).
- 2) Read: the user's manual (B), the plates fixed on the machine, the data plate.





NOTE

In case you should transport or move the machine, keep to the instructions as per the figures.


Make the transportation when the machine has **no** petrol in its tank, **no** oil in the engine and and electrolyte in the battery.

Be sure that the lifting devices are: correctly mounted, adequate for the weight of the machine with it's packaging, and conform to local rules and regulations.

Only authorized persons involved in the transport of the machine should be in the area of movement.

DO NOT LOAD OTHER PARTS WHICH CAN MODIFY WEIGHT AND BARICENTER POSITION. IT IS STRICTLY FORBIDDEN TO DRAG THE MACHINE MANUALLY OR TOW IT BY ANY VEHICLE (model with no CTL accessory).

If you did not keep to the instructions, you could damage the structure of the machine.







1.0-01/01

@ MOSA

NOTE

In case you should transport or move the machine, keep to the instructions as per the figures.


Make the transportation when the machine has \underline{no} petrol in its tank, \underline{no} oil in the engine and and electrolyte in the battery.

Be sure that the lifting devices are: correctly mounted, adequate for the weight of the machine with it's packaging, and conform to local rules and regulations.

Only authorized persons involved in the transport of the machine should be in the area of movement.

<u>DO NOT</u> LOAD OTHER PARTS WHICH CAN MODIFY WEIGHT AND BARICENTER POSITION. IT IS STRICTLY <u>FORBIDDEN</u> TO DRAG THE MACHINE MANUALLY OR TOW IT BY ANY VEHICLE (model with no CTM accessory).

If you did not keep to the instructions, you could damage the structure of the machine.





ATTENTION


The CTL or CTM accessory cannot be removed from the machine and used separately (actioned manually or following vehicles) for the transport of loads or anyway for used different from the machine movements.

TRAILERS

The machines provided for assembling the CTL accessory (slow towing trolley) can be towed up to a <u>maximum</u> speed of <u>40 Kms/hour</u> on asphalted surfaces.

Towing on public roads or turnpikes of any type **IS EXCLUDED**, because **not** in possesion of the requirements by national and foreign traffic norms.

Nota: Lift the machine and assemble the parts as shown in the drawing




For assembling the generating set on the trolley CTL300 please keep to following instructions:

- 1) Lift the generating set (by means of suitable hook).
- Slightly fix the jaw (3) of the parking foot to the bar with the M10x20 screws, the M10 nuts and the washers (so as to let the foot sprag go through.
- 3) Split (unscrewing them) the two parts of the foot (4S-4I) to be able later to assemble them on the jaw.
- 4) Introduce into the jaw (3) the upper part (4S) of the foot and screw again the lower part (4I), then tighten the screws (4V) of the jaw to the towbar and block momentaneously with the lever (4L) the whole foot.
- 5) Assemble on the machine the towbar (5) complete of foot with the M10x20 screws, nuts and washers (see fig. page M6.4).
- 6) Assemble the axle (7) to the base of the machine (see fig. page M6.4) with the M 8x20 screws and relative washers (two per part) so that their supports coincide.
- 7) Introduce on the axle the antidust ring (7A) with folded edges turned toward the machine.
- 8) Insert the wheel (9) on the axle paying attention to the spacer (8D) which is between the two bearings, then insert the selfblocking nut (8A) and finally assemble the shutting cap (8C).
- 9) Pump the tyre (9) bringing the pressure to three atms.
- 10)- Lower the machine to the ground and place the parking foot definitively (regulating at the best height).



ATTENTION

Do not substitute the original tires with other types.





BATTERY WITHOUT MAINTENANCE



Connect the cable + (positive) to the pole + (positive) of the battery (after having taken away the protection), by properly tightening the clamp.

Check the state of the battery

from the colour of the warning light which is in the upper part.

- Green colour: battery OK

- Black colour: battery to be recharged - White colour: battery to be replaced DO NOT OPEN THE BATTERY.



LUBRICANT

RECOMMENDED OIL

MOSA recommends selecting AGIP engine oil. Refer to the label on the motor for the recommended products.



Please refer to the motor operating manual for the recommended viscosity.

REFUELLING AND CONTROL:

Carry out refuelling and controls with motor at level position.

- 1. Remove the oil-fill tap (24)
- 2. Pour oil and replace the tap
- 3. Check the oil level using the dipstick (23); the oil level must be comprised between the minimum and maximum indicators.



ATTENTION

It is dangerous to fill the motor with too much oil, as its combustion can provoke a sudden increase in rotation speed.



DRY AIR FILTER

Check that the dry air filter is correctly installed and that there are no leaks around the filter which could lead to infiltrations of non-filtered air to the inside of the motor.



OIL BATH AIR FILTER

Fill the air filter using the same engine oil up to the level indicated on the filter.



FUEL



ATTENTION



Do not smoke or use open flames during refuelling operations, in order to avoid explosions or fire hazards.

Fuel fumes are highly toxic; carry out operations outdoors only, or in a wellventilated environment.



Avoid accidentally spilling fuel. Clean any eventual leaks before starting up motor.

Refill the tank with good quality diesel fuel, such as automobile type diesel fuel, for example.

For further details on the type of diesel fuel to use, see the motor operating manual supplied.

Do not fill the tank completely; leave a space of approx. 10 mm between the fuel level and the wall of the tank to allow for expansion.

In rigid environmental temperature conditions, use special winterized diesel fuels or specific additives in order to avoid the formation of paraffin.



GROUNDING CONNECTION

The grounding connection to an earthed installation is obligatory for all models equipped with a differential switch (circuit breaker). In these groups the generator star point is generally connected to the machine's earthing; by employing the TN or TT distribution system, the differential switch guarantees protection against indirect contacts.

In the case of powering complex installations requiring or employing additional electrical protection devices, the coordination between the protection devices must be verified.

For the grounding connection, use the terminal (12); comply to local and/or current regulations in force for electrical installations and safety.





check before each start-up









START-UP FROM FRONT PANEL

- 1. Position the LOCAL START / REMOTE START (I6) selector on LOCAL START (only EAS version);
- 2. check to ensure the emergency stop button is unblocked (where it is assembled);
- 3. make sure the load plugs are disconnected or



the thermal-magnetic switch (Z2) is not inserted (intervention/ insertion lever facing down), so as to ensure the motor's start-up without any loads inserted;



- 4. Make sure that the accelerator lever or the switch (16) is at its minimum setting;
- **5**. Insert the electric protection device (D-Z2-N2) lever towards above and, where mounted, check the isolation monitor (A3) see page M37 -
- 6. Introduce the key (Q1), turn it clockwise completely, leaving it as soon as the engine starts and/or the push button (32) (models

without key) leaving it as soon as the

engine starts.

NB.: for safety reason the key must be kept by qualified personel.

In case of unsuccessful start-up, do not insist for longer than 5 seconds. Wait 10 -15 seconds before attempting another startup.

REMOTE START (Only EAS version)

The unit can also be started by means of the remote TCM control device, or through the EAS automatic intervention panel.

- 1. Position the LOCAL START / REMOTE START (I6) selector on REMOTE START;
- 2. check that the emergency stop button is unblocked (where it is assembled):
- 3. Connect to the EAS (B3) connector the TCM or the EAS panel.
- 4. Start-up with EAS

The EAS panel automatically sees to controlling the motor's start-up cycle.

- The preheating time on the EAS panel is normally set at 10 seconds; for low temperatures, it may be necessary to increase it to 15 or 20 seconds to ensure start-up.
 - Contact an authorized Service Centre or our Technical Service Department directly to modify this setting.
- 5. Start-up with TCM

Perform the same procedure for start-up from the front panel using the TCM start-up key (Q1).

Temperature	Time
≤- 20° C	5 min.
to - 20° C from -10°C	2 min.
to - 10° C from -5°C	1 min.
≥ 5° C	20 sec.

- 7. Once the engine has started leave it running at a reduced speed for some minutes.
- 8. Accelerate the engine at max., set lever on maximum position and then take up load.



CAUTION

RUNNING-IN

During the first 50 hours of operation, do not use more than 60% of the maximum output power of the unit and check the oil level frequently, in any case please stick to the rules given in the engine use manual.

SHUT-DOWN FROM FRONT PANEL

For shutdown under normal conditions, proceed as follows:

- Position the LOCAL START /REMOTE START (I6) selector on LOCAL START; (only EAS version);
- 2. cut off power to all utilities by opening the load



switch or opening the thermalmagnetic switch (Z2) (input lever in downward position);

- **3**. Turn and push the accelerator lever (16) in minimum position;
- 4. allow the motor to run without any load for a few minutes:
- **5.** turn the key (Q1) to the OFF position.



NB.: as a safety measure the start-up key must be entrusted to qualified personnel.

SHUT-DOWN FROM REMOTE

(only EAS version)



WARNING

The start-up selector (I6) LOCAL START / RE-MOTE START enables the start-up and stop controls for the selected position.

From the REMOTE START position, the startup key on the front panel is completely disabled; to stop the generator, use the controls on the TCM or EAS panel.

The unit can also be shut down by means of the TCM remote control or EAS panel.

- 1. Check that the EAS (B3) connector is connected to the cable from the TCM or EAS panel.
- 2. Verify or position the LOCAL START / REMOT START (I6) selector on REMOTE START.
- 3. SHUT-DOWN with EAS

The EAS panel automatically sees to controlling the motor shutdown cycle, including the cooling cycle.

4. SHUT-DOWN with TCM


Follow the same shutdown procedure described for shutdown from the front panel using the TCM key (Q1).

EMERGENCY SHUTDOWN

Turn the key (Q1) to the OFF position.

E Mandos





Pos.	Descrizione	Description	Description	Descripción
15	Presa di corrente in c.a.	A.C. socket	Prises de courant en c.a.	Toma de corriente en c.a
16	Comando acceler./puls. marcia	Accelerator lever	Commande accélér./bouton marche	Mando de acel./pulsador marcha
22	Filtro aria motore	Engine air filter	Filtre air moteur	Filtro aire motor
23	Asta livello olio motore	Oil level dipstick	Jauge niveau huile moteur	Aguja nivel aceite motor
24	Tappo caricamento olio motore	Engine oil reservoir cap	Bouchon remplissage huile moteur	Tapón llenado aceite motor
26	Tappo serbatoio	Fuel tank cap	Bouchon réservoir	Tapón depósito
28	Comando stop	Stop control	Commande stop	Mando stop
59A	Protezione termica motore	Engine thermal switch	Protection thermique moteur	Protección térmica motor
59B	Protezione termica corrente aux	Aux current thermal switch	Protection thermique courant aux.	Protección térmica corr. aux
В3	Connettore EAS	EAS connector	Connecteur EAS	Conector E.A.S.
D	Interruttore differenziale (30mA)	G.F.I.	Interrupteur différentiel	Interruptor diferencial (30 mA)
F5	Spia alta temperatura	Warning light, high temperature	Voyant haute température	Piloto alta temperatura
16	Selettore Start Local/Remote	Start Local/Remote selector	Selecteur Start Local/Remote	Selector Start Local/Remote
M	Contaore	Hour counter	Compte-heures	Cuentahoras
M1	Spia livello combustibile	Warning level light	Voyant niveau carburant	Piloto nivel combustible
N1	Spia carica batteria	Battery charge warning light	Voyant charge batterie	Piloto carga bateria
01	Spia lumin. press. olio/oil alert	Oil press.warning light/oil alert	Voyant lumin. press.huile / oil alert	Indic.lum.pres. aceite/oil alert
Q1	Chiave di avviamento	Starter key	Clé de démarrage	Llave de arranque
T7	Strumento analogico V/Hz	Analogic instrument V/Hz	Instrument analogique	Instrumento analógico V/Hz
Z2	Interruttore magnetotermico	Thermal-magnetic circ.breaker	Interrupteur magnétothermique	Interruptor magnetotérmico



WARNING

It is absolutely forbidden to connect the unit to the public mains and/or another electrical power source.



Access forbidden to area adjacent to electricity-generating group for all non-authorized personnel.

The electricity-generating groups are to be considered electrical energy producing stations.

The dangers of electrical energy must be considered together with those related to the presence of chemical substances (fuels, oils, etc.), rotating parts and waste products (fumes, discharge gases, heat, etc.).

GENERATION IN AC (ALTERNATING CURRENT)

Before each work session check the efficiency of the ground connection for the electricity-generating group if the distribution system adopted requires it, such as, for example, the TT and TN systems.

Check that the electrical specifications for the units to be powered - voltage, power, frequency - are compatible with those of the generator. Values that are too high or too low for voltage and frequency can damage electrical equipment irreparably.

In some cases, for the powering of three-phase loads, it is necessary to ensure that the cyclic direction of the phases corresponds to the installation's requirements.

Connect the electric devices to be powered to the AC sockets, using suitable plugs and cables in prime condition.

Before starting up the group, make certain no dangerous situations exist on the installation to be powered. Check that the thermal-magnetic switch (Z2) is in the OFF position (input lever in downward position).

Start up the electricity-generating group, positioning the thermal-magnetic switch (Z2) and differential switch (D) to ON (input lever in upward position).

Before powering on the utilities, check that the voltmeter (N) and frequency meter (E2) indicate nominal values; in addition, check on the voltmeter change-over switch (H2) (where it is assembled) that the three line voltages are the same.

Is In the absence of a load, the values for voltage and frequency can be greater than their nominal values. See sections on VOLTAGE and FREQUENCY.

OPERATING CONDITIONS

POWER

The electrical power expressed in kVA on an electricity-generating group is the available output power to the reference environmental conditions and nominal values for: voltage, frequency, power factors ($\cos \varphi$).

There are various types of power: PRIME POWER (PRP), STAND-BY POWER established by ISO 8528-1 and 3046/1 Norms, and their definitions are listed in the manual's TECHNICAL SPECIFICATIONS page.

During the use of the electricity-generating group **NEVER EXCEED** the power indications, paying careful attention when several loads are powered simultaneously.

VOLTAGE GENERATORS WITH COMPOUND SETTING.

In these types of generators, the no-load voltage is generally greater than 3–5% with respect to its nominal value; f.e. for nominal voltage, threephase 400Vac or singlephase 230Vac, the no-load voltage can be comprised between 410-420V (threephase) and 235-245V (singlephase). The precision of the load voltage is maintained within $\pm 5\%$ with balanced loads and with a rotation speed variation of 4%. Particularly, with resistive loads (cos ϕ = 1), a voltage over-elevation occurs which, with the machine cold and at full load, can even attain +10 %, a value which in any case is halved after the first 10-15 minutes of operation.

The insertion and release of the full load, under constant rotation speed, provokes a transitory voltage variation that is less than 10%; the voltage returns to its nominal value within 0.1 seconds.

GENERATORS WITH ELECTRONIC SETTING (A.V.R.).

In these types of generators, the voltage precision is maintained within $\pm 1,5\%$, with speed variations comprised from -10% to +30%, and with balanced loads. The voltage is the same both with no-load and with load; the insertion and release of the full load provokes a transitory voltage variation that is less than 15%; the voltage returns to its nominal value within 0.2–0.3 seconds.

FREQUENCY

The frequency is a parameter that is directly dependent on the motor's rotation speed. Depending on the type of alternator, 2 or 4 pole, we will have a frequency of 50/60 Hz with a rotation speed of 3000/3600 or 1500/1800 revolutions per minute.

The frequency, and therefore the number of motor revolutions, is maintained constant by the motor's speed regulation system.

Generally, this regulator is of a mechanical type and presents a droop from no-load to nominal load which is less than 5 % (static or droop), while under static conditions precision is maintained within ±1%. Therefore, for generators at 50Hz the no-load frequency can be 52–52.5 Hz, while for generators at 60Hz the no-load frequency can be 62.5-63Hz.



GE_ Diesel engine M 37.1

In some motors or for special requirements the speed regulator is electronic; in these cases, precision under static operating conditions attains $\pm 0.25\%$, and the frequency is maintained constant in operation from noload to load (isochronal operation).

POWER FACTOR - COS φ

The power factor is a value which depends on the load's electrical specifications; it indicates the ratio between the Active Power (kW) and Apparent Power (kVA). The apparent power is the total power necessary for the load, achieved from the sum of the active power supplied by the motor (after the alternator has transformed the mechanical power into electrical power), and the Reactive Power (kVAR) supplied by the alternator. The nominal value for the power factor is $\cos \varphi = 0.8$; for different values comprised between 0.8 and 1 it is important during usage not to exceed the declared active power (kW), so as to not overload the electricity-generating group motor; the apparent power (kVA) will diminish proportionally to the increase of $\cos \varphi$.

For $\cos \varphi$ values of less than 0.8 the alternator must be downgraded, since at equal apparent power the alternator should supply a greater reactive power. For reduction coefficients, contact the Technical Service Department.

START-UP OF ASYNCHRONOUS MOTORS

The start-up of asynchronous motors from an electricity-generating group can prove critical because of high start-up currents the asynchronous motor requires (I start-up = up to 8 times the nominal current In.). The start-up current must not exceed the alternator's admissible overload current for brief periods, generally in the order of 250–300% for 10–15 seconds.

To avoid a group oversize, we recommend following these precautionary measures:

- in the case of a start-up of several motors, subdivide the motors into groups and set up their start-up at intervals of 30–60 seconds.
- when the operating machine coupled to the motor allows it, see to a start-up with reduced voltage, star point/triangle start-up or with autotransformer, or use a soft-start system.

In all cases, when the user circuit requires the start-up of an asynchronous motor, it is necessary to check that there are no utilities inserted into the installation, which in the case of a voltage droop can cause more or less serious disservices (opening of contact points, temporary lack of power to control and command systems, etc.).

SINGLE-PHASE LOADS

Power to monophase utilities by means of three-phase generators requires some operating limitations.

 In single-phase operation, the declared voltage tolerance can no longer be maintained by the regulator (compound or electronic regulator), since the system becomes highly unbalanced. The voltage variation on the phases not affected by the power can prove dangerous; we recommend sectioning the other loads eventually connected.


- The maximum power which can be drawn between Neutral and Phase (start connection) is generally 1/3 of the nominal three-phase power; some types of alternators even allow for 40%. Between two Phases (triangle connection) the maximum power cannot exceed 2/3 of the declared three-phase power.
- In electricity-generating groups equipped with monophase sockets, use these sockets for connecting the loads. In other cases, always use the "R" phase and Neutral.

ELECTRIC PROTECTIONS

THERMAL-MAGNETIC SWITCH

The electricity-generating group is protected against short-circuits and against overloads by a thermal-magnetic switch (Z2) situated upstream from the installation. Operating currents, both thermic and magnetic, can be fixed or adjustable in relation to the switch model.


In models with adjustable operating current **do not modify** the settings, since doing so can compromise the installation's protection or the electricity-generating



feature against overloads is not instantaneous, but follows a current overload/time outline; the greater the overload the less the intervention.

Furthermore, keep in mind that the nominal operating current refers to an operating temperature of 30°C, so that each variation of 10°C roughly corresponds to a

variation of 5% on the value of nominal current.



In case of an intervention on the part of the thermal magnetic protection device,

check that the total absorption does not exceed the electricity-generating group's nominal current.




DIFFERENTIAL SWITCH

The differential switch or differential relay guarantee protection against indirect contacts due to malfunction currents towards the ground. When the device detects a malfunction current that is higher than the nominal current

or the set current, it intervenes by cutting off







power to the circuit connected.

In the case of an intervention by the differential switch, check that there are no sheathing defects in the installation: connection cables, sockets and plugs, utilities connected.

Before each work session, check the operation of the differential protection device by pressing the test key. The electricity-generating group must be in operation, and the lever on the differential switch must be in the ON position.

THERMIC PROTECTION

Generally present to protect against overloads on an individual power socket c.a.

When the nominal operating current has been exceeded, the protection device intervenes by cutting off power to the socket.

The intervention of the protection device against overloads is not instantaneous, but follows a current overload/time outline; the greater the overload the less the intervention.

In case of an intervention, check that the current absorbed by the load does not exceed the protection's nominal operating current.

Allow the protection to cool off for a few minutes before resetting by pressing the central pole.









\triangle

ATTENTION

Do not keep the central pole on the thermic protection forcefully pressed to prevent its intervention.

USAGE WITH EAS AUTOMATIC START-UP PANEL

The electricity-generating group in combination with the EAS automatic start-up panel forms a unit for distributing electrical energy within a few seconds of a power failure from the commercial electrical power line.

Below is some general operating information; refer to the automatic panel's specific manual for details on installation, command, control and signalling operations.

- Perform connections on the installation in safety conditions. Position the automatic panel in RESET or LOCKED mode.
- ☐ Carry out the first start-up in MANUAL mode.
 Check that the generator's LOCAL START / REMOTE
 START switch (I6) is in the REMOTE position.
 Check that the generator switches are enabled (input lever in upward position).

Position the EAS panel in manual mode by pressing MAN. key, and only after having checked that there are no dangerous situations, press the START key to start the electricity-generating group.

□ During the operation of the generator, all controls and signals from both the automatic panel and group are enabled; it is therefore possible to control its operation from both positions.

In case of an alarm with a shutdown of the motor (low pressure, high temperature, etc.), the automatic panel will indicate the malfunction that has caused the stoppage, while the generator's front panel will be disabled and will no longer supply any information.



A

MAKE SURE

- → When the TCM 22-40 is used, it is not possible to connect the E.A.S automatic intervention unit.
- → The selector LOCAL START/REMOTE START (I6) of the generating set must be switched on REMOTE START.

USE OF THE REMOTE CONTROL TCM 22


The coupling of the TCM 22 with the generating set, ready for remot starting, permits to work far from the set itself.

The remote control is connected to the front plate, and/or rear plate, with a multiple connector.

The TCM 22 assures the following fonctions:

- starting (starting key Q1)
- acceleration (selector 16)
- stop (starting key Q1)
- indication of oil low pressure (warning light O1)

To stop the set, move the accelerator lever (16) to the minimum position, them turn the key to "OFF" position.



USE OF THE REMOTE CONTROL TCM 40


The coupling of the TCM 40 with the generating set, ready for remot starting, permits to work far from the set itself.

The remote control is connected to the front plate, and/or rear plate, with a multiple connector.

The TCM 40 assures the following fonctions:

- Preheat (starting key Q1). Use only for the models that need such function:
- starting (starting key Q1)
- stop (starting key Q1)
- indication of oil low pressure (warning light O1)

To stop the set turn the key to the position. "OFF".



ENGINE PROTECTION (ES - EV)

The devices ES or EV ensure the protection of the engine in case of low oil pressure or engine high temperature.


The system consist of electronic card of control and check, and of an engine stop device: solenoid (ElettroStop), electrovalve (ElettroValvola)

The device enter in operation when the engine starts and, in case of low oil pressure and high temperature, will stop the machine and show the cause of the stop with the warning light of high temperature or low oil pressure.

In case of low oil pressure, check the level and if it is correct, call the Service Station. In case of high temperature, make sure that there are no leaves and/or pieces of material obstructing the air ducts.

N.B.: if the unit is used as a generator in hot climates and with loads near to the maximum, the protection device can be triggered off, please reduce the load of the engine.

Once the cause of the problem is removed, to reset the protection, it is enough to report the ignition key (Q1) on "OFF" position and start the engine again.





NOTE

THE ENGINE PROTECTIONS DO NOT WORK WHEN THE OIL IS OF LOW QUALITY BECAUSE NOT CHANGED REGULARLY AT INTERVALS AS PRESCRIBED IN THE OWNER'S ENGINE MANUAL.



GE Diesel engine M 40.2

Problem Possible cause			Solution	
		ENGINE		
The motor does not start up	1) 2) 3)	Start-up switch (I6) (where it is assembled) in incorrect position Emergency button (L5) pressed Preheating (where it is assembled)	1) 2) 3)	Check position Unblock Lacking or insufficient preheating phase for sparkplugs.
	4) 5)	Engine control unit or starting key faulty. Battery low	4) 5)	Malfunction in circuit: repair. Replace Recharge or replace.
	6)	Battery cable terminals loose or	6)	Check the battery charge circuit on motor and automatic panel. Tighten and clean. Replace if
	0)	corroded	0)	corroded.
	7) 8) 9)	Start-up motor defective No fuel or air in feed circuit Malfunction on feed circuit: defective pump, injector blocked, etc.	7) 8) 9)	Repair or replace. Refill tank, un-aerate the circuit. Ask for intervention of Service Department.
	11) 12)	Air filter or fuel filter clogged Air in the gasoil filter. Motor stopping device defective Malfunction on electrical power circuit on generator control panel	11) 12)	Clean or replace Take the air out filling the filter with gasoil. Replace. Check and repair.
The motor does not accelerate. Inconstant speed.	1) 2)	Air filter or fuel filter clogged. Malfunction on feed circuit: defective pump, injector blocked, etc.		Clean or replace. Ask for intervention of Service Department.
	3) 4)	Oil level too high. Motor speed regulator defective.	3) 4)	Eliminate excess oil. Ask for intervention of Service Department
Black smoke	1) 2)	Air filter clogged. Overload.	1) 2)	Clean or replace Check the load connected and diminish.
	3)	Injectors defective. Injection pump requires calibration.	3)	Ask for intervention of Service Department.
White smoke	1) 2)	Oil level too high. Motor cold or in prolonged operation with little or no load.	1) 2)	Eliminate excess oil. Insert load only with motor sufficiently hot
	3)	Segments and/or cylinders worn out.	3)	Ask for intervention of Service Department.
Too little power provided by motor.	1) 2)	Air filter clogged. Insufficient fuel distribution, impurities or water in feed circuit.	1) 2)	Clean or replace. Check the feed circuit, clean and refill once again.
	3)	Injectors dirty or defective.	3)	Ask for intervention of Service Department.
Low oil pressure	1)	Oil level insufficient	1)	Reset level. Check for leaks.
	2)	Air filter clogged.	2)	Replace filter.
	3)4)	Oil pump defective. Alarm malfunction.	3) 4)	Ask for intervention of Service Department. Check the sensor and electrical
				circuit.
High temperature	1)	Overload Insufficient ventilation.	1) 2)	Check the load connected and diminish. Check the cooling vent and relative
	3)	Insufficient coolant liquid (Only for water cooled motors)	,	transmission belts Restore level. Check for leaks or breakage in the entire cooling circuit, pipes, couplings, etc.



GE Diesel engine M 40.2.1

Problem		Possible cause	Solution	
		ENGINE		
	4)	Water radiator or oil clogged (where it is assembled)	4)	Clean cooling fins on radiator
	5)	Water circulating pump defective (Only for water cooled motors)	5)	Ask for intervention of Service Department
	6)	Injectors defective. Injection pump requires calibration	6)	
	7)	Alarm malfunction	7)	Check the sensor and electrical circuit
		GENERATOR		Circuit
Absence of output voltage	1)	Voltage switch in position 0	1)	Check position
g	2)	Voltage switch faulty	2)	Check connections and working of the switch, repair or replace
	3)	Protection tripped due to overload	3)	Check the load connected and diminish
	4)	Differential protection device tripped. (Differential switch, differential relay)	4)	Check on the entire installation: cables, connections, utilities connected have no defective sheathing which may cause incorrect currents to ground
	5) 6)	Protection devices defective Alternator not sparked	5) 6)	Replace Carry out external spark test as indicated in alternator manual. Ask for intervention of Service Department
	7)	Alternator defective	7)	Check winding, diodes, etc. on alternator (Refer to alternator manual) Repair or replace. Ask for intervention of Service Department
No-load voltage too low or	1)	Incorrect motor running speed	1)	Regulate speed to its nominal no-
too high	2)	Voltage regulating device (where it is assembled) defective or requires	2)	load value Adjust regulator device as indicated in alternator manual, or replace
	3)	calibration Alternator defective	3)	Check winding, diodes, etc. on alternator (Refer to alternator manual) Repair or replace Ask for intervention of Service Department
Corrected no-load voltage	1)	Incorrect motor running speed due to	1)	Check the load connected and
too low with load	2) 3)	overload Load with cos φ less than 0.8 Alternator defective	2) 3)	diminish Reduce or rephase load Check winding, diodes, etc. on alternator (Refer to alternator manual) Repair or replace
				Ask for intervention of Service Department
Unstable tension	1)	Contacts malfunctioning	1)	Check electrical connections and tighten
	2)	Irregular rotation of motor	2)	Ask for intervention of Service Department Check winding, diodes, etc. on
	3)	Alternator defective	3)	Check winding, diodes, etc. on alternator (Refer to alternator manual) Repair or replace Ask for intervention of Service Department





WARNING



• Have **qualified** personnel do maintenance and troubleshooting work.

- Stop the engine before doing any work inside the machine. If for any reason the machine must be operated while working inside, <u>pay</u> <u>attention</u> moving parts, hot parts (exhaust manifold and muffler, etc.) electrical parts which may be unprotected when the machine is open.
- Remove guards only when necessary to perform maintenance, and replace them when the maintenance requiring their removal is complete.
- Use suitable tools and clothes.
- Do not modify the components if not authorized.
 - See pag. M1.1 -



HOT surface can hurt you

MOVING PARTS can injure

NOTE

By maintenance at care of the utilizer we intend all the operatios concerning the verification of mechanical parts, electrical parts and of the fluids subject to use or consumption during the normal operation of the machine.

For what concerns the fluids we must consider as maintenance even the periodical change and or the refills eventually necessary.

Maintenance operations also include machine cleaning operations when carried out on a periodic basis outside of the normal work cycle.

The repairs <u>cannot be considered</u> among the maintenance activities, i.e. the replacement of parts subject to occasional damages and the replacement of electric and mechanic components consumed in normal use, by the Assistance Authorized Center as well as by MOSA.

The replacement of tires (for machines equipped with trolleys) must be considered as repair since it is not delivered as standard equipment any lifting system.

The periodic maintenance should be performed according to the schedule shown in the engine manual. An optional hour counter (M) is available to simplify the determination of the working hours.



IMPORTANT



In the maintenance operations avoid that polluting substances, liquids, exhausted oils, etc. bring damage to people or things or can cause negative effects to surroindings, health or safety respecting completely the laws and/ or dispositions in force in the place.















ENGINE and ALTERNATOR

PLEASE REFER TO THE SPECIFIC MANUALS PROVIDED.

VENTILATION

Make certain there are no obstructions (rags, leaves or other) in the air inlet and outlet openings on the machine, alternator and motor.

ELECTRICAL PANELS

Check condition of cables and connections daily.
Clean periodically using a vacuum cleaner, **DO NOT USE COMPRESSED AIR.**

DECALS AND LABELS

All warning and decals should be checked once a year and **replaced** if missing or unreadable.

STRENUOUS OPERATING CONDITIONS

Under extreme operating conditions (frequent stops and starts, dusty environment, cold weather, extended periods of no load operation, fuel with over 0.5% sulphur content) do maintenance more frequently.

BATTERY WITHOUT MAINTENANCE DO NOT OPEN THE BATTERY

The battery is charged automatically from the battery charger circuit suppplied with the engine.

Check the state of the battery from the colour of the warning light which is in the upper part.

- Green colour: battery OK
- Black colour: battery to be recharged
- White colour: battery to be replaced



NOTE

THE ENGINE PROTECTION NOT WORK WHEN THE OIL IS OF LOW QUALITY BECAUSE NOT CHARGED REGULARLY AT INTERVALS AS PRESCRIBED IN THE OWNER'S ENGINE MANUAL.



ATTENTION

- Maintenance operations on the electricity-generating group prearranged for automatic operation must be carried out with the panel in RESET mode.
- Maintenance operations on the installation's electrical panels must be carried out in complete safety by cutting off all external power sources: ELECTRICAL POWER, GROUP and BATTERY.

For the electricity-generating groups prearranged for automatic operation, in addition to carrying out all periodic maintenance operations foreseen for normal usage, various operations must be carried out that are necessary in relation to the specific type of use. The electricity-generating group in fact must be continuously prepared for operation, even after prolonged periods of inactivity.

MAINTENANCE GENERATING SET WITH AUTOMATIC BOARD

	EVERY WEEK	EVERY MONTH AND/OR AFTER INTERVENTION ON LOAD	EVERY YEAR
TEST or AUTOMATIC TEST cycle to keep the generating set constantly operative		WITH LOAD X	
2. Check all levels: engine oil, fuel level, battery electrolyte,, if necessary top it up.		X	
Control of electrical connections and cleaning of control panel		X	Х

Carry out motor oil change at least once a year, even if the requested number of hours has not been attained.

In case the machine should not be used for more than 30 days, make sure that the room in which it is stored presents a suitable shelter from heat sources, weather changes or anything which can cause rust, corrosion or damages to the machine.

Have **qualified** personnel prepare the machine for storage.

GASOLINE ENGINE

Start the engine: It will run until it stops due to the lack of fuel.

Drain the oil from the engine sump and fill it with new oil (see page M25).

Pour about 10 cc of oil into the spark plug hole and screw the spark plug, after having rotated the crankshaft several times.

Rotate the crankshaft slowly until you feel a certain compression, then leave it.

In case the battery, for the electric start, is assembled, disconnect it.

Clean the covers and all the other parts of the machine carefully.

Protect the machine with a plastic hood and store it in o dry place.

DIESEL ENGINE

For short periods of time it is advisable, about every 10 days, to make the machine work with load for 15-30 minutes, for a correct distribution of the lubricant, to recharge the battery and to prevent any possible bloking of the injection system.

For long periods of inactivity, turn to the after soles service of the engine manufacturer.

Clean the covers and all the other parts of the machine carefully.

Protect the machine with a plastic hood and store it in a dry place.

In case of necessity for first aid and of fire prevention, see page. M2.5.



IMPORTANT



In the storage operations avoid that polluting substances, liquids, exhausted oils, etc. bring damage to people or things or can cause negative effects to surroindings, health or safety respecting completely the laws and/or dispositions in force in the place.

Have **qualified** personnel disassemble the machine and dispose of the parts, including the oil, fuel, etc., in a correct manner when it is to be taken out of service.

As cust off we intend all operations to be made, at utilizer's care, at the end of the use of the machine. This comprises the dismantling of the machine, the subdivision of the several components for a further reutilization or for getting rid of them, the eventual packing and transportation of the eliminated parts up to their delivery to the store, or to the bureau encharged to the cust off or to the storage office, etc.

The several operations concerning the cust off, involve the manipulation of fluids potentially dangerous such as: lubricating oil and battery electrolyte.

The dismantling of metallic parts liable to cause injuries or wounds, must be made wearing heavy gloves and using suitable tools.

The getting rid of the various components of the machine must be made accordingly to rules in force of law a/o local rules.

Particular attention must be paid when getting rid of:

lubricating oils, battery electrolyte, and inflamable liquids such as fuel, cooling liquid.

The machine user is responsible for the observance of the norms concerning the environment conditions with regard to the elimination of the machine being cust off and of all its components.

In case the machine should be cust off without any previous disassembly it is however compulsory to remove:

- tank fuel
- engine lubricating oil
- cooling liquid from the engine
- battery

NOTE: MOSA is involved with custing off the machine **only** for the second hand ones, when not reparable.

This, of course, after authorization.

In case of necessity for first aid and fire prevention, see page M2.5.



IMPORTANT




In the cust-off operations avoid that polluting substances, liquids, exhausted oils, etc. bring damage to people or things or can cause negative effects to surroindings, health or safety respecting completely the laws and/or dispositions in force in the place.




D AbmessungenDimensiones

(NL)

GE 12000 SXC/GS GE 14000 SXC/GS M 53







(B) ELECTRICAL SYSTEM LEGENDE


©Μ	OSA REV.7-10/09 F				
Α	: Alternator	А3	: Insulation moitoring	A6	: Commutator/switch
В	: Wire connection unit	В3	: E.A.S. connector		: Key switch, on/off
С	: Capacitor	C3	: E.A.S. PCB		: QEA control unit
D	: G.F.I.	D3	: Booster socket	D6	: Connector, PAC
E	: Welding PCB transformer	E3	: Open circuit voltage switch	E6	: Frequency rpm regulator
F	: Fuse	F3	: Stop push-button	F6	: Arc-Force selector
G	: 400V 3-phase socket	G3	: Ignition coil		: Device starting motor
Н	: 230V 1phase socket	H3	: Spark plug		: Fuel electro pump 12V c.c.
1	: 110V 1-phase socket : Socket warning light	13 L3	: Range switch : Oil shut-down button	16 L6	: Start Local/Remote selector : Choke button
L M	: Hour-counter		: Battery charge diode		: Switch CC/CV
N	: Voltmeter	N3	: Relay	N6	: Connector – wire feeder
P	: Welding arc regulator		: Resistor	06	: 420V/110V 3-phase transformer
Q	: 230V 3-phase socket	P3	: Sparkler reactor	P6	: Switch IDLE/RUN
R	: Welding control PCB	Q3	: Output power unit	Q6	: Hz/V/A analogic instrument
S	: Welding current ammeter	R3	: Electric siren	R6	: EMC filter
T	: Welding current regulator	S3	: E.P.4 engine protection	S6	: Wire feeder supply switch
U	: Current transformer	Т3	: Engine control PCB	Т6	: Wire feeder socket
V	: Welding voltage voltmeter		: R.P.M. electronic regulator		: DSP chopper PCB
Z	: Welding sockets		: PTO HI control PCB		: Power chopper supply PCB
X	: Shunt	Z3	: PTO HI 20 I/min push-button	Z6	: Switch and leds PCB
W	: D.C. inductor		: PTO HI 30 I/min push-button	W6 X6	: Hall sensor
Υ	: Welding diode bridge	X3 Y3	: PTO HI reset push-button : PTO HI 20 I/min indicator	76	: Water heather indicator : Battery charge indicator
A1	: Arc striking resistor	13	. FTO THE 20 I/IIIII IIIUICALOI	10	. Dattery Charge mulcator
B1	: Arc striking resistor	A4	: PTO HI 30 I/min indicator	A7	: Transfer pump selector AUT-0-MAN
C1	: 110V D.C./48V D.C. diode bridge	B4	: PTO HI reset indicator	B7	: Fuel transfer pump
D1	: E.P.1 engine protection		: PTO HI 20 I/min solenoid valve	C7	: "GECO" generating set test
E1	: Engine stop solenoid	D4	: PTO HI 30 I/ min solenoid valve	D7	: Flooting with level switches
F1	: Acceleration solenoid	E4	: Hydraulic oil pressure switch	E7	: Voltmeter regulator
G 1	: Fuel level transmitter	F4	: Hycraulic oil level gauge	F7	: WELD/AUX switch
H1	: Oil or water thermostat	G 4	: Preheating glow plugs	G7	: Reactor, 3-phase
I1	: 48V D.C. socket		: Preheating gearbox	H7	: Switch disconnector
L1	: Oil pressure switch	14	: Preheating indicator	17	: Solenoid stop timer
	: Fuel warning light	L4	: R.C. filter	L7	: "VODIA" connector
N1	: Battery charge warning light	M 4	: Heater with thermostat		: "F" EDC4 connector
01 P1	: Oil pressure warning light : Fuse	N 4 O 4	: Choke solenoid : Step relay	N7 07	: OFF-ON-DIAGN. selector : DIAGNOSTIC push-button
Q1	: Starter key	P4	: Circuit breaker	P7	: DIAGNOSTIC push-button
R1	: Starter motor	Q 4	: Battery charge sockets	Q7	: Welding selector mode
S1	: Battery		: Sensor, cooling liquid temperature	R7	: VRD load
T1	: Battery charge alternator	S4	: Sensor, air filter clogging	S7	: 230V 1-phase plug
U1	: Battery charge voltage regulator	T4	: Warning light, air filter clogging	T7	: V/Hz analogic instrument
V1	: Solenoid valve control PCBT	U4	: Polarity inverter remote control	U7	: Engine protection EP6
Z1	: Solenoid valve	V4	: Polarity inverter switch	V7	: G.F.I. relay supply switch
W1	: Remote control switch	Z4	: Transformer 230/48V	Z7	: Radio remote control receiver
X1	: Remote control and/or wire feeder socket	W4	: Diode bridge, polarity change		: Radio remote control trasnsmitter
Y1	: Remote control plug	X4	: Base current diode bridge	X7	: Isometer test push-button
۸۵	· Pamata control wolding regulator	Y4	: PCB control unit, polarity inverter	Y7	: Remote start socket
A2 B2	: Remote control welding regulator : E.P.2 engine protection	A5	: Base current switch	A8	: Transfer fuel pump control
C2	: Fuel level gauge	B5	: Auxiliary push-button ON/OFF	B8	: Ammeter selector switch
D2	: Ammeter	C5	: Accelerator electronic control	C8	: 400V/230V/115V commutator
E2	: Frequency meter	D5	: Actuator	D8	: 50/60 Hz switch
F2	: Battery charge trasformer	E5	: Pick-up	E8	: Cold start advance with temp. switch
	: Battery charge PCB	F5	: Warning light, high temperature	F8	: START/STOP switch
H2	: Voltage selector switch	G 5	: Commutator auxiliary power	G8	: Polarity inverter two way switch
12	: 48V a.c. socket	Н5	: 24V diode bridge	Н8	: Engine protection EP7
L2	: Thermal relay	15	: Y/s commutator	18	: AUTOIDLE switch
M2	: Contactor	L5	: Emergency stop button	L8	: AUTOIDLE PCB
N2 02	: G.F.I. and circuit breaker		: Engine protection EP5		: A4E2 ECM engine PCB
P2	: 42V EEC socket : G.F.I. resistor	N 5 O 5	: Pre-heat push-button : Accelerator solenoid PCB	N8 08	: Remote emergency stop connector : V/A digital instruments and led VRD PCB
Q2	: T.E.P. engine protection	P5	: Oil pressure switch	P8	: Water in fuel
R2	: Solenoid control PCBT	Q5	: Water temperature switch	Q8	: Battery disconnect switch
S2	: Oil level transmitter	R5	: Water heater	R8	: Inverter
T2	: Engine stop push-button T.C.1	S5	: Engine connector 24 poles	S8	: Overload led
U2	: Engine start push-buttonT.C.1	T5	: Electronic GFI relais	T8	: Main IT/TN selector
V2	: 24V c.a. socket	U5	: Release coil, circuit breaker	U8	: NATO socket 12V
Z2	: Thermal magnetic circuit breaker	V5	: Oil pressure indicator	V8	: Diesel pressure switch
	: S.C.R. protection unit	Z5	: Water temperature indicator	Z8	: Remote control PCB
X2	: Remote control socket	W5	: Battery voltmeter	W8	: Pressure turbo protection
Y2	: Remote control plug	X5	: Contactor, polarity change	X8	:
		Y5	: Commutator/switch, series/parallel	Y8	


: Contactor, polarity change : Commutator/switch, series/parallel

OPF












MOSA guarantees that any request for spare parts will be satisfied.


To keep the machine in full working order, when replacement of MOSA spare parts is required, always ask for genuine parts only.

The requested data are to be found on the data plate located on the machine structure, quite visible and easy to consult. **



(VS) Special version only (SR) By request only






☐ Ricambi ☐ Ersatzteile ☐ ☐ GB Spare parts ☐ Tabla de recambios ☐ E 12000 SXC/GS ☐ 1.1

Pos. Cod. Descr. Note 1 219869050 ELETTROMAGNETE ECONOMIZZATORE EAS VERSION - Fino a REV.0-09/05 Del.176/07-25/07/07 264149050 ELETTROMAGNETE ECONOMIZZATORE Da REV.0-09/05 Del.176/07-25/07/07 2 107302860 **GHIERA** EAS VERSION FUNE COMANDO ELETTROMAGNETE 3 319869056 EAS VERSION 4 319862244 MORSETTO PER FUNE EAS VERSION 5 209812230 **LEVA** EAS VERSION 6 **DISTANZIALE** 209509057 EAS VERSION 7 209509056 TIRANTE EAS VERSION 8 219869055 ELETTROMAGNETE ARRESTO MOTORE EAS VERSION - Fino a REV.0-09/05 Del.176/07-25/07/07 8 274009055 ELETTROMAGNETE ARRESTO MOTORE Da REV.1-09/09 Del.46/08-26/02/08 256602228 9 FILTRO GASOLIO 10 209702203 TUBO COMBUSTIBILE 11 209712205 TUBO COMBUSTIBILE FILTRO NAFTA 12 102011190 209712206 TUBO COMBUSTIBILE 13 14 309409060 **ELETTROVALVOLA GB VERSION** 15 309409061 VALVOLA NON RITORNO **GB VERSION** 16 309402225 VITE FORATA **GB VERSION ALTERNATORE** 17 359203100 18 359253024 COPERCHIO ALTERNATORE 19 6087740 FASCETTA STR.TUBO 38-50 ACC.ZN TUBO DI SCARICO 20 219932070 21 TUBO FLESSIBILE FINITO 309502077 22 209502200 MOTORE LOMBARDINI 12LD477/2 TUBO FLESSIBILE (MT.1) 23 1229810 24 307012037 PROTEZIONE ANTIVIBRANTE 25 209812035 TRAVERSA SUPPORTO MOTORE 26 307012038 RONDELLA PER ANTIVIB. 10,5X52 105112020 **ANTIVIBRANTE** 27 28 359253101 SUPPORTO ALTERNATORE 29 359253039 DISTANZIALE FISSAGGIO VENTOLA 30 210016020 **VENTOLA** Pos. Cod. Descr. 219869050 ACCELERATOR SOLENOID EAS VERSION - Up to REV.0-09/05 Del.176/07-25/07/07 1 264149050 ACCELERATOR SOLENOID From REV.0-09/05 Del.176/07-25/07/07 1 319862244 **TERMINAL** EAS VERSION 2 3 319869056 WIRE EAS VERSION 4 107302860 RING NUT EAS VERSION 5 209812230 **LEVER** EAS VERSION 6 209509057 **SPACER** EAS VERSION 7 TIE-ROD 209509056 EAS VERSION 8 STOP SOLENOID 219869055 EAS VERSION - Up to REV.0-09/05 Del.176/07-25/07/07 STOP SOLENOID 8 274009055 From REV.1-09/09 Del.46/08-26/02/08 9 256602228 **FUEL FILTER** PIPE, FUEL 10 209702203 11 209712205 PIPE, FUEL FILTER, FUEL 12 102011190 13 209712206 PIPE, FUEL 14 309409060 SOLENOID VALVE **GB VERSION** 15 309409061 NON RETURN VALVE **GB VERSION** 16 309402225 SCREW, DRILLED **GB VERSION** 17 359203100 **ALTERNATOR** ALTERNATOR COVER 18 359253024 19 6087740 CLAMP **EXHAUST PIPE** 20 219932070 FLEXIBLE PIPE (COMPL.) 21 309502077 **LOMBARDINI ENGINE 12LD477/2** 22 209502200 23 FLEXIBLE PIPE (MT.1) 1229810 PROTECTION, VIBRATION-DAMPER 24 307012037 **ENGINE SUPPORT CROSSBAR** 25 209812035 26 307012038 WASHER X VIBRATION DAMPER 27 VIBRATION DAMPER 105112020 28 359253101 ALTERNATOR SUPPORT 29 359253039 FIXING FAN SPACER

FAN

30


210016020



15




©IVIUSA	REV. I-09/09 FIELES	ue rechange w		
Pos.	Rev. Cod.	Descr.	Note	
1	352007109	PROTEZIONE TERMICA 5A		
2	105511810	CONTAORE 230V 50Hz IP65		
3	232027130	CAPPUCCIO PROTEZIONE I.D.		
4	107669705	INTERRUTTORE MAGNETOTERMICO 2P		
5	359207105	INTERRUTTORE DIFFERENZIALE 2P		
6	232027036	GUIDA		
7	359207300	STRUM. ANALOGICO A LED V/Hz		
8	305767240	PRESA CEE 63A 220V 2P+T		
9	105111520	PRESA CEE 220V MONOF. 2P+T		
10	359207020	FRONTALE		
11	873407107	DISGIUNTORE TERMICO 30A/250V		
12	359257032	COPERCH. CHIUS. FORO SCALDIGLIA		
13	307017240	PRESA 220V 16A		
14	209719105	COMANDO ACCELERATORE		
15	155307107	DISGIUNTORE TERMICO 15A-250V		
16	1302040	SPIA ROSSA 12V	Fino a REV.0-09/05 Del.58/08-10/03/08	
16	1302500	SPIA ROSSA 12V	Da REV.1-09/09 Del.58/08-10/03/08	
17	105191550	CUSTODIA PER PRESA EAS		
18	105191570	COPERCHIO PER PRESA EAS		
19	105191560	FRUTTO PRESA CONNETTORE		
20	102042740	CAPPUCCIO		
21	102013290	COMMUTATORE		
22	107302460	STARTER A CHIAVE		
23	220117130	COPERCHIO PROTEZIONE	GB VERSION	
24	201308039	COLONNETTA	GB VERSION	
25	1243020	GUIDA PER MORSETTIERA	GB VERSION	
26	305027105	INTERRUTTORE DIFFERENZIALE	GB VERSION	
27	307047250	PRESA CEE 110V 16A 2 P+T	GB VERSION	
28 29	105611890	COMANDO STOP FRONTALE	GB VERSION	
30	359227020 105111530	PRESA CEE 110V 32A 2 P+T	GB VERSION GB VERSION	
Pos.	Rev. Cod.	Descr.	Note	
1	352007109	THERMOPROTECTION	Note	
2	105511810	HOURMETER 230V 50Hz IP65		
3	232027130	CAP		
4	107669705	CIRCUIT BREAKER 2POLES		
5	359207105	GFI 2 POLES		
6	232027036	FIXING GUIDE		
7	359207300	ANALOGIC INSTRUMENT V/HZ		
8	305767240	EEC SOCKET 63A 220V 2P+T		
9	105111520	EEC SOCKET SINGLE-PH.220V 2P+		
10	359207020	FRONT PANEL		
11	873407107	CIRCUIT BREAKER 30A/250V		
12	359257032	COVER		
13	307017240	EEC SOCKET 16A, 220V 2P+T		
14	209719105	ACCELERATOR LEVER		
15	155307107	THERMAL SWITCH 15A-250V		
16	1302040	RED WARNING LIGHT 12V	Fino a REV.0-09/05 Del.58/08-10/03/08	
16	1302500	RED WARNING LIGHT 12V	Da REV.1-09/09 Del.58/08-10/03/08	
17	105191550	BOX, EAS SOCKET		
18	105191570	BLIND PLATE, EAS SOCKET		
19	105191560	SOCKET, EAS		
20	102042740	CAP		
21	102013290	COMMUTATOR		
22	107302460	STARTER KEY		
23	220117130	PROTECTION COVER	GB VERSION	
24	201308039	CONNECTING CYLINDER	GB VERSION	
25	1243020	TERMINAL GUIDE	GB VERSION	
26	305027105	GROUND FAULT INTERRUPTOR (GFI)	GB VERSION	
27	307047250	EEC SOCKET 110V 16A 2 P+N	GB VERSION	
28	105611890	FRONT PANEL	GB VERSION	
30	105111530	EEC SOCKET 32A 110V 2 P+N	GB VERSION	



		□ Ricambi	① Ersatzteile		HI
M		(B) Spare parts	E Tabla de recambios GE 1200	OO SXC/GS	3.1
© MOSA	REV.0-09/05	F Piéces de rechange	(NL) GE 1400	OO SXC/GS	


Pos.	Rev. Cod.	Descr.	Note
1	317802026	TAPPO SERBATOIO CON CHIAVE	(SR)
2	342202026	TAPPO SERBATOIO	
3	305719875	GALLEGGIANTE	
4	107301890	TUBO GOMMA	(qm)
5	107502208	TUBETTO RITORNO GASOLIO	(qm)
6	209702203	TUBO COMBUSTIBILE	
7	359259150	BATTERIA 12V 45Ah (senza manut.)	
8	209509152	TRAVERSA FISSAGGIO BATTERIA	
9	105611270	TIRANTE PER BATTERIA	
10	102042380	VASCHETTA BATTERIA	
11	309702050	SILENZIATORE DI SCARICO	
12	308102023	GUARNIZIONE	
13	308101262	TAPPO SCARICO SERBATOIO	
14	319930515	CASSONETTO SCARICO	
15	309708200	CASSONETTO ASPIRAZ.ALTERNATORE	
Pos	Rev Cod	Descr	Note
Pos.	Rev. Cod.	Descr.	Note
1	317802026	CAP,TANK	Note (SR)
1 2	317802026 342202026	CAP,TANK CAP, FUEL TANK	
1 2 3	317802026 342202026 305719875	CAP,TANK CAP, FUEL TANK FLOAT	(SR)
1 2 3 4	317802026 342202026 305719875 107301890	CAP,TANK CAP, FUEL TANK FLOAT PIPE, BREATHER (L=MT1)	(SR)
1 2 3 4 5	317802026 342202026 305719875 107301890 107502208	CAP,TANK CAP, FUEL TANK FLOAT PIPE, BREATHER (L=MT1) PIPE	(SR)
1 2 3 4 5 6	317802026 342202026 305719875 107301890 107502208 209702203	CAP,TANK CAP, FUEL TANK FLOAT PIPE, BREATHER (L=MT1) PIPE PIPE, FUEL	(SR)
1 2 3 4 5 6 7	317802026 342202026 305719875 107301890 107502208 209702203 359259150	CAP, TANK CAP, FUEL TANK FLOAT PIPE, BREATHER (L=MT1) PIPE PIPE, FUEL BATTERY 12V 45Ah (without maintenance)	(SR)
1 2 3 4 5 6 7 8	317802026 342202026 305719875 107301890 107502208 209702203 359259150 209509152	CAP,TANK CAP, FUEL TANK FLOAT PIPE, BREATHER (L=MT1) PIPE PIPE, FUEL BATTERY 12V 45Ah (without maintenance) BRACKET, BATTERY FIXING	(SR)
1 2 3 4 5 6 7 8 9	317802026 342202026 305719875 107301890 107502208 209702203 359259150 209509152 105611270	CAP, TANK CAP, FUEL TANK FLOAT PIPE, BREATHER (L=MT1) PIPE PIPE, FUEL BATTERY 12V 45Ah (without maintenance) BRACKET, BATTERY FIXING TIE ROD, BATTERY	(SR)
1 2 3 4 5 6 7 8 9	317802026 342202026 305719875 107301890 107502208 209702203 359259150 209509152 105611270 102042380	CAP,TANK CAP, FUEL TANK FLOAT PIPE, BREATHER (L=MT1) PIPE PIPE, FUEL BATTERY 12V 45Ah (without maintenance) BRACKET, BATTERY FIXING TIE ROD, BATTERY HOLDER, BATTERY	(SR)
1 2 3 4 5 6 7 8 9 10	317802026 342202026 305719875 107301890 107502208 209702203 359259150 209509152 105611270 102042380 309702050	CAP, TANK CAP, FUEL TANK FLOAT PIPE, BREATHER (L=MT1) PIPE PIPE, FUEL BATTERY 12V 45Ah (without maintenance) BRACKET, BATTERY FIXING TIE ROD, BATTERY HOLDER, BATTERY MUFFLER, EXHAUST	(SR)
1 2 3 4 5 6 7 8 9 10 11	317802026 342202026 305719875 107301890 107502208 209702203 359259150 209509152 105611270 102042380 309702050 308102023	CAP, TANK CAP, FUEL TANK FLOAT PIPE, BREATHER (L=MT1) PIPE PIPE, FUEL BATTERY 12V 45Ah (without maintenance) BRACKET, BATTERY FIXING TIE ROD, BATTERY HOLDER, BATTERY MUFFLER, EXHAUST GASKET	(SR)
1 2 3 4 5 6 7 8 9 10	317802026 342202026 305719875 107301890 107502208 209702203 359259150 209509152 105611270 102042380 309702050	CAP, TANK CAP, FUEL TANK FLOAT PIPE, BREATHER (L=MT1) PIPE PIPE, FUEL BATTERY 12V 45Ah (without maintenance) BRACKET, BATTERY FIXING TIE ROD, BATTERY HOLDER, BATTERY MUFFLER, EXHAUST	(SR)



	V I -		→ Ricambi	① Ersatzteile	HI	
	<u> </u>		Spare parts	E Tabla de recambios GE 12000	SXC/GS 4.1	
©	MOSA	REV.1-09/09	F Piéces de rechange	NL GE 14000	SXC/GS	


Pos.	Rev. Cod.	Descr.	Note
1	209748100	COPERCHIO FRONTALE	(*)
2	209818270	PERNO PER CERNIERA	(*)
3	373008005	CARENATURA (COMPL.)	(*)
4	209718070	COPERCHIETTO	(*)
5	105112270	GUARNIZIONE (L=MT.1)	(qm) (*)
6	209718073	TIRANTE	(*)
7	102042870	MOLLA	(*)
8	107300180	CHIUSURA COMPL.A LEVA	(*)
9	343339601	MANIGLIA	(*)
10	209508115	PISTONE SOSTEGNO	
11	219828230	GRIGLIA ASPIRAZIONE ARIA	
12	105112270	GUARNIZIONE (L=MT.1)	
13	219828200	PARATIA ASPIRAZ. MOTORE	
14	209711100	ROLL BAR	
15	319930501	BASAMENTO (VERS.SX/C)	
16	359258218	PARATIA INF. ASP. ALTERNATORE	
17	359258121	COPERTURA APP. ELETTRICHE	
18	359256010	CONVOGLIATORE ARIA ALTERNATORE	
19	209718024		
20	359258217	PARATIA SUP. ASP. ALTERNATORE	
22	209808065	GRIGLIA USCITA ARIA	
100	219938280	GR.CARENATURA COMPL.RICAMBI	(*) 1-9+22
Pos.	Rev. Cod.	Descr.	Note
Pos.	Rev. Cod. 209748100	Descr. FRONT COVER	
			(*)
1	209748100	FRONT COVER	(*) (*)
1 2	209748100 209818270	FRONT COVER HINGE PIN	(*)
1 2 3	209748100 209818270 373008005	FRONT COVER HINGE PIN COVER (COMPL.)	(*) (*) (*)
1 2 3 4	209748100 209818270 373008005 209718070	FRONT COVER HINGE PIN COVER (COMPL.) COVER	(*) (*) (*) (*)
1 2 3 4 5	209748100 209818270 373008005 209718070 105112270	FRONT COVER HINGE PIN COVER (COMPL.) COVER STRIP, SEALING (L=MT.1)	(*) (*) (*) (*) (qm) (*)
1 2 3 4 5 6	209748100 209818270 373008005 209718070 105112270 209718073	FRONT COVER HINGE PIN COVER (COMPL.) COVER STRIP, SEALING (L=MT.1) TIE-ROD	(*) (*) (*) (*) (qm) (*) (*)
1 2 3 4 5 6 7	209748100 209818270 373008005 209718070 105112270 209718073 102042870	FRONT COVER HINGE PIN COVER (COMPL.) COVER STRIP, SEALING (L=MT.1) TIE-ROD SPRING	(*) (*) (*) (*) (qm) (*) (*) (*)
1 2 3 4 5 6 7 8	209748100 209818270 373008005 209718070 105112270 209718073 102042870 107300180	FRONT COVER HINGE PIN COVER (COMPL.) COVER STRIP, SEALING (L=MT.1) TIE-ROD SPRING LATCH	(*) (*) (*) (qm) (*) (*) (*) (*) (*)
1 2 3 4 5 6 7 8	209748100 209818270 373008005 209718070 105112270 209718073 102042870 107300180 343339601	FRONT COVER HINGE PIN COVER (COMPL.) COVER STRIP, SEALING (L=MT.1) TIE-ROD SPRING LATCH KNOB	(*) (*) (*) (qm) (*) (*) (*) (*) (*)
1 2 3 4 5 6 7 8 9	209748100 209818270 373008005 209718070 105112270 209718073 102042870 107300180 343339601 209508115	FRONT COVER HINGE PIN COVER (COMPL.) COVER STRIP, SEALING (L=MT.1) TIE-ROD SPRING LATCH KNOB SUPPORT, AIR INLET WALL ENGINE INTAKE GRATE STRIP, SEALING (L=MT.1)	(*) (*) (*) (qm) (*) (*) (*) (*) (*)
1 2 3 4 5 6 7 8 9 10	209748100 209818270 373008005 209718070 105112270 209718073 102042870 107300180 343339601 209508115 219828230 105112270 219828200	FRONT COVER HINGE PIN COVER (COMPL.) COVER STRIP, SEALING (L=MT.1) TIE-ROD SPRING LATCH KNOB SUPPORT, AIR INLET WALL ENGINE INTAKE GRATE STRIP, SEALING (L=MT.1) ENGINE INTAKE COVER	(*) (*) (*) (qm) (*) (*) (*) (*) (*)
1 2 3 4 5 6 7 8 9 10 11	209748100 209818270 373008005 209718070 105112270 209718073 102042870 107300180 343339601 209508115 219828230 105112270	FRONT COVER HINGE PIN COVER (COMPL.) COVER STRIP, SEALING (L=MT.1) TIE-ROD SPRING LATCH KNOB SUPPORT, AIR INLET WALL ENGINE INTAKE GRATE STRIP, SEALING (L=MT.1) ENGINE INTAKE COVER ROLL BAR	(*) (*) (*) (qm) (*) (*) (*) (*) (*)
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15	209748100 209818270 373008005 209718070 105112270 209718073 102042870 107300180 343339601 209508115 219828230 105112270 219828200 209711100 319930501	FRONT COVER HINGE PIN COVER (COMPL.) COVER STRIP, SEALING (L=MT.1) TIE-ROD SPRING LATCH KNOB SUPPORT, AIR INLET WALL ENGINE INTAKE GRATE STRIP, SEALING (L=MT.1) ENGINE INTAKE COVER ROLL BAR CRANKASE (VERS.SX/C)	(*) (*) (*) (qm) (*) (*) (*) (*) (*)
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16	209748100 209818270 373008005 209718070 105112270 209718073 102042870 107300180 343339601 209508115 219828230 105112270 219828200 209711100 319930501 359258218	FRONT COVER HINGE PIN COVER (COMPL.) COVER STRIP, SEALING (L=MT.1) TIE-ROD SPRING LATCH KNOB SUPPORT, AIR INLET WALL ENGINE INTAKE GRATE STRIP, SEALING (L=MT.1) ENGINE INTAKE COVER ROLL BAR CRANKASE (VERS.SX/C) ALTERNATOR INTAKE UNDERWALL	(*) (*) (*) (qm) (*) (*) (*) (*) (*)
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17	209748100 209818270 373008005 209718070 105112270 209718073 102042870 107300180 343339601 209508115 219828230 105112270 219828200 209711100 319930501 359258218 359258121	FRONT COVER HINGE PIN COVER (COMPL.) COVER STRIP, SEALING (L=MT.1) TIE-ROD SPRING LATCH KNOB SUPPORT, AIR INLET WALL ENGINE INTAKE GRATE STRIP, SEALING (L=MT.1) ENGINE INTAKE COVER ROLL BAR CRANKASE (VERS.SX/C) ALTERNATOR INTAKE UNDERWALL COVER, ELEVTRICAL BOX	(*) (*) (*) (qm) (*) (*) (*) (*) (*)
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18	209748100 209818270 373008005 209718070 105112270 209718073 102042870 107300180 343339601 209508115 219828230 105112270 219828200 209711100 319930501 359258218 359258121 359256010	FRONT COVER HINGE PIN COVER (COMPL.) COVER STRIP, SEALING (L=MT.1) TIE-ROD SPRING LATCH KNOB SUPPORT, AIR INLET WALL ENGINE INTAKE GRATE STRIP, SEALING (L=MT.1) ENGINE INTAKE COVER ROLL BAR CRANKASE (VERS.SX/C) ALTERNATOR INTAKE UNDERWALL COVER, ELEVTRICAL BOX ALTERNATOR AIR CONVEYOR	(*) (*) (*) (qm) (*) (*) (*) (*) (*)
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19	209748100 209818270 373008005 209718070 105112270 209718073 102042870 107300180 343339601 209508115 219828230 105112270 219828200 209711100 319930501 359258218 359258121 359256010 209718024	FRONT COVER HINGE PIN COVER (COMPL.) COVER STRIP, SEALING (L=MT.1) TIE-ROD SPRING LATCH KNOB SUPPORT, AIR INLET WALL ENGINE INTAKE GRATE STRIP, SEALING (L=MT.1) ENGINE INTAKE COVER ROLL BAR CRANKASE (VERS.SX/C) ALTERNATOR INTAKE UNDERWALL COVER, ELEVTRICAL BOX ALTERNATOR AIR CONVEYOR HINGE PIN	(*) (*) (*) (qm) (*) (*) (*) (*) (*)
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20	209748100 209818270 373008005 209718070 105112270 209718073 102042870 107300180 343339601 209508115 219828230 105112270 219828200 209711100 319930501 359258218 359258121 359256010 209718024 359258217	FRONT COVER HINGE PIN COVER (COMPL.) COVER STRIP, SEALING (L=MT.1) TIE-ROD SPRING LATCH KNOB SUPPORT, AIR INLET WALL ENGINE INTAKE GRATE STRIP, SEALING (L=MT.1) ENGINE INTAKE COVER ROLL BAR CRANKASE (VERS.SX/C) ALTERNATOR INTAKE UNDERWALL COVER, ELEVTRICAL BOX ALTERNATOR AIR CONVEYOR HINGE PIN ENGINE AIR INTAKE EXHAUST SITE	(*) (*) (*) (qm) (*) (*) (*) (*) (*)
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19	209748100 209818270 373008005 209718070 105112270 209718073 102042870 107300180 343339601 209508115 219828230 105112270 219828200 209711100 319930501 359258218 359258121 359256010 209718024	FRONT COVER HINGE PIN COVER (COMPL.) COVER STRIP, SEALING (L=MT.1) TIE-ROD SPRING LATCH KNOB SUPPORT, AIR INLET WALL ENGINE INTAKE GRATE STRIP, SEALING (L=MT.1) ENGINE INTAKE COVER ROLL BAR CRANKASE (VERS.SX/C) ALTERNATOR INTAKE UNDERWALL COVER, ELEVTRICAL BOX ALTERNATOR AIR CONVEYOR HINGE PIN	(*) (*) (*) (qm) (*) (*) (*) (*) (*)





Rev.	Cod.	Descr.	Descr.	Note
	0000219930131	GR.TIMONE,PIEDE x TRAINO LENTO	KIT SITE TOW	
	102012560	PARAPOLVERE	COVER,DUST	
	0000219930132	GR. ASSALE, RUOTE TRAINO LENTO	KIT SITE TOW	
	209711160	ASSALE	AXLE	
	209711170	RUOTA	WHEEL	
			0000219930131 GR.TIMONE,PIEDE x TRAINO LENTO 102012560 PARAPOLVERE 0000219930132 GR. ASSALE, RUOTE TRAINO LENTO 209711160 ASSALE	0000219930131 GR.TIMONE,PIEDE x TRAINO LENTO KIT SITE TOW 102012560 PARAPOLVERE COVER,DUST 0000219930132 GR. ASSALE, RUOTE TRAINO LENTO KIT SITE TOW 209711160 ASSALE AXLE






Pos.	Rev.	Cod.	Descr.	Descr.	Note	
1		0000219930141	GR.TIMONE,PIEDE X TRAINO LENTO	KIT SITE TOW		1
2		102351750	PIEDE DI STAZIONAMENTO	PARKING STAND		l
3		209701150	TIMONE	TOW BAR		
4		0000219930142	GR. ASSALE, RUOTE TRAINO LENTO	KIT SITE TOW		₹
5		209701160	ASSALE	AXLE		1/03
6		105112770	RUOTA	WHEEL		06/1





TCM 5 5D - 6 - 22 - 40 930150000 - 330100000 - 930300000 - 330200000 - 330400000



Pos.	Rev.	Cod.	Descr.	Descr.	Note
1		107509900	SCATOLA	CASE, BOTTOM HALF	
2		330109901	COPERCHIO PER SCATOLA TCM	TCM COVER	
3		102042740	CAPPUCCIO	CAP	
4		1302040	SPIA 12V	WARNING LIGHT 12V	
5		102013290	COMMUTATORE	COMMUTATOR	
6		107302460	STARTER A CHIAVE	STARTER KEY	
7		33010C060	GRUPPO CAVITC	TC CABLE KIT	TCM5D-6
8		6062050	TAPPO	CAP	
9		33020C060	GR.CAVI TCM	TCM CABLE KIT	TCM22-40
10	Α	101091830	PULSANTE DI STOP	BUTTON, STOP	TCM5
11	Α	101091840	CAPPUCCIO	CAP	TCM5
12	Α	93015C060	GRUPPO CAVI TCM	TCM CABLE KIT	TCM5
13	Α	259107055	STARTER A CHIAVE	KEY STARTER	TCM5
14	Α	307457055	INTERRUTT.ACCENSIONE A CHIAVE	STARTER SWITCH	TCM40
15	Α	930159901	COPERCHIO PER SCATOLA TCM	TCM COVER	TCM5