
GE 6000 - 6500 DES/GS-L

0 5 0 4 256089003 - GB

ENGLISH







UNI EN ISO 9001: 2000

MOSA has certified its quality system according to UNI EN ISO 9001:2000 to ensure a constant, high quality of its products. This certification covers the design, production and servicing of engine driven welders and generating sets.

The certifying institute, ICIM, which is a member of the International Certification Network IQNet, awarded the official approval to MOSA after an examination of its operations at the head office and plant in Cusago (MI), Italy.

This certification is not a point of arrival but a pledge on the part of the entire company to maintain a level of quality of both its products and services which will continue to satisfy the needs of its clients, as well as to improve the transparency and the communications regarding all the company's actives in accordance with the official procedures and in harmony with the MOSA Manual of Quality.

The advantages for MOSA clients are:

- Constant quality of products and services at the high level which the client expects;
- Continuous efforts to improve the products and their performance at competitive conditions;
- Competent support in the solution of problems;
- Information and training in the correct application and use of the products to assure the security of the operator and protect the environment;
- Regular inspections by ICIM to confirm that the requirements of the company's quality system and ISO 9001 are being respected.

All these advantages are guaranteed by the CERTIFICATE OF QUALITY SYSTEM No.0192/3 issued by ICIM S.p.A. - Milano (Italy) - www.icim.it



K...

ACCESSORIES

INDEX (for all MOSA models)

M 01	QUALITY SYSTEM	
M 1.01	COPYRIGHT	
M 1.1	NOTES	
M 1.4	NOTES	
M 2	2015 C. V. 100 (2015) C	
M 2.3	ABBREVIATIONS LEGEND	
M 2.4	SYMBOLS	
M 2.5		
M 2.6	INSTALLATIONS AND ADVICE	
M 2.7	INSTALLATION	
M 3	PACKING	
M 4 M 6	TRANSPORT AND DISPLACEMENTS	
M 20	ASSEMBLY: CT	
M 21	SETTING-UP THE UNIT (DIESEL ENGINE) ENGINE STARTING AND USE (DIESEL ENGINE)	
M 22	STOPPING THE ENGINE (DIESEL ENGINE)	
M 25	SETTING-UP THE UNIT (GASOLINE ENGINE)	
M 26	STARTING THE ENGINE (GASOLINE ENGINE)	
M 27	STOPPING THE ENGINE (GASOLINE ENGINE)	
M 30	CONTROLS LEGEND	
M 31	CONTROLS	
M 32	CONTROLS (FRONT PANEL)	
M 33	USE AS HYDRAULIC POWER TAKE-OFF	only for TS
M 34	USE AS A WELDER	only for TS
M 35	USE AS AN ENGINE STARTER	only for TS
M 36	USE AS A BATTERY CHARGE	
M 37	USE AS A GENERATOR	
M 38	USE OF THE REMOTE CONTROL	
M 39	USE OF THE ENGINE PROTECTION	
M 40	TROUBLE SHOOTING	
M 43	MAINTENANCE	
M 44	PERIODIC MAINTENANCE	
M 45	STORAGE	
M 46	CAST OFF	
M 51	TECHNICAL DATA	
M 52	TECHNICAL DATA ENGINE DRIVEN WELDER	only for TS
M 53	DIMENSIONS	
M 55	RECOMMENDED ELECTRODES	only for TS
M 60 M 61	ELECTRICAL SYSTEM LEGENDE ELECTRICAL SYSTEM	
M 65	HYDRAULIC SYSTEM	
IVI OS	TTDRAULIC STSTEM	
R1	SPARE PARTS LIST	
	SPARE PARTS	



ATTENTION

This use and maintenance manual is an important part of the machines in question.

The assistance and maintenance personel must keep said manual at disposal, as well as that for the engine and alternator (if the machine is synchronous) and all other documentation about the machine.

We advise you to pay attention to the pages concerning the security (see page M1.1).

MOSA

@ All rights are reserved to said Company.

It is a property logo of MOSA division of B.C.S. S.p.A. All other possible logos contained in the documentation are registered by the respective owners.

The reproduction and total or partial use, in any form and/or with any means, of the documentation is allowed to nobody without a written permission by MOSA division of B.C.S. S.p.A.

To this aim is reminded the protection of the author's right and the rights connected to the creation and design for communication, as provided by the laws in force in the matter.

In no case MOSA division of B.C.S. S.p.A. will be held responsible for any damaga, direct or indirect, in relation with the use of the given information.

MOSA division of B.C.S. S.p.A. does not take any responsibility about the shown information on firms or individuals, but keeps the right to refuse services or information publication which it judges discutible, unright or illegal.



INFORMATION

Dear Customer, We wish to thank you for having bought from MOSA a high quality set.

Our sections for Technical Service and Spare Parts will work at best to help you if it were necessary.

To this purpose we advise you, for all control and overhaul operations, to turn to the nearest authorized Service Centre, where you will obtain a prompt and specialized intervention.

- In case you do not profit on these Services and some parts are replaced, please ask and be sure that are used exclusively original MOSA parts; this to guarantee that the performances and the initial safety prescribed by the norms in force are re-established.
- The use of non original spare parts will cancel immediately any guarantee and Technical Service obligation from MOSA.

NOTES ABOUT THE MANUAL

Before actioning the machine please read this manual attentively. Follow the instructions contained in it, in this way you will avoid inconveniences due to negligence, mistakes or incorrect maintenance. The manual is for qualified personnel, who knows the rules: about safety and health, installation and use of sets movable as well as fixed.

You must remember that, in case you have difficulties for use or installation or others, our Technical Service is always at your disposal for explanations or interventions.

The manual for Use Maintenance and Spare Parts is an integrant part of the product. It must be kept with care during all the life of the product.

In case the machine and/or the set should be yielded to another user, this manual must also given to him.

Do not damage it, do not take parts away, do not tear pages and keep it in places protected from dampness and heat.

You must take into account that some figures contained in it want only to identify the described parts and therefore might not correspond to the machine in your possession.

INFORMATION OF GENERAL TYPE

In the envelope given together with the machine and/or set you will find: the manual for Use Maintenance and Spare Parts, the manual for use of the engine and the tools (if included in the equipment), the guarantee (in the countries where it is prescribed by law).

Our products have been designed for the use of generation for welding, electric and hydraulic system; ANY OTHER DIFFERENT USE NOT INCLUDED IN THE ONE INDICATED, relieves MOSA from the risks which could happen or, anyway, from that which was agreed when selling the machine; MOSA excludes any responsibility for damages to the machine, to the things or to persons in this case.

Our products are made in conformity with the safety norms in force, for which it is advisable to use all these devices or information so that the use does not bring damage to persons or things.

While working it is advisable to keep to the personal safety norms in force in the countries to which the product is destined (clothing, work tools, etc.).

Do not modify for any motive parts of the machine (fastenings, holes, electric or mechanical devices, others..) if not duly authorized in writing by MOSA: the responsibility coming from any potential intervention will fall on the executioner as in fact he becomes maker of the machine.

Notice: this manual does not engage MOSA, who keeps the faculty, apart the essential characteristics of the model here described and illustrated, to bring betterments and modifications to parts and accessories, without putting this manual uptodate immediately.





Tel.: 02 - 90352.1 Fax: 02 - 90390466 e-mail: info@mosa.it www.mosa.it





Divisione della BCS S.p.A. V.le Europa 59 - 20090 Cusago (Mi) - Italia

DICHIARAZIONE DI CONFORMITA'



Déclaration de Conformité – Declaration of Conformity – Konformitätserklärung Conformiteitsverklaring – Declaración de Conformidad

MOSA dichiara sotto la pro	pria resp	onsabilità che l	a macchi	na;			
MOSA déclare, sous sa pro							
MOSA declares, under its of							
MOSA erklärt, daß die Agg							
MOSA verklaard, onder ha	ar eigen	verantwoordelii	kheid da	t de machine:			
MOSA declara bajo su resp							
Modello/Modèle/Model/Mod	ell/Mode	l/Modelo:					
Codice/ Code/ Code/ Kode/	Code/ C	Codigo:					
è conforme con quanto prev							
est en conformité avec ce q					s et rela	tives modifications:	
conforms with the Commun							
mit den Vorschriften der Ge-	meinsch	aft und deren Ei	gänzung	en übereinstimi	nt:		
in overeenkomst is met de it					orde mod	lificaties:	
comple con los requisitos de	la Dire	ctiva Comunita	ria y sus	anexos:			
98/37/CE		73/23/CE	2	89/336/CE	-	2000/14/CE	
No. of the last of							
per la verifica sono state coi	nsiderate	le sequenti noi	me armo	nizzate, Norme	naziona	li e internazionali:	
pour la vérification de la co	nformité	ont été consult	ées les r	ormes harmon	isées su	ivantes, normes na	tionale
et internationales:							
to check the conformity,	he fello	wina harmoniz	ed norm	s, national and	d interna	ational norms, hav	e bee
consulted:				9			
zur Prüfung hat man die folg	enden ü	bereinstimmend	ien natio	nalen und interr	ationale	n Normen herangez	ogen:
ter verificatie van de overe	enkomst	. ziin de volger	nde geha	rmoniseerde n	ormen, r	nationaal en interna	tionaa
geconsulteerd:							
para su verification se han to	enido en	cuenta las Non	nas armo	nizadas, Norm	as nacio	nales e internaciona	les:
Norme armonizzate - norme	s harmo	nisées - harmor	ized non	ns - übereinstin	nmende	Normen	

eharmoniseerde normen - Normas armonizadas

EN 292-1 EN 60204-1 EN 292-2

EN 60974-1 (Solo per modelli - Seulement pour les modèles - Only for models - nur für die Modelle - Alleen voor de modellen - Sólo para modelos: TS) EN 50199

EN 50081-2 EN 50082-2

- autres normes - other norms - andere Normen - andere normen - otras normas;
(Solo per modelli - Seulement pour les modèles - Only for models - nur für die Modelle - Alleen voor de modellen - Sôlo para modelos: GE) Altre norme ISO 8528

Benso Marelli Direttore Generale

Cusago,

MM 065.2.doc



The CE mark (European Community) certifies that the product complies with the essential safety requirements provided by the applicable COMMUNITY DIRECTIVES. In the Conformity Declaration are reported the HARMONIZED NORMS and not, used for the checking.

(B) SYMBOLS AND SAFETY PRECAUTIONS

GE_, MS_, TS_

M 2

SYMBOLS IN THIS MANUAL

 The symbols used in this manual are designed to call your attention to important aspects of the operation of the machine as well as potential hazards and dangers for persons and things.

IMPORTANT ADVICE

- Advice to the User about the safety:
- N.B.: The information contained in the manual can be changed without notice.
 Potential damages caused in relation to the use of

Potential damages caused in relation to the use of these instructions will not be considered because these are only <u>indicative</u>.

Remember that the non observance of the indications reported by us might cause damage to persons or things.

It is understood, that local dispositions and/or laws must be respected.

WARNING



<u>Situations of danger - no harm to persons or things</u>

Do not use without protective devices provided

Removing or disabling protective devices on the machine is prohibited.

Do not use the machine if it is not in good technical condition

The machine must be in good working order before being used. Defects, especially those which regard the safety of the machine, must be repaired before using the machine.

SAFETY PRECAUTIONS



DANGEROUS

This heading warns of an <u>immediate</u> danger for persons as well for things. Not following the advice can result in serious injury or death.



WARNING

This heading warns of situations which could result in injury for persons or damage to things.



CAUTION

To this advice can appear a danger for persons as well as for things, for which can appear situations bringing material damage to things.



IMPORTANT



NOTE



ATTENTION

These headings refer to information which will assis you in the correct use of the machine and/or accessories.

GE_, MS_, TS_

M 2-1

SYMBOLS (for all MOSA models)



STOP - Read absolutely and be duly attentive



Read and pay due attention



GENERAL ADVICE - If the advice is not respected damage can happen to persons or things.



HIGH VOLTAGE - Attention High Voltage. There can be parts in voltage, dangerous to touch. The non observance of the advice implies life danger.



FIRE - Danger of flame or fire. If the advice is not respected fires can happen.



HEAT - Hot surfaces. If the advice is not respected burns or damage to things can be caused.



EXPLOSION - Explosive material or danger of explosion. in general. If the advice is not respected there can be explosions.



WATER - Danger of shortcircuit. If the advice is not respected fires or damage to persons can be caused.



SMOKING - The cigarette can cause fire or explosion. If the advice is not respected fires or explosions can be caused.



ACIDS - Danger of corrosion. If the advice is not respected the acids can cause corrosions with damage to persons or things.



WRENCH - Use of the tools. If the advice is not respected damage can be caused to things and even to persons.



PRESSION - Danger of burns caused by the expulsion of hot liquids under pressure.

PROHIBITIONS No harm for persons

Use only with safety clothing -



It is compulsory to use the personal protection means given in equipment.

Use only with safety clothing -



It is compulsory to use the personal protection means given in equipment.

Use only with safety protections -



It is a must to use protection means suitable for the different welding works.

Use with only safety material -



It is prohibited to use water to quench fires on the electric machines.

Use only with non inserted voltage -



It is prohibited to make interventions before having disinserted the voltage.

No smoking -



It is prohibited to smoke while filling the tank with fuel.

No welding -



It is forbidden to weld in rooms containing explosive gases.

ADVICE No harm for persons and things

Use only with safety tools, adapted to the specific use -

It is advisable to use tools adapted to the various maintenance works.

Use only with safety protections, specifically suitable It is advisable to use protections suitable for the different welding works.

Use only with safety protections -



It is advisable to use protections suitable for the different daily checking works.

Use only with safety protections -



It is advisable to use all protections while shifting the machine.

Use only with safety protections -



It is advisable to use protections suitable for the different daily checking works.and/or of maintenance.



°C: temperature Celsius grades

10:10 kVA synchronous (wording example)

10000:10 kVA asynchronous (wording example)

A: Ampere
A: ADIM engine
atm: pressure

B: pretrol BAT: battery BC: base current

C.A.(c.a.): alternating current

C.B.: battery charger C.C.(c.c.): direct current

cc: cm³ (volume)

CE: European norm conformity CF: special for pipe welding CTL: slow touring trolley

CTM CTV: fast touring trolley: hand touring trolley

D: diesel D: GFI

D: Deutz engine E: electric start

EAS: automatic intervention panel for generating sets for connection to the mains

EL: electronic regulation, allows to use welder and generating set simultaneausly

EP1: automatic accelerator according to requestedpower, engine protection, low oil pressure, high temperature with engine stop, troble warning lights

EP2: engine protection, low oil pressure, hight temperature with engine stop, trouble warning lights

EP4: engine protection, low oil pressure, high temperature with engine stop, no battery charge, belt broken, low fuel level with engine stop, trouble warning lights

EP5: engine protection, low oil pressure, high temperature with engine stop, no battery charge, belt broken, low fuel level with engine stop, everspeed, trouble warning lights

ES: oil/temperature engine protection device

EV: electrovalve

g/kwh: grams/kilowatt hour (engine consumption)

GA: asynchronous alternator

GE: generating set

GHF: high frequency alternator GS: synchronous alternator h: hour meter (symbol)

H: Hatz engine H: Honda engine

HI: hydraulic central

Hz: frequency

I: single-phase auxiliary generation (symbol 1~)

IP: protection grads for electric devices against acess to dangerous parts according to the IEC 529 norm (Internal

Protection)

kg: kilogram (mass)K: welding cables setkVA: kilovolt amperekW: kilowatt (engine power)kWh: kilowatt hour (energy)

I: liters (capacity)

L: Lombardini engine

Lwa: maximum acoustic (power level) according to

EEC norm 535/536

mm: millimeter (length) (measure)

m: meter (length) mA: milliampere

MS-MSG: MOSA engine driven welder with high

frequency alternator MT: magnetothermic switch

MT: grounding kit

MTD: magnetothermic switch / GFI OH: heater (engine oil) for generating sets

P: plus

PAC: power electric frame PAR: device for double PB: battery holder PL: "pipe line" welding PS: exhaust pipe extension

PW: welder for polyethylene and propylene pipes

QEA: automatic electric panel **QEM**: manual electric panel

R: Ruggerini engine

RVT: voltage electronic regulator

S: symbol of EN 60974-1 **S**: Suzuki mengineotore

SKID: unit assembled on a base with no protection (no

fairing)

S-SC: silenced (faired) - silenced compact (faired SX-SXC: supersilenced (faired and sound prof) - supersilenced compact (faired and super sound prof)

T: thermic switch

TC-TCM-TCPL: remote control

TS: welder with asynchronous alternator

V: Volt

Y: Yanmar engine

Y: three-phase auxiliary generation (symbol 3~)



GE_, MS_, TS_

M 2.4

















Conformity

Sound power conformity


EN 60974-1 conformity

Triphase Singlephase

Users

Various

Equipment and optional





(B) INSTALLATION AND ADVICE BEFORE USE

GE_, MS_, TS_

M 2-5

The installation and the general advice concerning the operations, are finalized to the correct use of the machine, in the place where it is used as generator group and/or welder.

Γ	Stop engine when fueling		Do not touch electric devices if you
	Do not smoke, avoid flames, sparks or electric tools when fueling.		are barefoot or with wet clothes.
	Unscrew the cap slowly to let out the fuel vapours.	8	Always keep off leaning surfaces
ш	Slowly unscrew the cooling liquid tap if the liquid must be topped up.	BOA	during work operations
ENGIN	The vapor and the heated cooling liquid under pressure can burn face, eyes, skin.	KING	Static electricity can demage the parts on the circuit.
	Do not fill tank completely.		
	Wipe up spilled fuel before starting engine.	ᅴᇷ	
	Shut off fuel of tank when moving machine (where it is assembled).		An electric shock can kill
	Avoid spilling fuel on hot engine.		11
	Sparks may cause the explosion of battery vapours		



FIRST AID. In case the operator shold be sprayed by accident, from corrosive liquids a/o hot toxic gas or whatever event which may cause serious injuries or death, predispose the first aid in accordance with the ruling labour accident standards or of local instructions.

Skin contact	Wash with water and soap
Eyes contact	Irrigate with plenty of water, if the irritation persists contact a specialist
Ingestion	Do not induce vomit as to avoid the intake of vomit into the lungs, send for a doctor
Suction of liquids from	If you suppose that vomit has entered the lungs (as in case of spontaneous vomit) take the
lungs	subject to the hospital with the utmost urgency
Inhalation	In case of exposure to high concentration of vapours take immediately to a non polluted zone the person involved



FIRE PREVENTION. In case the working zone, for whatsoever cause goes on fire with flames liable to cause severe wounds or death, follow the first aid as described by the ruling norms or local ones.

	EXTINCTION MEANS
Appropriated	Carbonate anhydride (or carbon dioxyde) powder, foam, nebulized water
Not to be used	Avoid the use of water jets
Other indications	Cover eventual shedding not on fire with foam or sand, use water jets to cool off the surfaces close to the fire
Particular protection	Wear an autorespiratory mask when heavy smoke is present
Useful warnings	Avoid, by appropriate means to have oil sprays over metallic hot surfaces or over electric contacts (switches,plugs,etc.). In case of oil sprinkling from pressure circuits, keep in mind that the inflamability point is very low.
1	

					⚠ C	NOITUA	Sno
							△ DANGER
-+			Con Constitution of the Co				7



THE MACHINE MUST NOT BE USED IN AREAS WITH **EXPLOSIVE ATMOSPHERE**






INSTALLATION AND ADVICE BEFORE USE

GASOLINE ENGINES

Use in open space, air swept or vent exhaust gases, which contain the deathly carbone oxyde, far from the work area.

DIESEL ENGINES

Use in open space, air swept or vent exhaust gases far from the work area.




POSITION

Place the machine on a level surface at a distance of at least 1,5 m from buildings or other plants.



Maximum leaning of the machine (in case of dislevel)

Check that the air gets changed completely and the hot air sent out does not come back inside the set so as to cause a dangerous increase of the temperature.



Make sure that the machine does not move during the work: **block** it possibly with tools and/or devices made to this purpose.

MOVES OF THE MACHINE

At any move check that the engine is <u>off</u>, that there are no connections with cables which impede the moves.

PLACE OF THE MACHINE




In spots where it often rains and/or there are flooded areas, do **not** put the machine:


- in the bad weather
- in flooded places.

Protect all the electric parts at risk, because water infiltrations could cause short circuits with damages at persons and/or things.

The protection degree of the machine is put on the data plate and in this manual at page "Technical Data".





Entrada aire



SUPERFICIE CALDA **HOT SURFACE** SURFACE TRES CHAUDE HEIBER BEREICH SUPERFICIE CALIENTE


Scarico silenziatore motore Gas exhaust pipe Tuyau d'échappement gaz Auspuffgase Motor Tubo de descarga gas








NOTE





- 1) Take the machine (C) out of the shipment packing. Take out of the envelope (A) the user's manual (B).
- 2) Read: the user's manual (B), the plates fixed on the machine, the data plate.







GE_, MS_, TS_

M 4-1



NOTE

In case you should transport or move the machine, keep to the instructions as per the figures.


Make the transportation when the machine has no petrol in its tank, no oil in the engine and and electrolyte in the

Be sure that the lifting devices are: correctly mounted, adequate for the weight of the machine with it's packaging, and conform to local rules and regulations.

Only authorized persons involved in the transport of the machine should be in the area of movement.

DO NOT LOAD OTHER PARTS WHICH CAN MODIFY WEIGHT AND BARICENTER POSITION. IT IS STRICTLY FORBIDDEN TO DRAG THE MACHINE MANUALLY OR TOW IT BY ANY VEHICLE (model with no CTM accessory).

If you did not keep to the instructions, you could damage the structure of the machine.












M

6.6





Note: Lift the machine and assemble the parts as shown in the drawing

CTM 10 BES/GS



CTM 10 DS/GS





ATTENTION

The CTM accessory cannot be removed from the machine and used separately (actioned manually or following vehicles) for the transport of loads or anyway for used different from the machine movements.








BATTERY

Take the battery out of the machine.



Fill the battery (S1) to the maximum level with electrolyte. Wait for about 30 minutes and top up with electrolyte.

In case of spilled acid, rinse with water before putting the battery back into the machine and reconnecting cables. NOTE: Before starting the engine read the instructions in the owner's manual for the engine



FUEL

Fill the tank with good quality diesel fuel.

ATTENTION: Diesel fuel is highly inflammable; before filling the tank, stop the engine. Do not fuel in the presence of open flames.



If fuel is spilled on the engine, clean it immediately before starting up the engine.



는 COOLING LIQUID (Water-cooled no engines only)

Pour the cooling liquid through the hole (24B) at the top of the radiator until it reaches the opening.



CLEANING OF DRY AIR FILTER

See page M43.



GROUND CONNECTION

A good ground is <u>obligatory</u> for all models with GFI (ground fault interrupter) / ELCB (earth leakage circuit breaker). These protective devices <u>will not</u> protect the operator unless there is a good ground.

Use a good quality ground cable and connect it to the grounding point of the machine (12). Follow all local rules and/or regulations in force.

Machines with Isometer protection do not need to be grounded.

Once the above operations have been completed,











WARNING



Sulfuric acid is corrosive.

Protect hands, eyes and clothes

Take the battery out of the machine for filling.Warranty **VOIDED** for damages due to spilled acid.



LUBRIFICANT



Check the level of the engine oil using the oil dipstick. The level should be between the minimum and maximum marks. If necessary, add more oil.

If the air filter is of the oil bath type, fill it with the same oil up to the level indicated on the filter.

RECOMMENDED SAE VISCOSITY GRADES

For the type and viscosity of oil refer to owner's manual for the engine (supplied with the machine).

OIL AND COOLING LIQUID RECOMMENDED

MOSA advises to choose **AGIP** for the type of oil and cooling liquid.

Please keep to the label put on the engine for the recommended products.









NOTE

Do not alter the primary conditions of regulation and do not touch the sealed parts.

ENGINES WITH MANUAL RECOIL



Hold the starting handle firmly.



Pull the rope hard and fast. Pull it all the way out. Use two hands if necessary.



Then returning it slowly.

ENGINES WITH ACCELERATOR LEVER

Make sure that the accelerator lever or the switch (16) is at its minimum setting.

Insert the electric protection device (D-Z2-N2) lever towards above and, where mounted, check the isolation monitor (A3) see page M37 –



Introduce the key (Q1), turn it clockwise completely, leaving it as soon as the engine starts and/or the push button (32) (models without key) leaving it as soon as the engine starts.

NB.: for safety reason the key must be kept by qualified personel.

Once the engine has started leave it running at a reduced speed for some minutes.

Accelerate the engine at max., set lever on maximum position and then take up load.

ENGINES WITHOUT ACCELERATOR LEVER

Insert the electric protection device (D-Z2-N2) lever towards above and, where mounted, check the isolation monitor (A3) see page M37 –



Introduce the key (Q1), turn it clockwise completely, leaving it as soon as the engine starts.

NB.: <u>for safety reason the key must be kept by qualified personel.</u>

Let the engine run for some minutes before drawing the load.

Open the fuel cock (where it is assembled).



CAUTION

RUNNING-IN

During the first 50 hours of operation, do not use more than 60% of the maximum output power of the unit and check the oil level frequently, in any case please stick to the rules given in the engine use manual.



NOTE

The machines with E.P.1 engine protection device (D1), use the accelerator lever ONLY IN EMERCENCY when the engine protection does not work. In this case turn immediately to our Authorized Assistance Centers.

the lood.

ENGINE WITH PREHEATING GLOW PLUGS

Turn the starter key (Q1) on the position "preheating glow plugs" (the glow plugs light will be on I4), when the light is off, turn the starter key completely clockwise until the engine begins to fire. Let the engine run for some minutes before drawing

ENGINES WITH R.P.M. **ELECTRONIC** ADJUSTER (ONLY FOR GENERATING SET)

Turn the starter key (Q1) completely clockwise until the engine begins to fire.

Wait for the AUTOMATIC preheating time before drawing the load

OCCASIONAL USE OF THE ENGINE

Using the engine in special conditions which need an immediate intervention, such as emergency plants, etc., use advise to use our Engine Assistance Centres for specific interventions or our Technical Assistance Service.

CAUTION

If the engine fails to start, do not insist for at least 15 seconds.

Space the further operations waiting for at least 4 minutes.



CAUTION

MACHINE WITH EMERGENCY BUTTON

Before starting the engine, make sure that the emergency button (32B) is off (turn the button clockwise for this operation)





CAUTION


RUNNING-IN

During the first 50 hours of operation, do not use more than 60% of the maximum output power of the unit and check the oil level frequently, please follow the instructions on the engine use and maintenance manual..


1.0-10/00 **(F)** @MOSA

Before stopping the engine it is compulsory to effect the following operations:

- stop to draw three/single-phase current from the auxiliary sockets.



- stop to draw power from the welding sockets (only for TS models).



ENGINES WITH ACCELERATOR LEVER

Make sure that the unit is not supplying any power.

Disconnect the electrical protection device (D-Z2-N2) lever downward.

Set the accelerator lever or the switch (16) to minimum position and wait for a few minutes to allow the engine to cool, anyway follow the instructions contained in the engine manual.

Pull the stop lever (28) until the engine stops (where it is assembled).



Remove the key (Q1) turning it counter clockwise, OFF position, then take it out.

NB.:for safety reason the key must be kept by qualified personel.

ENGINES WITHOUT ACCELERATOR LEVER

Make sure that the unit is not supplying any power.

Disconnect the electrical protection device (D-Z2-N2) lever downward.

Let the engine idle for a few minutes.

Press the pushbutton (F3) until the engine stops

(where it is assembled).

Shut the fuel cock (where it is assembled).



Remove the key (Q1) turning it counter clockwise, OFF position, then take it

TNB.: for safety reason the key must be kept by qualified personel.

ENGINES WITH R.P.M. ELECTRONIC ADJUSTER (ONLY FOR GENERATING SET)

Make sure that the unit is not supplying any power.

Disconnect the electrical protection device (D-Z2-N2 lever downward.

Let the engine idle for a few minutes.

Press the pushbutton (F3) until the engine stops (where it is assembled).



Remove the key (Q1) turning it counter clockwise, OFF position, then take it


RB.: for safety reason the key must be kept by qualified personel.

CAUTION

MACHINE WITH EMERGENCY BUTTON

Pressing it, it allows to stop the engine in any condition (32B) (when assembled). To re-establish it, see page M21...





4A	Hydraulic oil level light
9	Welding socket (+)
10	Welding socket (-)
12	Earth terminal
15	A.C. socket
16	Accelerator lever
17	Feed pump
19	48V D.C. socket
22	Engine air filter
23	Oil level dipstick
24	Engine oil reservoir cap
24A	Hydraulic oil reservoir cap
24B	Water filling cap
25	Fuel prefilter
26	Fuel tank cap
27	Muffler

30	Engine cooling/alternator fan belt
31	Oil drain tap
31A	Hydraulic oil drain tap
31B	Water drain tap
31C	Exhaust tap for tank fuel
32	Button
33	Start button
34	Booster socket 12V
34A	Booster socket 24V

Engine protection cover

Stop control

28

29

35	Battery charge fuse
36	Space for remote control
37	Remote control
42	Space for E.A.S.
42A	Space for PAC
47	Fuel pump
49	Electric start socket
54	Reset button PTO HI
55	Quick coupling m. PTO HI
55A	Quick coupling f. PTO HI

56	Hydraulic oil filter
59	Battery charger thermal switch
59A	Engine thermal switch
59B	Aux current thermal switch

59C Supply thermal switch wire feeder-42V 63 No load voltage control

66 Choke control Auxiliary / welding current control 67A 68 Cellulosic electrodes control

69A Voltmeter relay 70 Warning lights 71 Selecting knob

72 Load commut. push button 73 Starting push button 74 Operating mode selector 75 Power on' warning light

76 Display

79 Wire connection unit

86 Selector

86A Setting confirmation

87 Fuel valve **A3** Insulation monitoring

A4 Button indicating light 30 I/1' PTO HI

B2 Engine control unit EP2 **B3** E.A.S. connector

B4 Exclusion indicating light PTO HI **B5** Auxiliary current push button

C2 Fuel level light C3 E.A.S. PCB

C6 Control unit for generating sets QEA D Ground fault interrupter (30 mA) D1 Engine control unit and economiser EP1 D2 Ammeter

E2 Frequency meter Fuse F

F3 Stop switch

F5 Warning light, high temperature

F6 Arc-Force selector G1 Fuel level transmitter H₂ Voltage commutator H₆ Fuel electro pump 12 48V A.C. socket 13 Welding scale switch 14 Preheating indicator 15 Y/s switch

16 Start Local/Remote selector L A.C. output indicator L5 **Emergency button**

L6 Choke button Μ Hour counter M1 Warning level light M2 Contactor

M5 Engine control unit EP5

M6 CC/CV switch N Voltmeter

N1 Battery charge warning light

N2 Thermal-magnetic circuit breaker/Ground fault interrupter

N5 Pre-heat push-button Connector - wire feader N6 01

Oil pressure warning light/Oil alert

Р Welding arc regulator Q1 Starter key

Derivation box Q3 Q4 Battery charge sockets R3 Siren

S Welding ammeter S1 Battery

S3 Engine control unit EP4 **S6** Wire feeder supply switch T Welding current regulator

T4 Dirty air filter warning light/indicator

T5 Earth leakage relay Current trasformer H U3 R.P.M. adjuster U4

Polarity inverter remote control

U5 Relase coil

Welding voltage voltmeter V V4 Polarity inverter control V5 Oil pressure indicator W1 Remote control switch

W3 Selection push button 30 I/1' PTO HI

W5 Battery voltmeter Remote control socket X1 Button indicating light 20 I/1' PTO HI **Y3** Y5 Commutator/switch, serial/parallel **Z2** Thermal-magnetic circuit breaker **Z**3 Selection push button 20 I/1' PTO HI **Z**5


Water temperature indicator




Bedienelemente **(E)** Mandos (N)

GE 6000 - 6500 DES/GS-L

M 31





According to the version of the machine on the front panel there are assembled some instruments:

panel there	are assembled some instruments:
	warning lights (L) corresponding to the current sockets on the front panel, indicate that the current can be drawn from the sockets when they are lit (15);
D MT	GFI (D), Thermal magnetic circuit breaker (Z2) (TSPL: : one for each auxiliary socket) or Thermal magnetic circuit breaker/GFI (N2);
-V (i)	voltage selector switch (H2);
R< \$	insulation monitoring (A3)- See page M 39.10 -;
h	hour-counter (M), which indicates the hours of effective operation of the unit;
	fuse (F), which protects the electric circuit of the engine, replacement of which, in case it breaks, must be effected absolutely with the machine stopped. Remove the mechanical protection, then shift down the small lever of the fuse holder placed on the front panel;
	fuel level gauge (M1): when the quantity of fuel in the tank falls below 5 litres a worning light on the instrument panel lights up;
<u> </u>	fuel level indicator (C2);
⊗ W	preheating glow plugs warning light (I4) for the preheating (for diesel engines it shows the intervention time of the glow plugs);
$\otimes $	dirty air filter warning light (T4);
A I	ammeter (D2) indicates the drown current. In case current is drawn simultaneously from several sockets, it shows the current sum. (DO NOT GO OVER THE MAX. CURRENT INDICATED ON THE LABEL);
从- ▲‡	star/ triangle switch (I5);
	frequency meter (E2), that indicates the frequency generated and therefore the number of revolutions of the engine: the frequency should be of 52 Hz» or 62 Hz» when the unit is idle and about 50 Hz or 60 Hz at full load (in cose that the found volue is different make sure that the engine is completely accelerated), (do never use the unit with a frequency lower than 49 Hz or 59 Hz, in this case decrease the load);
	tone horn (R3)) indicates the defects in the

engine;

	lengine protections: EV - EP1 (D1) (for engine at 3000/3600 rpm.), EP2 (B2 for engine at 1500/1800 rpm), EP4 - EP5 (M5)- See pag. M39
STATE OF	starter key (Q1) and engine stop;
O OF	welding socket (gouging, when assembled, - 9+ - 10-) - See pag. M 34 -;
0	Emergency button (L5);
 	Control switch for accelerator (only for engine at 3000/3600 rpm) - WE ADVISE TO USE THE SWITCH ONLY IF THE EP1 DEVICE IS BROKEN);
	auxiliary current push button (B5);
OFF ARC FORCE	welding current regulator (T) and/or "arc force" selector (F6) - See pag. M34 -1;
I O XXX A	welding scale switch (I3);
Polarity switch	polarity inverter control (V4);- See pag M34 -1;
OFF	cellulosic electrodes control (68);- See pag M34 -1;
	Protection fuse for welding PCB, welding ammeter (S);
ON OFF	remote control switch (W1) and remote control socket (X1) - See pag M38;
	switch CC/CV (M6)- See pag M34 -1;-



to the public mains a/o to another source of electric power.

A

WARNING

Sockets are not **self-locked**: tension is avaible immediately after starting also with no plug.



WARNING

The areas, access of which is forbidden to unqualified personel, are:

- the control switchboard (front), the exhaust of the endothermic engine.
- At the beginning of every work, check the electric parameters and/or the controls placed on the front.

Make sure the unit is properly grounded (12) (where it is assembled).


- See page M20, 21, 22, 25, 26, 27 -.

Move the accelerator lever (16) and reach the engine maximum speed, except for the engines with constant rpm; the voltmeter (N) (where it is assembled) shows the single-phase voltage whether three or single-phase current has to be drawn.

Nominal	Indicative no-load voltage					
voltage	asynchronous	synchronous (*)				
110V	±10%	±5%				
230V	±10%	±5%				
230V	±10%	±5%				
400V	±10%	±5%				

*N.B.: with electronic tens. regul. RVT ±1%

Connect up the machine, using proper plugs and cables in good condition to the AC socket (15) to draw single or three-phase power, or, by cables with adeguate section, to the terminal board, placed inside the derivation box (Q3).



The warning light (L), located near the current socket, lights up when the unit can supply alternated current, on condition that the engine is at the maximum rpm.

N.B.: if the warning light does not flash, check the accelerator which must bebat its maximum, or the fuse of the relevant socket. (single-phase) or the thermoprotection.

Using several sockets at the same time, the maximum power possible is that indicated on the data plate.

To draw power simultaneously in the TS welder version see page M52.



CAUTION


The replacement of the fuse must absolutely be done with the engine off (remove the mechanical protection, then shift down the small lever of the fuse holder placed on the front panel).

The max. continuous power of the generating set or theload current must not be exceeded.

MACHINE WITH THERMOPROTECTION

If you overload the genset the thermoprotection will automatically switch off.

If the thermoprotection is released, disconnect all the connected loads.



CIRCUIT BREAKER

Reset the thermoprotection pressing the central pole.

When reset, connect the loads again.


In case the protection should act furtherly, check: the connections, the wires or others, and if necessary call the Assistance Service.



Avoid to hold the central pole of the thermoprotection pressed for a long time.

Otherwise, in case of trouble, it will not click, damaging the generating set.





TS ... PL VERSION

Start the machine and wait for the end of the preheating time imposed by the EP1, EP2, EP5 engine protection device. - See pages M39... -

Press the "generation possibility" push button (B5) placed on the font side of machine.

The voltmeter will show the auxiliary voltage which, for machines at 1500/1800 RPM, must. be approx. \approx 230V \pm 10% and for machines at 3000/3600 RPM (engine idling) must. be approx. \approx 180V \pm 10%.

Push upwards the lever of magnetothermic switch reffering to the socket from which load is to be drawn.

MACHINE WITHOUT PROTECTIVE DEVICE

In case machine is not equipped with protective device of indirect contacts, by means of automatic breaking of supply, it **is necessary** to put between the load and the generation a differential switch or a similar equipment capable, in any case, to observe the regulations in force CEI 64/8 (and/or successive) Part 4 Par. 4.13.1 and harmonzed by directive Nr. 72/23/EEC.

UNIT FITTED WITH GROUND FAULT INTERRUPTER SWITCH (GFI)






Turn on the GFI safety-switch (D) by pushing it upwards.

The GFI is a safety device which protects the circuit in the event of a malfunction. In this case the switch disconnects the three and single-phase circuit when in any part of the electric connections a current leakage of more than 30 mA occurs.

UNIT FITTED WITH THERMAL MAGNETIC BREAKER




Turn on the thermal magnetic breaker (Z2) by pushing it to the ON position.

The thermal-magnetic breaker is a safety device which

protects the circuit in the event of a malfunction. In this case the switch disconnects the three and single-phase circuit when in any part of the electric connections a short circuit or a current absorption occurs above the data specified on the label of the unit.

In the model with setting **DO NOT INTERVENE** on the setting itself. To modify it, please contact our Technical Assistance Service.


UNIT FITTED WITH GFI SWITCH THERMAL MAGNETIC BREAKER



This switch includes the characteristics of both types of breakers (N2).

UNIT WITH VOLTMETRIC COMMUTATOR (ONLY FOR GENERATING SET)

warning: the possible single-phase loads must be correctly divided in the three phases, in order to avoid any possible voltage fall on one phase that results excessively loaded.



Check the voltages on the various phases with the switch located on the front (H2) and check, reading on the voltmeter (N) about the same voltage value

N.B.: in case of overload, it is possible that the engine lowers its speed and the voltage is reduced remarkably. In this case, it is necessary to reduce immediately the load.

CAUTION

For machines at 3000/3600 RPM the EP1 safety device will automatically provide to accelerate engine when load is drawn.

- See page M39.1 -









(B) Engine protection

GE 6000 - 6500 DES/GS-L

M 39.6

The engine is equipped with system which shuts down the engine in the event the oil pressure is too low. Low oil pressure is also indicated by the red

There is also a red battery charger warning lamp on the engine starter box which lights up if the battery is not being charged.

warning lamp on the engine starter box.



There is a thermal protection device to protect the battery in case there is too much charging current.


The thermal protection is reset by pressing the button.

If the thermic protection should continue to intervene, check:

- the battery charger and its connections
- the charge condition of the battery.

Once the cause of the problem has been removed, stop the engine by turning the starter key to the "OFF" position and restart the engine. In this way the protection will be assured.

The above mentioned devices function when the ignition is turned on.







WARNING



Have <u>qualified</u> personnel do maintenance and troubleshooting work.

• Stop the engine before doing any work inside the machine. If for any reason the machine must be operated while working inside, pay attention moving parts, hot parts (exhaust manifold and muffler, etc.) electrical parts which may be unprotected when the machine is open.

Remove guards only when necessary to perform maintenance, and replace them when the maintenance requiring their removal is complete.



HOT surface can hurt you

MOVING PARTS can injure · Use suitable tools and clothes.

Do not modify the components if not authorized.

- See pag. M1.1 -

By maintenance at care of the utilizer we intend all the operatios concerning the verification of mechanical parts, electrical parts and of the fluids subject to use or consumption during the normal operation of the machine.

For what concerns the fluids we must consider as maintenance even the periodical change and or the refills eventually necessary.

The routine cleaning of the machine is also considered maintenance.

The repairs cannot be considered among the maintenance activities, i.e. the replacement of parts subject to occasional damages and the replacement of electric and mechanic components consumed in normal use, by the Assistance Authorized Center as well as by MOSA.

The replacement of tires (for machines equipped with trolleys) must be considered as repair since it is not delivered as standard equipment any lifting system.

For the maintenance of the gasoline or Diesel engine please refer to the specific manual supplied with the unit.

The periodic maintenance should be performed according to the schedule shown in the engine manual. An optional hour counter (M) is available to simplify the determination of the working hours.

Every day check the oil level in the engine and in the air filter (if at oil bath). Make sure that these are no obstructions in the aspiration/exhaust ducts of the alternator, in the engine or in the cover (pieces of material, leaves or other).

See page M21 and M26.



NOTE

THE ENGINE PROTECTION DO NOT WORK WHEN THE OIL IS OF LOW QUALITY BECAUSE NOT CHARGED REGULARLY AT INTERVALS AS PRESCRIBED IN THE OWNER'S ENGINE MANUAL.

















UNITS WITH ELECTRIC STARTER

Check periodically the electrolyte level in the battery, especially after long periods of inactivity.

ATTENTION: the battery must have all its elements in good condition and must be filled with electrolyte.

The battery is automatically charged while the engine is running at speed.

PN.B.: In the models with safety protections, in case the battery is not reloaded, check the thermic protection (59A) reload it if it is the caseas well as the fuse (35).

PROCEDURE FOR RECHARGING A BATTERY

Keep to the advice indicated page - M36 -

Take off the breather caps of the battery.

Check the electrolyte level in all the elements of the

If necessary, add up distilled water to have the liquid at the recommended level.

Put back the breather caps of the battery.

Use a densimeter to determine the charge state of the battery.

SPECIFIC WEIGHT	CHARGE PERCENTAGE
1.265	100%
1.230	75%
1.200	50%
1.170	25%

MODELS WITH DRY AIR FILTER (CLEANING)

Replace the air filter cartridge every 200 hours when using the unit in a clean environment.

In a dusty environment, the filter cartridge must be replaced every 100 hours.

ALTERNATOR (brushless)

No other further periodical maintenance is necessary, as the alternator has no brushes or slip tings, and the output regulation is entirely electronic.

ALTERNATOR (with brushless)

Control the wear and the position of the carbon brushes at regular intervals (refer to the alternator manual supplied with the machine for details).

MODEL WITH COOLING LIQUID

Every day check the cooling liquid level. Verify each day freezing liquid and check periodically the radiator state (losses obstructions for air circulation etc.)

N.B.: all warning and decals should be checked once a year and replaced if missing or unreadable.

Check periodically the condition of the cables and tighten the connections.

In case the machine should not be used for more than 30 days, make shure that the room in which it is stored presents a suitable shelter from heat sources, weather changes or anything which can cause rust, corrosion or damages to the machine. See page M45.

In the maintenance operations avoid that polluting substances, liquids, exhausted oils, etc. bring damage to people or things or can cause negative effects to surroindings, health or safety respecting completely the laws and/or dispositions in force in the place.

In case of necessity for first aid and of fire prevention, see page. M2.5.



IMPORTANT



In the maintenance operations avoid that polluting substances, liquids, exhausted oils, etc. bring damage to people or things or can cause negative effects to surroindings, health or safety respecting completely the laws and/or dispositions in force in the place.

















In case the machine should not be used for more than 30 days, make sure that the room in which it is stored presents a suitable shelter from heat sources, weather changes or anything which can cause rust, corrosion or damages to the machine.

Have qualified personnel prepare the machine for storage.

GASOLINE ENGINE

Start the engine: It will run until it stops due to the lack of fuel.

Drain the oil from the engine sump and fill it with new oil (see page M25).

Pour about 10 cc of oil into the spark plug hole and screw the spark plug, after having rotated the crankshaft several times.

Rotate the crankshaft slowly until you feel a certain compression, then leave it.

In case the battery, for the electric start, is assembled, disconnect it.

Clean the covers and all the other parts of the machine carefully.

Protect the machine with a plastic hood and store it in o dry place.

DIESEL ENGINE

For short periods of time it is advisable, about every 10 days, to make the machine work with load for 15-30 minutes, for a correct distribution of the lubricant, to recharge the battery and to prevent any possible bloking of the injection system.

For long periods of inactivity, turn to the after soles service of the engine manufacturer.

Clean the covers and all the other parts of the machine carefully.

Protect the machine with a plastic hood and store it in a dry place.

In case of necessity for first aid and of fire prevention, see page. M2.5.



IMPORTANT



In the storage operations avoid that polluting substances, liquids, exhausted oils, etc. bring damage to people or things or can cause negative effects to surroindings, health or safety respecting completely the laws and/or dispositions in force in the place.



Have qualified personnel disassemble the machine and dispose of the parts, including the oil, fuel, etc., in a correct manner when it is to be taken out of service.

As cust off we intend all operations to be made, at utilizer's care, at the end of the use of the machine. This comprises the dismantling of the machine, the subdivision of the several components for a further reutilization or for getting rid of them, the eventual packing and transportation of the eliminated parts up to their delivery to the store, or to the bureau encharged to the cust off or to the storage office, etc.

The several operations concerning the cust off, involve the manipulation of fluids potentially dangerous such as: lubricating oil and battery electrolyte.

The dismantling of metallic parts liable to cause injuries or wounds, must be made wearing heavy gloves and using suitable tools.

The getting rid of the various components of the machine must be made accordingly to rules in force of law a/o local rules.

Particular attention must be paid when getting rid of:

lubricating oils, battery electrolyte, and inflamable liquids such as fuel, cooling liquid.

The machine user is responsible for the observance of the norms concerning the environment conditions with regard to the elimination of the machine being cust off and of all its components.

In case the machine should be cust off without any previous disassembly it is however compulsory to remove:

- tank fuel
- engine lubricating oil
- cooling liquid from the engine
- battery

NOTE: MOSA is involved with custing off the machine <u>only</u> for the second hand ones, when not reparable.

This, of course, after authorization.

In case of necessity for first aid and fire prevention, see page M2.5.



IMPORTANT



In the cust-off operations avoid that polluting substances, liquids, exhausted oils, etc. bring damage to people or things or can cause negative effects to surroindings, health or safety respecting completely the laws and/or dispositions in force in the place.





(B) Technical data and machine description

GE 6000 - 6500 DES/GS-L

M 51

The generating set GE 6000 - 6500 is a unit which transforms the mechanical energy, generated by endothermic engine, into electric energy, through an alternator.

Is meant for industrial and professional use, powered by an endothermic engine; it is composed of various main parts such as: engine, alternator, electric and electronic controls, the fairing or a protective structure.

The assembling is made on a steel structure, on which are provided elastic support which must damp the vibrations and also eliminate sounds which would produce noise.

Technical data	GE 6000 DES/GS-L	GE 6500 DES/GS-L
A.C. GENERATOR		
Three-phase generation Single-phase generation Frequency Power factor (cos φ)	6 kVA (5.4 kW) / 230 V / 26 A 50 Hz 0.9	6.5 kVA (5.2 kW) / 400 V / 9.4 A 4 kVA / 230 V / 17.4 A 50 Hz 0.8
ALTERNATOR	Self-excited, self-regulated	Self-excited, self-regulated
Type Insulating class	single-phase, synchronous H	three-phase, synchronous H
ENGINE		
Mark Model Type Displacement Cylinders Output Speed Fuel consumption Cooling system Engine oil capacity Starter Fuel	YANMAR L 100 AE 4-stroke 406 cm³ 1 6.5 kW (8.8 HP) 3000 rpm 245 g/kWh air 1.6 I electric Diesel	
GENERAL SPECIFICATIONS	D10001	
Battery Tank capacity Running time Protection Dimensions / max. Lxwxh (mm) *	12V - 40 Ah 18 I 14 h IP 23 910x530x620	126 Kg
Weight * Noise level * Dimensions and weight are inclusive of all par	99 LWA (74 dB(A) - 7 m)	99 LWA (74 dB(A) - 7 m)

OUTPUT

Declared powers at the following ambient conditions: temperature 20*C, relative humidity 30% altitude 100 m above sea level. In an approximative way one reduces: of 1% every 100 m altitude and of 2.5% for every 5°C above 25°C.

For possible modifications or changes to be brought on the engines, with climate conditions different from those above mentioned, please call our Assistance Authorized Centers.

ACOUSTIC POWER LEVEL

The machine respects the noise limits, expressed in sound power, given in the a.m. directives.

These limits can be used to judge the sound level produced on site.

For example: the sound power level of 100 LWA.

The sound pressure (noise produced) at 7 meters distance is about 75dBA (the limit value less 25).

To calculate the sound level at other distances use this formula:

$$dBA_X = dBA_Y + 10 \log \frac{ry^2}{rx^2}$$

At 4 meters the noise level becomes:

$$75 \text{ dBA} + 10 \log \frac{7^2}{4^2} = 80 \text{ dBA}$$

DIMENSIONS DIMENSIONS

SCHEMI ELETTRICI ELECTRICAL SYSTEM

RICAMBI SPARE PARTS



Dimensioni

B Dimensions


D Abmessungen

D Dimensions

D Dimensiones

GE 6000 - 6500 DES/GS-L

M 53



MO	SA.	Legenda schema elettrico Electrical system legende	① Stromlaufplan - Referenzliste ② Leyenda esquema eléctrico	M 60
© MOSA		© Legende des schemas electriq		W 14

A B C D G H M N	: Alternatore : Supporto connessione cavi : Condensatore : Interruttore differenziale : Presa 400V trifase : Presa 230V monofase : Contaore : Voltmetro	A: B: C: D: G: H: M:	Alternator Wire connection unit Capacitor G.F.I. 400V 3-phase socket 230V 1phase socket Hour-counter Voltmeter	A B C D G H M N	: Alternateur : Connexion câbles : Condensateurs : Interrupteur différentiel : Prise 400V triphasé : Prise 230V monophasé : Compte-heures : Voltmètre
L1	: Pressostato	L1:	Oil pressure switch	L1	: Pressostat huile
N1	: Spia carica batteria		Battery charge warning light	N1	: Voyant charge batterie
01	: Spia pressostato		Oil pressure warning light		: Voyant pressostat
R1	: Motorino avviamento	R1:	Starter motor	R1	: Moteur de démarrage
S1	: Batteria	S1:	Battery	S1	: Batterie
	: Regolatore tensione batteria		Battery charge voltage regulator		: Régulateur tension batterie
Z 1	: Elettrovalvola	Z1:	Solenoid valve	Z1	: Electrosoupape
Z2	: Interruttore magnetotermico	Z2:	Thermal magnetic circuit breaker	Z2	: Interrupteur magnétothermique
N3	: Relè	N3:	Relay	N3	: Relais
P4	: Protezione termica	P4:	Circuit breaker	P4	: Protection thermique
Α	Generator	Α :	Alternador		
В	Klemmleiste	В :	Soporte conexión cables		
C	Kondensatorbox		Condensador		
D	FI-Schalter (GFI)	D :	Interruptor diferencial		
^	0. 11 10010 1 1		T 1001111111		

Α	Generator	Α	:Alternador
В	Klemmleiste	В	:Soporte conexión cables
C	Kondensatorbox	C	:Condensador
D	FI-Schalter (GFI)	D	:Interruptor diferencial
G	Steckdose 400V 3-phasig	G	:Toma 400V trifásica
Н	Steckdose 230V 1-phasig	Н	:Toma 230V monofásica
M	Stundenzähler	M	:Cuentahoras
N	Voltmeter	N	:Voltímetro
L1	Öldruckschalter	L1	:Presostato
N1	Warnleuchte Batterieladung	N1	:Piloto carga batería
01	Warnleuchte Öldruck	01	:Piloto presostato
R1	Anlasser	R1	:Motor arranque
S1	Batterie	S 1	:Batería
U1	Laderegler Batterie	U1	:Regulador tensión batería
Z1	Magnetventil	Z 1	:Electroválvula
Z2	Thermomagnetschalter (Si-Automat)	Z2	:Interruptor magnetotérmico
N3	Relais	N3	:Relé

P4 : Protección térmica

P4 Thermosicherung

Schema elettrico

Stromlaufplan

GE 6000 - 6500 DES/GS-L

M 61

GB Electric diagram E Esquema eléctrico
1.0-05/04 F Schemas electriques N @ MOSA

8 8 ∽≥ (2) 21/05/04 25616-1

© MOSA

Schema elettrico■ Electric diagram

Stromlaufplan GB Electric diagram


1.0-05/04 F Schemas electriques

E Esquema eléctrico

GE 6000 DES/GS-L

M 61.1

Date: Date: | 24.10.2003 2 (3) 21/05/04 25616-1



Schema elettrico

Stromlaufplan **E** Esquema eléctrico

GE 6500 DES/GS-L

M 61.2

La MOSA si riserva a termini di legge la proprieta' del presente disegno con divieto di riprodurio o comunicarlo a terzi senza sua autorizzazione. eporace N. (3) [§] 30 LEGENDA COLORI KEY COLOR (W) BIANCOMHITE

21/05/04 25616-1

La MOSA è in grado di soddisfare ogni richiesta di pezzi di ricambio.

Se si desidera mantenere in efficienza la macchina, sempre nel caso di riparazione che comportino sostituzioni di pezzi MOSA, si deve pretendere che vengano usati solo parti di ricambio originali.

MOSA guarantees that any request for spare parts will be satisfied.

To keep the machine in full working order, when replacement of MOSA spare parts is required, always ask for genuine parts only. MOSA est en mesure de satisfaire toute demande de pièces de rechange.

Si l'ont veut garder l'appareil en bonne condition de fonctionnement, dans le cas de réparations qui comportent le replacement de pièces, on doit exiger que soient employées des pièces d'origine MOSA.

MOSA kann jedes Verlangen von Ersatzteilen befriedigen.

Wenn man die Maschine arbeitsfaehig halten will, im Falle von Reparaturen, die den Ersatz von MOSA-Teilen benoetigen, muss man immer originale MOSA Ersatzteile fordern.

MOSA está capacitada para satisfacer cualquier pedido de piezas de recambio.

Si se desea mantener la máquina en un funcionamiento eficaz, se debe usar siempre recambios originales, cuando es preciso sustituir piezas MOSA.

Per ordinare le parti di ricambio indicare - When ordering the spare parts, it is recommended to indicate - Pour commander les pièces de rechange, indiquer - Zur Bestellung der Teile muss man - Para hacer un pedido de piezas de recambio indicar:


- 1) n. di matricola / serial number / matricule de la machine / Seriennummer / n. de matrícula
- 2) stipo motosaldatrice e/o gruppo elettrogeno / model of welder and/or generating set / type de motosoudeuse et/ou groupe électrogène / Typ des Schweissgeraets und/oder Stromerzeugers / tipo motosoldadora y/o grupo electrógeno
- 3) an. tavola / n. table / n. table / taflenummer / n. tabla =
- 4) n. posizione / n. position / n. position / positionnummer / n. posición

- struttura della macchina ben visibile e di facile consultazione.

 The requested data are to be found on the data plate
 - res The requested data are to be found on the data plate located on the machine structure, quite visible and easy to consult.

II dati richiesti si trovano sulla targa dati situata sulla

- Les données demandées se trouvent sur la plaque des données, située sur la structure de la machine, bien visible et facile à consulter.
- Die verlangten Daten sind auf der Datenplatte, die sichtbar und leicht zu verstehen an der Maschinestruktur gehoert.
- Los datos solicitados se hallan en la placa de datos situada en la estructura de la máquina en un lugar visible y de fácil consulta.



LEGENDA NOTE - ABBREVIATIONS AND SYMBOLS - LEGENDE DES NOTES - NOTENERKLAERUNG - LEYENDA NOTAS:

- (EV) Specificare all'ordine il tipo di motorizzazione e le tensioni ausiliarie When ordering, specify the engine type and
 - the auxiliary voltage Type de moteur et/ou tensions auxiliaires doivent être spécifiés à la commande Motortyp und Hilfspannungen beim Auftrag angeben Especificar en el pedido el tipo de motor y las tensiones auxiliares
- (ER) Solo motore con avviamento a strappo Engine with recoil starter only Moteur avec démarrage à cordelette seulement Nur bei Motor mit Reversierstart Sólo motor con arranque por tirón
- (ES) Solo motore con avviamento elettrico Engine with electric starter only Moteur avec démarrage électrique seulement Nur bei Motor mit Elektrostart Sólo motor con arranque eléctrico
- (VE) Solo versione E.A.S. E.A.S version only Version E.A.S. seulement Nur bei E.A.S Ausfuehrung Sólo versión E.A.S.
- (QM) Specificare all'ordine la quantità in m When ordering, specify the length in meters A la commande spécifier la longueur en mètres Beim Auftrag die Laenge in Metern angeben Especificar en el pedido la cantidad en m
- (VS) Solo versioni speciali Special version only Versions spéciales seulement Nur bei Sonderausfuehrungen Sólo versiones especiales
- (SR) Solo a richiesta By request only Sur demande seulement Nur auf Wunsch Sólo bajo pedido




GE 6000 - 6500 DES/GS-L

HL 21

Tabla de recambios

1.0-05/04 Piéces de rechange © MOSA



	Ri	icambi	① Ersatzteile		HL
MU	5A (B) Sp	oare parts	E Tabla de recambios	GE 6000 - 6500 DES/GS-L	21.1
© MOSA	1.0-05/04 F Pi	éces de rechange	ND		

© MOSA	1.0-05/04 F Piéces		GE 0000 - 0300 DES/GS-L	21.1
Pos.	Rev. Cod.	Descr.	Note	
1	259123097	CUFFIA SUP. ALTERNATORE	GE 6000 - 6500 DES/GS-L	
2	256602200	MOTORE YANMAR L100 AE-DEG	GE 6000 - 6500 DES/GS-L	
3	256651035	ANTIVIBRANTE	GE 6000 - 6500 DES/GS-L	
4	256703100	ALTERNATORE	GE 6000 DES/GS-L	
5	256011035	ANTIVIBRANTE	GE 6000 - 6500 DES/GS-L	
6	256081050	BARELLA	GE 6000 - 6500 DES/GS-L	
7	256153101	STAFFA SUPP. ALTERNATORE		
8	256803100	ALTERNATORE	GE 6500 DES/GS-L	
Pos.	Rev. Cod.	Descr.	Note	
1	259123097	ALTERNATOR UPPER COVER	GE 6000 - 6500 DES/GS-L	
2	256602200	YANMAR ENGINE L100 AE-DEG	GE 6000 - 6500 DES/GS-L	
3	256651035	VIBRATION DAMPER	GE 6000 - 6500 DES/GS-L	
4	256703100	ALTERNATOR	GE 6000 DES/GS-L	
5	256011035	VIBRATION DAMPER	GE 6000 - 6500 DES/GS-L	
6	256081050	FRAME	GE 6000 - 6500 DES/GS-L	
7	256153101	ALTERNATOR FIXING BRACKET		
8	256803100	ALTERNATOR	GE 6500 DES/GS-L	



① Ricambi


① Ersatzteile **E** Tabla de recambios

GE 6000 - 6500 DES/GS-L


HL 22

GB Spare parts

1.0-05/04 F Piéces de rechange © MOSA







		(Ricambi	① Ersatzteile	-comme we are there are a resident and a second a second and a second	HL
M O	15A	Ricambi Spare parts	(E) Tabla de recambios	GE 6000 - 6500 DES/GS-L	22.1
© MOSA		F Piéces de rechange		Service (Production Service Se	i steron viscous

Pos.	Rev. Cod.	Descr.	Note
1	103011310	VOLTMETRO	GE 6000 DES/GS-L
2	105511810	CONTAORE	
3	1302040	SPIA 12V	
4	107302460	STARTER A CHIAVE	
5	232027130	CAPPUCCIO PROTEZIONE I.D.	
6	1241010	PIASTRINA	
7	220237105	Vedi Cod.256007105	GE 6000 DES/GS-L
8	232027036	GUIDA	
9	256707325	INTERR.MAGNETOTERMICO BIP.25A	GE 6000 DES/GS-L
10	306479199	RELE' AVV. ELETTRICO	
11	256088003	FIANCATA CARENATURA + FRONTALE	GE 6000 DES/GS-L
12	105111520	PRESA CEE 220V MONOFASE	GE 6000 DES/GS-L
13	307017240	PRESA 220V 16A	GE 6000 DES/GS-L
14	155307107	DISGIUNTORE TERMICO	
15	105111550	VOLTMETRO FS 500V	GE 6500 DES/GS-L
16	256078003	FIANCATA CARENAT. CON FRONTALE	GE 6500 DES/GS-L
17	734507325	INTERRUTTORE MAGNETOTERMICO	GE 6500 DES/GS-L
18	256557325	INTERRUTTORE MAGNETOTERMICO	GE 6500 DES/GS-L
19	105111540	Vedi Cod.219937105	GE 6500 DES/GS-L
20	305907270	PRESA CEE 16A 400V 3P+N+T	GE 6500 DES/GS-L
21	259107241	PRESA SCHUKO 16A 230V - 2P+T	GE 6500 DES/GS-L
Pos.	Rev. Cod.	Descr.	Note
Pos.	Rev. Cod. 103011310	Descr. VOLTMETER	<i>Note</i> GE 6000 DES/GS-L
(ACCUSED ACCUSED			1
1	103011310	VOLTMETER	1
1 2	103011310 105511810	VOLTMETER HOURMETER	1
1 2 3	103011310 105511810 1302040	VOLTMETER HOURMETER WARNING LIGHT 12V	1
1 2 3 4	103011310 105511810 1302040 107302460	VOLTMETER HOURMETER WARNING LIGHT 12V STARTER KEY	1
1 2 3 4 5	103011310 105511810 1302040 107302460 232027130	VOLTMETER HOURMETER WARNING LIGHT 12V STARTER KEY CAP	1
1 2 3 4 5	103011310 105511810 1302040 107302460 232027130 1241010	VOLTMETER HOURMETER WARNING LIGHT 12V STARTER KEY CAP PLATE	GE 6000 DES/GS-L
1 2 3 4 5 6 7	103011310 105511810 1302040 107302460 232027130 1241010 220237105	VOLTMETER HOURMETER WARNING LIGHT 12V STARTER KEY CAP PLATE See Part n°256007105	GE 6000 DES/GS-L
1 2 3 4 5 6 7 8	103011310 105511810 1302040 107302460 232027130 1241010 220237105 232027036	VOLTMETER HOURMETER WARNING LIGHT 12V STARTER KEY CAP PLATE See Part n°256007105 FIXING GUIDE	GE 6000 DES/GS-L GE 6000 DES/GS-L
1 2 3 4 5 6 7 8	103011310 105511810 1302040 107302460 232027130 1241010 220237105 232027036 256707325	VOLTMETER HOURMETER WARNING LIGHT 12V STARTER KEY CAP PLATE See Part n°256007105 FIXING GUIDE CIRCUIT BREAKER	GE 6000 DES/GS-L GE 6000 DES/GS-L
1 2 3 4 5 6 7 8 9	103011310 105511810 1302040 107302460 232027130 1241010 220237105 232027036 256707325 306479199	VOLTMETER HOURMETER WARNING LIGHT 12V STARTER KEY CAP PLATE See Part n°256007105 FIXING GUIDE CIRCUIT BREAKER RELAY, ELECTRIC START	GE 6000 DES/GS-L GE 6000 DES/GS-L
1 2 3 4 5 6 7 8 9 10	103011310 105511810 1302040 107302460 232027130 1241010 220237105 232027036 256707325 306479199 256088003	VOLTMETER HOURMETER WARNING LIGHT 12V STARTER KEY CAP PLATE See Part n°256007105 FIXING GUIDE CIRCUIT BREAKER RELAY, ELECTRIC START COVER WITH FRONT PANEL	GE 6000 DES/GS-L GE 6000 DES/GS-L GE 6000 DES/GS-L
1 2 3 4 5 6 7 8 9 10 11	103011310 105511810 1302040 107302460 232027130 1241010 220237105 232027036 256707325 306479199 256088003 105111520	VOLTMETER HOURMETER WARNING LIGHT 12V STARTER KEY CAP PLATE See Part n°256007105 FIXING GUIDE CIRCUIT BREAKER RELAY, ELECTRIC START COVER WITH FRONT PANEL EEC SOCKET SINGLE-PHASE 220V	GE 6000 DES/GS-L
1 2 3 4 5 6 7 8 9 10 11 12 13	103011310 105511810 1302040 107302460 232027130 1241010 220237105 232027036 256707325 306479199 256088003 105111520 307017240	VOLTMETER HOURMETER WARNING LIGHT 12V STARTER KEY CAP PLATE See Part n°256007105 FIXING GUIDE CIRCUIT BREAKER RELAY, ELECTRIC START COVER WITH FRONT PANEL EEC SOCKET SINGLE-PHASE 220V EEC SOCKET 16A, 220V 2P+T	GE 6000 DES/GS-L
1 2 3 4 5 6 7 8 9 10 11 12 13 14	103011310 105511810 1302040 107302460 232027130 1241010 220237105 232027036 256707325 306479199 256088003 105111520 307017240 155307107	VOLTMETER HOURMETER WARNING LIGHT 12V STARTER KEY CAP PLATE See Part n°256007105 FIXING GUIDE CIRCUIT BREAKER RELAY, ELECTRIC START COVER WITH FRONT PANEL EEC SOCKET SINGLE-PHASE 220V EEC SOCKET 16A, 220V 2P+T THERMAL SWITCH	GE 6000 DES/GS-L
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15	103011310 105511810 1302040 107302460 232027130 1241010 220237105 232027036 256707325 306479199 256088003 105111520 307017240 155307107 105111550	VOLTMETER HOURMETER WARNING LIGHT 12V STARTER KEY CAP PLATE See Part n°256007105 FIXING GUIDE CIRCUIT BREAKER RELAY, ELECTRIC START COVER WITH FRONT PANEL EEC SOCKET SINGLE-PHASE 220V EEC SOCKET 16A, 220V 2P+T THERMAL SWITCH VOLTMETER FS 500V	GE 6000 DES/GS-L
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16	103011310 105511810 1302040 107302460 232027130 1241010 220237105 232027036 256707325 306479199 256088003 105111520 307017240 155307107 105111550 256078003	VOLTMETER HOURMETER WARNING LIGHT 12V STARTER KEY CAP PLATE See Part n°256007105 FIXING GUIDE CIRCUIT BREAKER RELAY, ELECTRIC START COVER WITH FRONT PANEL EEC SOCKET SINGLE-PHASE 220V EEC SOCKET 16A, 220V 2P+T THERMAL SWITCH VOLTMETER FS 500V COVER WITH FRONT PANEL	GE 6000 DES/GS-L GE 6500 DES/GS-L
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16	103011310 105511810 1302040 107302460 232027130 1241010 220237105 232027036 256707325 306479199 256088003 105111520 307017240 155307107 105111550 256078003 734507325	VOLTMETER HOURMETER WARNING LIGHT 12V STARTER KEY CAP PLATE See Part n°256007105 FIXING GUIDE CIRCUIT BREAKER RELAY, ELECTRIC START COVER WITH FRONT PANEL EEC SOCKET SINGLE-PHASE 220V EEC SOCKET 16A, 220V 2P+T THERMAL SWITCH VOLTMETER FS 500V COVER WITH FRONT PANEL CIRCUIT BREAKER	GE 6000 DES/GS-L GE 6500 DES/GS-L GE 6500 DES/GS-L GE 6500 DES/GS-L GE 6500 DES/GS-L
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18	103011310 105511810 1302040 107302460 232027130 1241010 220237105 232027036 256707325 306479199 256088003 105111520 307017240 155307107 105111550 256078003 734507325 256557325	VOLTMETER HOURMETER WARNING LIGHT 12V STARTER KEY CAP PLATE See Part n°256007105 FIXING GUIDE CIRCUIT BREAKER RELAY, ELECTRIC START COVER WITH FRONT PANEL EEC SOCKET SINGLE-PHASE 220V EEC SOCKET 16A, 220V 2P+T THERMAL SWITCH VOLTMETER FS 500V COVER WITH FRONT PANEL CIRCUIT BREAKER CIRCUIT BREAKER	GE 6000 DES/GS-L GE 6500 DES/GS-L
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18	103011310 105511810 1302040 107302460 232027130 1241010 220237105 232027036 256707325 306479199 256088003 105111520 307017240 155307107 105111550 256078003 734507325 256557325 105111540	VOLTMETER HOURMETER WARNING LIGHT 12V STARTER KEY CAP PLATE See Part n°256007105 FIXING GUIDE CIRCUIT BREAKER RELAY, ELECTRIC START COVER WITH FRONT PANEL EEC SOCKET SINGLE-PHASE 220V EEC SOCKET 16A, 220V 2P+T THERMAL SWITCH VOLTMETER FS 500V COVER WITH FRONT PANEL CIRCUIT BREAKER CIRCUIT BREAKER See part no. 219937105	GE 6000 DES/GS-L GE 6500 DES/GS-L



Thicambi

GB Spare parts


1.0-05/04 Piéces de rechange

① Ersatzteile

(E) Tabla de recambios

GE 6000 - 6500 DES/GS-L

HL 23




	MD5A (i) Ricambi (ii) Spare parts	① Ersatzteile	OF COOR CFOR BFO/00	HL
l	GB) Spare parts	Tabla de recambios	GE 6000 - 6500 DES/GS-L	23.1
1	© MOSA 1.0-05/04 F Piéces de rechange	(NL)		Ш

© MOSA	1.0-05/04 F Piéces de rechange N			= 10	
Pos.	Rev. Cod.	Descr.	Note		
1	307402208	TUBO IN GOMMA (L=MT.1)	(qm)		
2	308102207	TUBO GOMMA (L=MT.1)	(qm)		
3	259102026	TAPPO SERBATOIO			
4	259102020	SERBATOIO CARBURANTE			
5	107509005	GUARNIZIONE	(qm)		
6	259102025	RUBINETTO CARBURANTE			
7	256602226	FILTRO PER GASOLIO			
8	256022275	REGOLATORE DI TENSIONE			
9	256658235	GRIGLIA ASPIRAZ.GENERATORE			
10	259118015	FIANCATA CAREN. LATO BATTERIA			
11	259119162	COPERCHIO ISPEZIONE BATTERIA			
12	209509150	BATTERIA 45 AH			
Pos.	Rev. Cod.	Descr.	Note		
1	307402208	RUBBER PIPE	(qm)		
2	308102207	PIPE	(qm)		
3	259102026	TANK CAP			
4	259102020	FUEL TANK			
5	107509005	GASKET	(qm)		
6	259102025	TAP,FUEL			
7	256602226	FUEL FILTER			
8	256022275	VOLTAGE REGULATOR			
9	256658235	GRATE AIR INLET			
10	259118015	COVER BATTERY SIDE			
11	259119162	INSPECTION BATTERY COVER			
12	209509150	BATTERY			









Pos.	Rev.	Cod.	Descr.	Descr.	Note	
1		107012150	CAVALLOTTO	U-BOLT	52-11-2-00000000000000000000000000000000	
2		259101051	MANIGLIA/PIEDE DI STAZIONAM.	HANDLE / PARKING STAND		
7		259101160	ASSALE	AXLE		
9		6075020	COPIGLIA	PIN, SPLIT		5
10		102042490	RUOTA	WHEEL		ç
						10/41/02

R 1.1

sia con le nu Dear C	cliente, potrà inviarci ove tavole ricambi ustomer, You can sen rts tables as well as w	che con le vecchi ed us the request i	e, a mezzo for order of	FAX o per p MOSA origin	oosta.	27
Richiesta	da/Request from:				data/date	,
Inviateci i s machine be	ature: eguenti ricambi de low: IOSA / MOSA SPARI	lla sotto elenca	ta macchi	na /Please se	end use us followi	ng sapre parts f
modello tip	oo / model type:					
	nr. ma	tricola / serial n	r:			
	NUOVE TAV	OLE/NEW TA	BLES		VECCHIE T	
	tavola nr. table nr.	posizione position	q.tà q.ty		OLD TA	g.tà/q.ty
	table IIII	pooliion	4,	_	554,657,5546	quayquy
,						
				_	9	

	-					
	31-11-31			1		
	<u> </u>		-	-		
RICAMBI MO	TORE / ENGINE SP	ARE PARTS:		-	la a su canonimical	in the second se
	tore / engine mod					
	otore / engine seri					
		codice e/o posi code and/or po			one e/o tavola on and/or table	q.tà q.ty
	-	7 - 10 -	(10-1-10112-0000000000000000000000000000	wante y		
		10000 X 32 - 10 300 100 - 2 300 - 10	, , , , , , , , , , , , , , , , , , ,			
RICAMBI AL	TERNATORE SINCE	RONO / SYNCHI	RONOUS A	ALTERNATO	R SPARE PARTS:	
	ernatore / alternato					
natricola al	ternatore / alternat	or serial nr.:			•••	
		codice e/o posi code and/or pos			one e/o tavola on and/or table	q.tà q.ty
					- Vitte: 2	A STATE OF THE STA